Bosch-Norm

N51M M27

2019-05-14

Delivery instructions for IT-Security of machines, installations and production equipment (MAE)

Document part number:	4 497 040 708
Technical responsibility:	hlo2fe C/TED1 (400)
Replaces edition:	2015-08-14
Changes:	New Bosch-Norm layout; chap. 2 "Transitional regulation" and chap. 8 “IT-Security guidelines for external service providers” supplemented; Chap. 4 "Technical specifications and requirements" updated and extended by point 4 "Remote access/remote maintenance"; Chap. 5 "Using the IT-Security questionnaire" updated In chap. 9 “Normative references” attachment 2 “IT-Security questionnaire User documentation” and attachment 3 “ and “IT-Security guidelines for external service providers” supplemented; Editorial changes
Change information:	AEN 4497R29368 (internal document of the Bosch Group)

Area of validity, binding force, freedom to disclose	
Valid for	Bosch Group
Binding for	Bosch Group
Binding due to	SC-ITM decision (2015-02-25)
Recommended for	Not applicable
Disclosure	No restrictions

This Bosch-Norm is binding for suppliers if it is part of the order.

FEO1IZ 2020-01-08 NormMaster

© Robert Bosch GmbH. All rights reserved, also regarding any disposal, exploitation, reproduction, editing, distribution, as well as in the event of application for industrial property rights.

General information	
Series	N51M Machine tools, delivery instructions
Bosch-Norm standardization expert	snm1si C/TED6 (497)
Document language	en
Original language	de

Translation			
Release date	Source language	Target language	Author
2019-04-26	de	en	C/TED6 (497)

In case of doubt, the original language edition of this Bosch-Norm applies.
The comma is used as the decimal marker.
Valid edition only in NormMaster. No change service for copies.

1 Scope

This Bosch-Norm specifies the IT-Security requirements for machines, installations and production equipment (MAE).

2 Transitional regulation

This Bosch-Norm will become binding with a transitional period of 3 month.

This Bosch-Norm will become binding in the context of Post Merger Integration (PMI) of new divisions with a transitional period of 12 months.

3 General

The Bosch-Norm N51M M27 is binding for all machine types around the world.

Deviations from the N51M M27 should be coordinated with the responsible plant-representative for IT in manufacturing (Local-ITM).

The following standards and guidelines serve as basis for the IT-Security questionnaire, **in the version valid at the time of order acceptance respectively:**

- VDI/VDE 2182 SHEET 3.3 IT-security for industrial automation - Example of use of the general model for plant managers in process industry - LDPE-plant
- IEC 62443-3-3 * CEI 62443-3-3 Industrial communication networks - Network and system security - Part 3-3: System security requirements and security levels.

The supplier is obliged to apply these instructions. The suppliers have to change deviations **that do not have our approval** for us **free of charge**.

The cooperation of the customer in the technical solution or the approval of design characteristics does not relieve the supplier of the sole responsibility for flawless function and do not restrict the assured properties in any way.

FEO1IZ 2020-01-08 NormMaster

© Robert Bosch GmbH. All rights reserved, also regarding any disposal, exploitation, reproduction, editing, distribution, as well as in the event of application for industrial property rights.

4 Technical specifications and requirements

The following technical specifications should be considered and adhered to; the orderer has to be informed in case of deviations.

1. Authentication measures

In case of new installations, authentication information have to be transmitted exclusively via secure protocols or through a transport encryption.

2. Wi-Fi

If Wi-Fi should be used for point-to-point connections, then channels 36 and 40 in the 5 GHz band have been reserved for this. An authentication is required for a Wi-Fi point-to-point connection in the manufacturing zone. A spectrum analysis has to be carried out before starting a Wi-Fi connection. The requirements have to be coordinated with the local ITM.

3. Export control

IT-Software and technologies have to adhere to the Export Control (CD03402) for foreign trade.

4. Remote access/remote maintenance

If a remote maintenance is necessary, then the use of the Bosch-internal solution Remote Shopfloor Access is compulsory for the remote maintenance.

FEO1IZ 2020-01-08 NormMaster

5 Using the IT-Security questionnaire

The IT-Security questionnaire in the appendix should be used in three phases:

- At the time of offer creation, the following proof should be filled out:
  - 1. Supplier information
  - 2. Proof
  - 3. Part-A- Planned IT-devices up to component level
- At the time of order receipt:
  - 4. Part B - Installed IT-devices has to be filled and made available latest at the preliminary inspection.
- The entire IT-Security questionnaire should be made available at the time of delivery.

The IT-Security questionnaire serves the network planning and documentation during the delivery of the machines as well as the IT risk assessment of the used IT systems in the MAE.

The supplier properties can, if required, be used as basis for the supplier development.

6 Documentation

The entire IT-Security questionnaire can be used as basis of a technical IT-Documentation and is part of the installation documentation (see N51M M20, chap.10, folder 6, Electrical documentation) and is handed over to the orderer latest at the time of the MAE delivery.

Within the EU, the N51M M20 applies for the documentation. Outside the EU, the IT-Security questionnaire has to be signed and provided to the orderer.

The IT-Security questionnaire is available in NormMaster in Excel format as an attachment of the Bosch-Norm N51M M27 and/or the corresponding user documentation as PDF.

© Robert Bosch GmbH. All rights reserved, also regarding any disposal, exploitation, reproduction, editing, distribution, as well as in the event of application for industrial property rights.

7 Preliminary inspection and acceptance

The IT-Security questionnaire is to be checked by the orderer during the preliminary inspection and acceptance in the plant. He can be supported by the local-ITM or the IT-planer.

8 IT-Security guidelines for external service providers

During the assignment by the assigning technical department, the attachment "IT-Security guidelines for external service providers" should be handed over to the service provider.

The "IT-Security guidelines for external service providers" are available in NormMaster in PDF format as an attachment of the Bosch-Norm N51M M27.

9 Normative references

The following documents are applicable for using this Bosch-Norm. With dated references, solely the edition referred to applies. With undated references, the last edition of the indicated document applies (including all revisions). Intentionally cited historical documents are additionally identified as "H" in the column "Type."

No.	Document number	Title	Type
1	N51M M27	Attachment 1: IT-Security questionnaire	M
2	N51M M27	Attachment 2: IT-Security questionnaire User documentation	M
3	N51M M27	Attachment 3: IT-Security guidelines for external service providers	M
4	N51M M20	General delivery instructions for machines, installations and production equipment (MAE)	Z
5	VDI/VDE 2182 BLATT 3.3	IT-security for industrial automation - Example of use of the general model for plant managers in process industry - LDPE-plant	Z
6	IEC 62443-3-3 * CEI 62443-3-3	Industrial communication networks - Network and system security - Part 3-3: System security requirements and security levels	Z
7	CD03402	Central Directive Export Control	Z

Type M = document to be supplied; Z = cited document; H = historical document

FEO1IZ 2020-01-08 NormMaster

© Robert Bosch GmbH. All rights reserved, also regarding any disposal, exploitation, reproduction, editing, distribution, as well as in the event of application for industrial property rights.