

[illegible]

Reset

The diagram shows a circuit for the Reset signal. It includes a 10k resistor connected to a 'RUN' line and pin 1 of a J3 connector. Pin 2 of the J3 connector is connected to GND. The J3 connector is labeled 'Conn_01x02'.

H1 MountingHole H2 MountingHole
H3 MountingHole H4 MountingHole

9/28/2024