







LCD




RESET and BOOT



Micor-SD





TYPE-C



POWER

ESP32-S3-0.96-SD



ESP32-S3N4R2

