SUBCONTRACTOR FIELD WORK ORDER

Crew 1: Contents Handling, Site Protection & Demolition

INSURED / CLIENT
David & Amanda Torres

SITE ADDRESS
Confirm with the superintendent before mobilization

CLAIM / CARRIER
CB-2026-8812 | Chubb Insurance | Policy CHU-77218-A

SCOPE REFERENCE
T-1, T-9

SITE RULES

Hours: Monday-Friday, 7:00 AM - 5:00 PM. Weekend work requires superintendent approval 24h in advance.

Parking / Staging: Park only in the approved staging area; keep driveways and streets clear for material deliveries.

Dust & Debris: Stage debris in the designated dumpster/containment area. No debris may remain in occupied areas overnight.

Emergency: Notify the on-site superintendent immediately for any incident; call 911 for gas, electrical or flooding emergencies. Locate the main panel and water shutoff before starting.

$ CONTRACT AMOUNT & BUDGET LINE LINKAGE

TASK	TRADE PACKAGE	AMOUNT
T-1	Demolition & Fire Debris *Sub bid*	**$6,700.00**
T-9	Final Cleaning & Punch List *Sub bid*	**$1,020.00**
	TOTAL CONTRACT AMOUNT	**$7,720.00**

1 SCOPE SUMMARY

Perform dust barriers, contents manipulation, structural tear-out, subfloor prep, concrete grinding, debris staging and final detail clean for: Demolition & Fire Debris, Final Cleaning & Punch List. Work only from the approved field scope; report any variance to the superintendent before proceeding.

2 SAFETY, SITE PROTECTION & CONTAINMENT

- Erect 6-mil poly dust barriers with zipper doors at every work boundary; verify seals before starting.
- Run HEPA air scrubbers continuously and rotate filters per manufacturer intervals.
- Wear N95 respirators, sealed eye protection and cut-rated gloves for all tear-out work.
- Photograph and inventory all contents before moving; store in labeled, protected staging.
- Locate and isolate water, gas and electrical services before any demolition starts.
- Stage debris only in the designated containment area; keep egress paths clear at all times.

3 STEP-BY-STEP FIELD INSTRUCTIONS

Scope Execution

- Complete the Demolition & Fire Debris scope described in the approved estimate: Tear out charred kitchen cabinetry, burnt sheetrock, soot-damaged ceiling, remove contaminated appliances and debris haul. (3 working day(s)).
- Complete the Final Cleaning & Punch List scope described in the approved estimate: Final ozone treatment, scrub cabinetry inside/out, polish countertops and appliances, punch-list touch-ups, PM handover. (2 working day(s)).

Quantities & Material Staging

- Verify all field quantities against the approved scope before ordering or cutting materials.

Sequencing (CREW-1)

- T-9: mobilize only after predecessor scope (T-7, T-8) is complete and accepted.

4 MATERIAL SPECIFICATIONS & FASTENERS

- All materials must match the approved manufacturer specifications and be staged in a dry, protected area.
- Fasten per manufacturer requirements; use corrosion-resistant fasteners in wet or exterior areas.
- Verify quantities with the superintendent before installing; retain packaging and cut sheets for verification.

5 QUALITY CONTROL & PUNCHLIST STANDARDS

[ ] All debris removed from occupied areas and staged in the approved location.
[ ] Containment intact - zero visible dust migration beyond the barrier.
[ ] Substrate sound, dry and ready for the next trade; photos uploaded.
[ ] Contents inventory reconciled and signed by the homeowner where applicable.
[ ] Walk the work area with the superintendent and sign off on this sheet before demobilizing.

DO NOT PERFORM / SCOPE EXCLUSIONS

Do not perform any credited, omitted or out-of-scope work without a written change order.

SIGN-OFF & ACCEPTANCE

Crew Lead Signature | Print Name | Date

Subcontractor acknowledges the scope, quantities, materials and sequencing above. Any deviation requires a written change order approved by the superintendent before work continues.