

First steps Instruction

Connection:

1. Connect 5V to device, using AC adapter or powerbank, the 12V power supply is also acceptable, but not recommended. 12V the maximum voltage
2. Check you phone, find for ecologicXXXX device
3. Connect to it, use password "12345678"
4. The phone will ask you about "remain connection", answer "yes"
5. On your phone go to 192.168.4.1 address
6. Open WIFI settings, then choose your WIFI network, click save
7. Now we need to find your device IP address, use your router, or go to site ecologic.go.ro and find for IP address
8. Open your device IP address

Redmi-Note-12	5a:cf:d9:a3:1c:0c	192.168.1.138	LAN3	22h 51min 27s
Redmi-Note-12	ce:c0:03:1a:c9:02	192.168.1.156	LAN3	23h 40min 0s
ESP-F7A7F7	68:c6:3a:f7:a7:f7	192.168.1.159	LAN3	23h 43min 37s
ESP-2E2D4A	c8:2b:96:2e:2d:4a	192.168.1.158	LAN3	23h 46min 6s
EPUADNIW004B	e0:70:ea:d7:ae:07	192.168.1.155	LAN3	23h 54min 35s

Main Page

The screenshot shows a web interface for a smart home system. It features several input fields for controlling different components: 'tx vent 1', 'd0 switch 1', 'rx light -123.12', 'd5 comp power 0', 'd5 comp rec 0', and 'd7 PWM 0'. Below these is a section for 'ds18b20 temp.' displaying a value of '34.13', and 'd1 ir:' displaying '1'. An 'ADC:' section shows a value of '-123.12'. At the bottom, there is an 'update' button, a progress bar, and a JSON data string. A navigation bar at the very bottom contains links for 'cont', 'Wifi', 'conn', 'buttons', 'condition', 'ws2811', and 'API'.

You can switch relays, or use different power for DC, also you can see temperature and humidity

WIFI page

Choose your WIFI settings, it is recommended to choose **Client mode**,

Client mode – your device working in WIFI client mode

AP mode – your device will be discoverable via WIFI

Client+AP – both modes together

*** IMAGE: WIFI-01

You are connected to the access point: Home_2

Local IP: 192.168.1.151

Software access point: ecologic_1403884

Software access point IP: 0.0.0.0

WiFi SSID	Encryption	Signal Strength
DIGI-00063852		-78
EMRDO		-91
DIGI-28y2		-70
door3F2628		-87
Home_6		-32
TP-Link_EE78_EXT		-88
TP-Link_D13C		-86
Home_2		-55
Home		-61

WiFi Mode:

WiFi Mode:

SoftAP Password:

WiFi networks:

Default: 12345678. Leave empty to keep current.

Choose your WIFI settings, it is recommended to choose **Client mode**,

Client mode – your device working in WIFI client mode

AP mode – your device will be discoverable via WIFI

Clint+AP – both modes together

Server Device ID:

Server URL:

Sync seconds interval:

Owner:

Device name:

AP Password:

Device port:

GMT+ (timezone):

Use Static IP: ☒

Static IP:

Gateway:

Subnet:

DNS 1:

DNS 2 (optional):

Node-RED Server

Use node-red ☐

Node-RED Server Address:

Server URL – needed for device, to connect to API server, don't change it

Sync interval – how often the device will check updates from server, it is recommended not less then 5 seconds

Owner – if you want to sell device, change for a new name of owner

Device name – use short device name

AP password – password for first connection

Port – how you can reach your device ex: 192.168.1.151:80

Use static IP – it is recommended to use static IP, to do not change it after you router reboots

Node-red Server – you can configure the hook events by this node-red server