

## **Bot Instructions for Github**

To make a new bot on Telegram, add BotFather, and type [/newbot](#). Choose a name for the bot. For this make it - [Clipoz Keychain Tracker](#). Then make the username something related. Copy the token, and paste it into the code

Copy it into where it is black.

```
const char* WIFI_SSID      = "placeholder";
const char* WIFI_PASSWORD = "placeholder";
const char* BOT_TOKEN      = "████████████████████████████████████████";
const char* CHAT_ID        = "placeholder";
```

Next, add User info, and type [/start](#). Copy the id, and put it where it is yellow.

```
const char* WIFI_SSID      = "placeholder";
const char* WIFI_PASSWORD = "placeholder";
const char* BOT_TOKEN      = "████████████████████████████████████████";
const char* CHAT_ID        = "████████████████████████████████████████";
```

Almost there. Next add in your wifi password and username into the code to finish setting it up. Don't share this code with anyone after you add it.

Finally, start a new conversation with your bot, searching its username and pressing start, make sure to use the Profile picture provided in the files!