TechGear Troubleshooting Guide (techgear_troubleshooting.md)

Product Won't Power On
1. Charge device for at least 30 minutes and retry.
2. Try a different charging cable/adapter.
3. Hold power button for 15 seconds to force restart.
4. If still unresolved, this is a hardware issue — direct customer to warranty claim.

Device Won't Connect to Wi-Fi/Bluetooth
1. Restart device and connecting phone/router.
2. Confirm software is updated (Settings > About > Update).
3. Forget network/device pairing and reconnect.
4. If issue persists, escalate to technical support.

App Crashes or Freezes
1. Force-close and reopen app.
2. Confirm app is updated from app store.
3. Restart device.
4. If crashes continue, request device model & app version, then escalate to tech support.

Common Error Scenarios

- Error Code E01: Battery calibration — drain battery completely, then charge to 100% uninterrupted.
- Error Code E02: Firmware corruption — customer MUST NOT reinstall manually; escalate
directly to tech support.
- Error Code E03: Sensor malfunction — cannot be fixed remotely; escalate to warranty/repair team.