

FEATURES & SPECIFICATION

INTENDED USE

Support bracket for pendant mounting the Indura® small housing. Not available for large housing units.

CONSTRUCTION

16 ga. galvanized sheet steel.

3.8" x 4" x 1.45"

Includes one pendant mount bracket and two 1/2" slotted hex head screws.

Conduit and canopy are not provided.

Actual performance may differ as a result of end-user environment and application. Note: Specifications subject to change without notice.



Unit Accessories



Example: ELA IND PM ORDERING INFORMATION

ELA IND PM

Series

ELA IND PM

Pendant mount kit for Indura small housing: IND618, IND654, IND1236, IND1254, IND6100, IND12100 (XTRA and SEL options), IND24100 (XTRA and SEL options)

FEATURES & SPECIFICATIONS

INTENDED USE

Battery support brackets for use when ceiling mounting the Indura® small housing unit. Not available for large housing units.

CONSTRUCTION

20 ga. galvanized sheet steel

Includes one ceiling-mount bracket and one Phillips head screw.

Note: Must be used for ceiling-mount applications.

Actual performance may differ as a result of end-user environment and application.

Note: Specifications subject to change without notice.

Unit Accessories



ORDERING INFORMATION

Lead times will vary depending on options selected. Consult with your sales representative.

Series

UL Listed products

ELA IND CM1 Ceiling mount kit for IND618

ELA IND CM2 Ceiling mount kit for IND654, IND1236, IND1254

ELA IND CM3 Ceiling mount kit for IND6100

ELA INDX CM1 Ceiling mount kit for INDX618 (for use with standard, XTRA, or SEL only)

ELA INDX CM2 Ceiling mount kit for INDX654/1236/1254 (for use with standard, XTRA, or SEL only)

Example: ELA IND CM1

EMERGENCY ELA-IND-PM-CM-RHB-R3

ELA IND PM CM RHB R3 Unit Accessories

FEATURES & SPECIFICATION

INTENDED USE

Bracket for surface mounted single-gang j-boxes with 3-9/32" hole spacings for Indura remote heads.

CONSTRUCTION

Seals opening between surface mount box and and Indura mounting plate.

Dimensions fit footprint of remote Indura head mounting plate (see spec sheet ELA-IND).

Actual performance may differ as a result of end-user environment and application. Note: Specifications subject to change without notice.

Catalog Number	
Notes	
Туре	

Unit Accessories



ORDERING INFORMATION Example: ELA IND RHB

ELA IND RHB

Series

ELA IND RHB Remote head brackets to use with surface-mounted j-boxes.

FEATURES & SPECIFICATIONS

INTENDED USE

Prepack provides template and hardware to field install third head on Indura unit equipment.

INSTALLATIO

Includes template and instructions to help with the drilling of holes for the third lamp on the small or large Indura housing.

CONSTRUCTION

Includes necessary hardware to field install third head. (Third head not included.) Tools needed: 9/64" (.140") dull bit; 1/2" (.500") dull bit Phillips screwdriver.

Actual performance may differ as a result of end-user environment and application. Note: Specifications subject to change without notice.

ELA IND R3
Indura' Third Head Mounting Kit

ORDERING INFORMATION Example: ELA IND R3

ELA IND R3

EMERGENCY

Series

ELA IND R3 Prepack kit to field install third head on Indura unit



ELA-IND-PM-CM-RHB-R3

Rev. 08/13/15

Unit Accessories

An **Acuity**Brands Company