Connected Room Hardware Job Aid

Please refer to the guide below for assistance identifying Connected Room hardware. As always, please reach out to **Connected Room Support**, available 24x7, should you need further assistance. First, run the "Check for Issues" option under settings, then please call **1-800-HELP-HELP**. On the telephone tree, **Select your PMS (Option 1 or 2), Option 5**, then **Option 4.**

EDGE CONTROLLERS

North American:

Connected Room Hardware Job Aid

International:

Connected Room Hardware Job Aid

REMOTE CONTROLS



Connected Room Hardware Job Aid

CABLING

Power Supplies (North American and Interntational):



Connected Room Hardware Job Aid

CABLING

HDMI:

Coax:

Connected Room Hardware Job Aid

CABLING

Ethernet:

MPI Cables (Cables vary, pending upon TV model) North America:

Connected Room Hardware Job Aid

CABLING

MPI Cables (Cables vary, pending upon TV model) North America, continued:



MPI Cables (Cables vary, pending upon TV model) International:

Connected Room Hardware Job Aid

CABLING

MPI Cables (Cables vary, pending upon TV model) International, continued:

SUPPORT VIDEOS

For assistance with Connecting the Edge Controller or troubleshooting, please review the video by scanning the QR code below: