Title	"Activate Personalisation" button acting as not responding		
System information			
OS	Android 10		
Testing App Version	TV_2_6_1		
Device	Android Smart TV		
Description	When personalisation is deactivated and the "activate personalisation" button on the most left is clicked, it does noting. It would be more intuitive to give some information to the user what is happening. Ex. "Please login and active personalisation to be able to switch on personalisation mode" as a message to the user		
Steps to reproduce the bug	 Go to settings and deactivate personalisation Just click the button multiple times 		
Expected Result	Some indication for unexperienced users that the app is working as intended		
Actual Result	No responce		
Proof			
Severity/Priority	Minot		
Impact [If known]			

Title	Enable to go back to initial menu from "Guest Mode" screan		
System information			
os	Android 10		
Testing App Version	TV_2_6_1		
Device	Android Smart TV		
Description	Once entered the "Guest mode" I was unable t go to the previous step so I could activate "Group viewing" I have to exit "Guest mode so I could go to the previous menu step.		
Steps to reproduce the bug	 Go to settings and select "Guest mode" Input any year and intensity Activate "Guest mode" Click back in the remote control so I can select "Group viewing" I'm landing directly in video 		
Expected Result	Able to go back on the previous menu step and select "Group mode"		
Actual Result	Going back directly to video/closing settings menu		
Proof	Look at attached video Screen Recording 2021-06-16 at 12.12.26		
Severity/Priority	Major		
Impact [If known]			

Title	"Sound personalization" and "Intensity" option in "Guest mode" Settings are inactive		
System information			
os	Android 10		
Testing App Version	TV_2_6_1		
Device	Android Smart TV		
Description	I click a little between different videos while paused, than tried to activate "Guest mode", which was not possible		
Steps to reproduce the bug	 Select a video Click play Click pause Select another video Click "Settings" Select "Guest mode" Cannot activate "Guest mode" 		
Expected Result	Activate personalisation and set up "Intensity"		
Actual Result	"Sound personalization" and "Intensity" options are inactive		
Proof	Hear every detail Mimi personalizes your TV audio to your unique hearing ability, for a richer and more immersive sound experience.	Year of birth Select to finish setup Sound personalization Inactive Intensity 70 % Exit guest mode	
Severity/Priority	Major		
Impact [if known]			