




SPK7858B ERGONOMIC WIRELESS MOUSE

INSTRUCTIONS FOR USE & FAQ

Quick Setup | Everyday Use | Answers



NEED HELP?

Use this document for quick setup, basic operation, compatibility answers, charging, care, and links to detailed support.

Customer Support: philips.us@top-support.net

Software Download (Scan): [PHILIPS U.S. Home & Office Mouse Support](#)



I. INSTRUCTIONS FOR USE

1. QUICK START - 3 STEPS

1	Turn the mouse ON	Slide the power switch on the bottom to ON.
2	Choose a connection	Use USB-A, Bluetooth, or USB-C according to your device.
3	Connect and start using	Follow the matching setup below. Default sensitivity is 1600 DPI.

2. Choose Your Connection

CONNECTION	BEST FOR	QUICK SETUP
USB-A	PC / Laptop (USB-A port)	Plug in the USB-A receiver (from bottom storage). Switch to Mode 1 via the bottom button.
Bluetooth	Any Bluetooth device (No USB)	Switch to Mode 2 via the bottom button. Hold >5 seconds to enter pairing, then choose "SPK7858" in settings.
USB-C	MacBook / iPad / USB-C Laptop	Plug in the USB-C receiver (from bottom storage). Switch to Mode 3 via the bottom button (factory paired).

3. Everyday Controls

CONTROL	ACTION	RESULT
DPI button	Press	Cycles 800 / 1600 / 2400 / 3200 / 4000 DPI
Vertical wheel	Scroll or click	Scrolls vertically; click function depends on the active application
Side wheel	Roll left or right	Horizontal scrolling in supported applications
Forward / Back	Press	Navigates in supported browsers and applications
Mode button	Short press / hold >5 sec in Mode 2	Switches mode / starts Bluetooth pairing
Indicator light	Status	Flashing red: Low battery Solid red: Charging Solid green: Fully charged

The indicator light turns red while charging and turns green when fully charged.

II. FAQ (FREQUENTLY ASKED QUESTIONS)

1	How do I connect the mouse for the first time?	1. Slide the power switch on the bottom of the mouse to "ON" to turn it on. 2. For USB-A or USB-C, insert the receiver and switch to the matching mode. For Bluetooth, switch to Mode 2, hold the button for more than 5 seconds, then pair "SPK7858".
2	Where are the USB receivers stored?	Open the bottom compartment of the mouse to find both USB-A and USB-C receivers.
3	Do I need KeyLink to use the mouse?	1. No. Basic mouse functions work without KeyLink. 2. KeyLink is only needed for supported customization features. 3. Go to the Philips SPK7858B Support page to download the current KeyLink software.
4	What should I do if the pointer is slow, laggy, or moves unevenly?	1. Restart your device or close unnecessary apps. 2. Clean the sensor and use the mouse on a clean matte surface. 3. Press the DPI button to increase pointer speed. 4. Charge the mouse if the battery is low.
5	Why can't I connect the mouse to my computer?	1. Make sure the mouse is turned on and charged. 2. Confirm the selected mode matches the receiver or Bluetooth connection. 3. If it still will not connect, try another available connection mode. NOTE: Basic mouse use supports compatible Windows, macOS, Android, iOS, and iPadOS devices. KeyLink requirements are listed in the Product User Guide.
6	Why does the mouse keep disconnecting after it connects?	1. Charge the mouse first. 2. Move it closer to the computer and away from wireless interference. 3. For Bluetooth, remove the existing SPK7858 pairing record and pair the mouse again if needed.



7	Why is the scroll wheel slow, jerky, or not scrolling smoothly?	1. This mouse does not support free-spin or infinite scrolling. 2. Use the scroll wheels in supported applications or interfaces. 3. Restart your computer or close unnecessary apps, then test again.
8	Why can't I customize the mouse buttons or use KeyLink features?	1. Connect the mouse through the supplied 2.4 GHz USB-A or USB-C receiver; Bluetooth is not supported for KeyLink customization. 2. Open KeyLink and select the appropriate profile. 3. Assign the supported functions you want to use.
9	Why doesn't the side wheel or horizontal scrolling work?	1. Open an app or page that supports horizontal scrolling, such as a spreadsheet. 2. Test the side wheel in that content. 3. If it still does not respond, contact Customer Support.
10	Can I connect multiple devices using Bluetooth only?	1. The mouse supports one Bluetooth channel only. 2. It cannot control two or more devices via Bluetooth at the same time. 3. To use the mouse with multiple devices, use the included 2.4 GHz USB receivers and switch between connection modes.
11	What should I do if the mouse will not charge or the battery drains unusually fast?	1. Connect the charging cable to a standard 5 V USB power source. 2. Charge the mouse, then test it again. 3. If it still will not charge or battery life remains unusually short after charging, contact Customer Support.
12	Why does the scroll direction feel reversed on my Mac?	macOS may use a different scrolling direction from Windows. 1. On your Mac, open System Settings > Mouse. 2. Change the "Natural scrolling" setting to your preference.
13	What should I do if a mouse button does not respond or click correctly?	1. Test the button in a standard browser or file window. 2. Reconnect the mouse and restart the computer. 3. If the same problem occurs in multiple apps or on another compatible device, contact Customer Support.

Quick Problem Guide

PROBLEM	TRY THIS FIRST
No response	Check power and battery, then confirm the selected connection mode.
USB receiver not detected	Reinsert the matching receiver and try another compatible USB port.
Bluetooth device not found	Remove any old SPK7858 pairing record, hold the mode button for >5 seconds, then search again.
Pointer jumps or lags	Charge the mouse, reduce wireless distance, and try a clean matte surface.
Side wheel does not work	Test it in an application that supports horizontal scrolling.
KeyLink does not detect the mouse	Use a supplied 2.4 GHz receiver; confirm system requirements; restart KeyLink; update the application.

Care & Safety: Keep the mouse dry. Do not disassemble, crush, burn, immerse, or expose it to excessive heat. Stop use if it is damaged, unusually hot, swollen, wet, or emits an odor.

MORE HELP

For detailed specifications and full operating steps, see the Product User Guide. For symptom-based repair steps, see the Troubleshooting Guide. For coverage and remedies, see the Limited Warranty.

Customer Support

Email	philips.us@top-support.net
Prepare	Model, Amazon order number, serial number, host device, operating system, connection mode, issue description, and steps already tried
Support Hours	Mon–Fri, 6:30 PM–9:30 PM and 11:00 PM–4:00 AM (PT)
More Help	Product User Guide / Troubleshooting Guide / Limited Warranty

Document Information

Document Number	SPK7858B-IFU-FAQ-US-EN
Version	1.0
Effective Date	August 21, 2026