GPRS 通讯协议

2015-09-18

1. GPRS 包格式

2. 命令码

命令码占用5字节节,ASCII码格式

命令码	功能	方向	备注
CTRL:	上报数据	模块->上位机	

3. 包长

包长占一个字节,二进制格式,值为'数据(nB)'部分的长度,如:数据部长度为 10 个字节,包长值为 0x0A.

4. 设备编号

设备编号 15 字节, ASCII 码格式, 例如 GPRS 模块号为:201506123456789,上报数据时为可见字符 ASCII 码 201506123456789.

5. 数据

上报数据格式为符合国标 CJ-188 协议格式

索引	长度	内容	功能	
0	1	0x68	包头	
1	1	0x10	水表类型标识(CJ-188 协议)	
2~5	4	0x78563412	水表编号(BCD 码),如表号 12345678	
35~37	3		累计流量(BCD 码),最大值 999999 吨	
60~62	3		表底(二进制)	
63	1		脉冲系数,即多少个脉冲折算为一吨水	
64	1		功能选择,抄水表时恒为0	
65~71	7		模块时钟: 秒,分,时,星期,日,月,年,各	
			占一字节(BCD 码)	
72~74	3		累计脉冲数 (二进制)	
75~77	3		累计流量(二进制)	
78	1		电池电压,模块放大10倍,上位机需除10	
79~81	3		上传时间或上传周期,格式:时,分,秒各占一	
			字节(BCD 码)	
			如:上传时间为 1:2:3 时为: 0x01,0x02,0x03	
			上传周期为 2 小时时为:0x02,0x00,0x00	
82	1		校验和,从0~82 所有字节求和取低 8 位	
83	1	0x16	包尾,固定值 0x16	

6. GPRS 上报水表数据参考代码, C语言

```
void SendWaterData(void)
   unsigned char i,pbuf[84];
   unsigned short sum;
   unsigned long water;
   water = hextobcdlong(g_watertotal);
   memset(pbuf,0,sizeof(pbuf));
   pbuf[0]= 0x68; //包头
  pbuf[1]= 0x10; //表类型-水表
  // 水表 ID 号 ,集中器号的后 8 位数字
  pbuf[2] = (g\_code[13]-0x30) * 16 + (g\_code[14]-0x30);
   pbuf[3] = (g code[11]-0x30) * 16 + (g code[12]-0x30);
   pbuf[4] = (g\_code[9]-0x30) * 16 + (g\_code[10]-0x30);
   pbuf[5] = (g\_code[7]-0x30) * 16 + (g\_code[8]-0x30);
   //累计流量
 pbuf[35] = (unsigned char)(water &0xff);
   pbuf[36] = (unsigned char) (water >> 8);
    pbuf[37] = (unsigned char)(water >> 16);
    pbuf[40] = 0x25;//进水温度-无用
    pbuf[43] = 0x25 ://回水温度-无用
   //水表表底
   pbuf[60] = (unsigned char)(g_waterbase >> 16);
   pbuf[61] = (unsigned char) (g_waterbase >> 8);
 pbuf[62] = (unsigned char)(g_waterbase &0xff);
   //脉冲系数
pbuf[63] = g_waterscale;
   //模块功能 0-抄水表 1- 抄热表
pbuf[64] = g_fun;
    get_time(g_time); //模块当前时间
 memcpy(&pbuf[65],g_time,7);
   //累计脉冲数
   pbuf[72] = (unsigned char)(g_watercount >> 16);
 pbuf[73] = (unsigned char) (g_watercount >> 8);
   pbuf[74] = (unsigned char)(g_watercount &0xff);
    //累计流量
   pbuf[75] = (unsigned char)(g_watertotal >> 16);
   pbuf[76] = (unsigned char) (g_watertotal >> 8);
 pbuf[77] = (unsigned char)(g_watertotal &0xff);
    g_vol = ad_vcc(); //电池电压, 放大 10 倍, 上位机需除以 10 得到实际电压
    pbuf[78] = (unsigned char) (g_vol);
```

```
//上传时间或上传周期
    memcpy(&pbuf[79],g_uploadtime,3);
    //求校验和
    sum=0;
    for (i=0;i<82;i++)
      sum += pbuf[i];
    pbuf[82] = (unsigned char)(sum \&0xff);
    pbuf[83] = 0x16; //包尾
    //打包头
    m_sendBuff[0] = 'C';
    m_sendBuff[1] = 'T';
    m_sendBuff[2] = 'R';
    m_sendBuff[3] = 'L';
    m_sendBuff[4] = ':';
    m_sendBuff[5] = sizeof(pbuf); //数据长度
    memcpy(&m_sendBuff[6],g_code,15); //设备编号
    memcpy(&m_sendBuff[21],pbuf,sizeof(pbuf)); //复制数据
    gprs_send(m_sendBuff,sizeof(pbuf)+21); //GPRS 发送
}
```