

HANDOUT #2

Library - TM1637.py



There should be a space in between these quotation marks!!

DO THIS IN THE SHELL >>> AREA




HANDOUT #2 (cont'd)

import tm1637 display = tm1637.TM1637(20, 16) display.clear() S1=' ' S2=' ' S3='8' S4='7'

display.set values([S1, S2, S3, S4])





DO THIS IN THE EDITOR, SAVE THE CODE AND RUN THEM

countdown.py (count from 9 to 1)

import tm1637 from time import sleep display = tm1637.TM1637(20, 16) S1=' ' S2=' ' S3=' '

S4='9' display.clear()

display.set_values([S1,S2,S3,S4])

sleep(1) S4='8'

display.set_values([S1,S2,S3,S4])

sleep(1) S4='7'

display.set_values([S1,S2,S3,S4])

countdown2.py (count from 9 to 0, and 0 to 9 using for loop)

import tm1637

from time import sleep

display = tm1637.TM1637(20, 16)

input('Hit Enter to Count Down')

display.clear()

S1=' '

S2=' '

S3=' '

S4=' '

for count in range(9,-1,-1):

S4=str(count)

display.set_values([S1,S2,S3,S4])

sleep(1)

input('Hit Enter to Count Up')

display.clear()

for count in range(0,10,1):

S4=str(count)

display.set_values([S1,S2,S3,S4])

sleep(1)