Manual

Car License Plate Identification with a Jetson Nano J1010

Author:	Mansour Ahmady Phoulady
Matriculation No.:	7025671
Author:	Hemanth Prabhakaran
Matriculation No.:	7026000
Author:	Ranjeetsing Tawar
Matriculation No.:	7026116
Course of Studies:	Business Intelligence and Data Analytics

First examiner:	Prof. Dr. Elmar Wings
Submission date:	October 28, 2024

University of Applied Sciences Emden/Leer · Faculty of Technology · Mechanical Engineering Department
Constantiaplatz 4 · 26723 Emden · http://www.hs-emden-leer.de

Contents

List of figures i

List of tables ii

Acronyms 1

1 Introduction 2

2 Hardware Overview 3
- 2.1 System Requirements . . . 3

3 Sketch of the GUI, Hardware Ports and Connectors 4

4 System Configuration 5
- 4.1 Configuring the Camera . . . 5
- 4.2 Loading the License Plate Detection Model . . . 5
- 4.3 System Test . . . 6

5 System Operation 7
- 5.1 Starting the System . . . 7
- 5.2 Running the Detection Script . . . 7
- 5.3 Shutting Down the System . . . 7
- 5.4 Safety Notes . . . 7

6 Troubleshooting 8
- 6.1 System Not Powering On . . . 8
- 6.2 Camera Not Detected . . . 8
- 6.3 LED Indicator Not Activating . . . 8
- 6.4 Model Failing to Detect License Plates . . . 8
- 6.5 Low Detection Accuracy . . . 9

7 Maintenance 10
- 7.1 Hardware Maintenance . . . 10
- 7.2 Software Maintenance . . . 10
- 7.3 Model Maintenance . . . 10

8 Performance Optimization 11
- 8.1 Hardware Optimization . . . 11
- 8.2 Software Optimization . . . 11

8.3 Efficient Data Processing 11
8.4 Memory and Storage Management 12

9 Frequently Asked Questions (FAQ) 13
9.1 General Questions 13
9.2 Setup and Configuration 13
9.3 Performance and Operation 13
9.4 Maintenance and Troubleshooting 14

Bibliography 14

List of Figures

3.1 Sketch of Jetson Nano Ports and Connectors 4

List of Tables

Acronyms

1 Introduction

Welcome to the Vehicle License Plate Detection System Manual. This manual provides a comprehensive guide for setting up, configuring, and operating a real-time vehicle license plate identification system, designed specifically for use with the NVIDIA Jetson Nano J1010. Built on the powerful Jetson Nano platform, this system utilizes advanced AI capabilities to capture, detect, and display license plate information with impressive accuracy and speed.

This manual will walk you through every step, from installation and configuration to effective use and troubleshooting, helping you achieve optimal performance with your Jetson Nano-based plate detection system. Whether you're aiming for integration with larger projects or simply seeking to experiment with computer vision on embedded platforms, this guide will serve as your go-to resource.

2 Hardware Overview

2.1 System Requirements

To ensure smooth operation of the Vehicle License Plate Detection System, please confirm that you have all necessary hardware and software components listed below.

Hardware Requirements

- NVIDIA Jetson Nano J1010
- Camera compatible with Jetson Nano
- LED indicator (optional but recommended)
- 5V/3A Type-C power adapter
- MicroSD card (32GB or larger, pre-flashed with JetPack SDK)
- USB Keyboard and mouse
- Display screen with HDMI support

Software Requirements

- JetPack SDK (latest version recommended)
- Vehicle license plate dataset (e.g. from Kaggle)
- Python 3 environment with required libraries:
    - TensorFlow or PyTorch (for deep learning model inference)
    - OpenCV (for image processing)
    - GPIO libraries (for controlling the LED indicator)

3 Sketch of the GUI, Hardware Ports and Connectors



Figure 3.1: Sketch of Jetson Nano Ports and Connectors

4 System Configuration

This chapter provides instructions for configuring the software and hardware settings on your Jetson Nano J1010 to ensure the Vehicle License Plate Detection System operates smoothly.

4.1 Configuring the Camera

To enable real-time license plate detection, configure the connected camera as follows:

1. **Verify Camera Connection:** Ensure the camera is securely connected to the Jetson Nano via the designated camera port.

2. **Install Camera Drivers:** If necessary, install drivers for the camera using the command:

   ```
   sudo apt-get install v4l-utils
   ```

3. **Test Camera Functionality:** Use the following command to verify that the camera is functioning:

   ```
   gst-launch-1.0 nvarguscamerasrc ! nvoverlaysink
   ```

4.2 Loading the License Plate Detection Model

Load and configure the pre-trained license plate detection model on the Jetson Nano:

1. **Model Download:** Ensure the trained model file (e.g., ‘.h5‘ or ‘.pt‘) is in the project directory.

2. **Load Model in Python:** Use TensorFlow or PyTorch to load the model. For TensorFlow:

   ```
   import tensorflow as tf
   model = tf.keras.models.load_model('path_to_model.h5')
   ```

   For PyTorch:

```
import torch
model = torch.load('path_to_model.pt')
model.eval()
```

3. **Configure Model Input**: Ensure the model's input dimensions match those of the camera feed. Resize images if necessary before passing them to the model.

4.3 System Test

Run a basic test to confirm that the system is correctly configured:

1. **Camera Feed Verification:** Verify that the camera feed displays properly and that images can be processed.
2. **Model Inference Test:** Run a sample inference on a test image to ensure the model detects the license plate correctly.
3. **LED Indicator Test:** Confirm that the LED lights up when a license plate is detected.

After completing these configuration steps, your system should be fully operational. In the next chapter, we will cover operational instructions for using the system.

5 System Operation

This chapter outlines how to start, run, and safely shut down the Vehicle License Plate Detection System.

5.1 Starting the System

1. **Power On:** Connect the power adapter to the Jetson Nano and allow it to boot.
2. **Navigate to Project Directory:** Open a terminal and navigate to the project folder.
3. **Activate Environment:** If using a virtual environment, activate it (e.g., `source venv/bin/activate`).

5.2 Running the Detection Script

1. **Start Script:** Run the main detection script (e.g., `python3 detect_plates.py`).
2. **View Output:** The system will process the camera feed, displaying detected license plates and activating the LED indicator if configured.

5.3 Shutting Down the System

1. **Stop Script:** Use `Ctrl + C` to terminate the script.
2. **Power Off:** Shut down the Jetson Nano with `sudo shutdown now`.

5.4 Safety Notes

Ensure stable setup, avoid extreme conditions, and check cable connections periodically.

This completes the basic operational steps. For troubleshooting guidance, refer to the next chapter.

6 Troubleshooting

This chapter provides solutions for common issues that may arise while using the Vehicle License Plate Detection System with the Jetson Nano.

6.1 System Not Powering On

- **Check Power Connection:** Ensure the power adapter is securely connected to the Jetson Nano and that the power supply is functional.
- **Confirm Power Specifications:** Verify that you are using a 12V/2A adapter, as inadequate power may prevent startup.

6.2 Camera Not Detected

- **Verify Camera Connection:** Confirm the camera is properly connected to the designated port on the Jetson Nano.
- **Install Required Drivers:** Ensure camera drivers are installed. Run `sudo apt-get install v4l-utils` if necessary.

6.3 LED Indicator Not Activating

- **Check GPIO Setup:** Confirm that the LED is connected to the correct GPIO pin and that the pin setup in your code matches the physical connection.
- **Test GPIO Output:** Run a simple GPIO test script to verify that the pin outputs correctly.

6.4 Model Failing to Detect License Plates

- **Verify Model Path:** Ensure the detection model file is correctly loaded in your script and that the path is accurate.
- **Check Input Dimensions:** Ensure the input image dimensions are compatible with the model's requirements. Adjust the camera feed size if necessary.

6.5 Low Detection Accuracy

- **Lighting Conditions:** Ensure adequate lighting for the camera feed, as poor lighting can affect detection.
- **Adjust Model Settings:** Fine-tune model parameters or consider retraining the model with additional data for improved accuracy.

For issues beyond these troubleshooting steps, consult the Jetson Nano documentation or support forums for additional assistance.

7 Maintenance

Regular maintenance helps ensure the Vehicle License Plate Detection System continues to perform effectively. This chapter outlines essential maintenance tasks.

7.1 Hardware Maintenance

- **Inspect Connections:** Periodically check all connections (power, camera, LED, and GPIO) to ensure they are secure and free of dust or debris.
- **Clean Components:** Gently clean the Jetson Nano, camera, and other components with compressed air or a soft cloth to prevent dust buildup, especially around ventilation areas.
- **Check for Wear and Tear:** Regularly examine cables, connectors, and the LED indicator for any signs of wear, replacing items as needed to prevent malfunctions.

7.2 Software Maintenance

- **Update Software:** Periodically update the JetPack SDK, Python packages, and dependencies to benefit from security patches and performance improvements.
- **Recalibrate Camera (if applicable):** If detection accuracy declines, recalibrate the camera settings to ensure it maintains proper focus and lighting adjustments.

7.3 Model Maintenance

- **Retrain Model (Optional):** As new license plate styles or formats are introduced, consider retraining the model with updated datasets to maintain high accuracy.
- **Clear Log Files:** Regularly clear log files generated by the system to free up storage and avoid slowdowns.

Consistent maintenance helps prolong the life of your system and ensures reliable performance for license plate detection.

8 Performance Optimization

Optimizing the Vehicle License Plate Detection System can improve detection speed, reduce power consumption, and ensure smooth operation in real-time applications. This chapter provides key techniques to enhance system performance on the Jetson Nano J1010.

8.1 Hardware Optimization

- **Use High-Performance Power Mode:** Switch to the maximum performance mode to allocate more resources to the detection process. Run:

  ```
  sudo nvpmodel -m 0
  ```

- **Add Cooling Solutions:** Overheating can reduce performance. Attach a fan or heatsink to prevent thermal throttling during long operating hours.

8.2 Software Optimization

- **Use TensorRT for Model Acceleration:** Convert the detection model to TensorRT, NVIDIA's inference optimization engine, to speed up model processing:

  ```
  sudo apt-get install python3-pycuda
  ```

  Then convert the model in Python:

  ```
  import tensorrt as trt
  # Model conversion code here
  ```

- **Reduce Model Complexity (Optional):** Use a lighter model architecture or reduce input dimensions for faster processing, especially if accuracy loss is acceptable.

8.3 Efficient Data Processing

- **Resize Input Images:** Reducing image resolution can improve processing speed. Test different resolutions to find the balance between speed and accuracy.

- **Lower Detection Frequency:** For scenarios where real-time updates are not critical, reduce the frame processing rate to save resources.

8.4 Memory and Storage Management

- **Clear Unused Cache:** Periodically clear memory cache to avoid slowdowns due to memory saturation:

  ```
  sudo sync && sudo sysctl -w vm.drop_caches=3
  ```

- **Free Up Storage:** Regularly remove unnecessary data and logs to maintain adequate storage, ensuring the system operates smoothly.

By applying these performance optimization techniques, you can achieve faster processing and maintain the stability of the Vehicle License Plate Detection System.

9 Frequently Asked Questions (FAQ)

This chapter addresses common questions about the Vehicle License Plate Detection System, offering quick answers and solutions.

9.1 General Questions

- **Q: What camera models are compatible with the Jetson Nano J1010?** A: The system generally supports CSI cameras compatible with the Jetson Nano, as well as USB cameras. Check the NVIDIA documentation for a full list of compatible models.
- **Q: Can I use the system with a Wi-Fi connection?** A: Yes, the system can connect to Wi-Fi using a compatible USB Wi-Fi adapter, enabling remote operation and updates.

9.2 Setup and Configuration

- **Q: Why is my camera not detected by the system?** A: Ensure the camera is securely connected to the Jetson Nano, and verify that the necessary drivers are installed. Restart the system if needed.
- **Q: How can I adjust the detection accuracy of the model?** A: Improve accuracy by training the model with a larger dataset or adjusting camera settings to ensure clear images.

9.3 Performance and Operation

- **Q: Why is the detection system running slower than expected?** A: Slow performance can result from insufficient power or high ambient temperatures. Ensure adequate cooling and try using the maximum performance mode on the Jetson Nano.
- **Q: How do I reduce false detections?** A: False detections can be minimized by fine-tuning model thresholds, improving lighting conditions, and using a more refined training dataset.

9.4 Maintenance and Troubleshooting

- **Q: How often should I update the software?** A: Regular updates are recommended, especially for JetPack SDK and Python packages, to benefit from new features and fixes.
- **Q: What should I do if the system stops responding?** A: Restart the Jetson Nano by powering it off and on. If the issue persists, check all connections and power sources.

For further assistance, consult the official NVIDIA Jetson documentation or reach out to support forums for more specific guidance.