
Internet Protocol (IP) "The" Network Layer

EE450: Introduction to Computer Networks

Professor A. Zahid

Network Layer


- On sending side, it encapsulates
 TCP Segments (or UDP
 Datagrams) into Packets
- On receiving side, it delivers TCP Segments (or UDP Datagrams) to corresponding Transport layer
- Network layer protocols are implemented in every host and router across the Network
- Router examines header fields in all IP packets passing through it and forward according to routing tables




Packet Switched Network (Review)

no establish

- No call setup at Network layer
- router cannot remember the same Source/Destination address
- Routers: no state about end-to-end connections
 - Packets may arrive out-of-order
- Packets forwarded using destination IP address



Routing vs. Forwarding




32位—

(aggregate table entries)


Router Architecture (EE555)

two key router functions:


- Run Routing algorithms/protocols (RIP, OSPF, BGP)
- forwarding packets from incoming to outgoing link




Network Layer at Source/Router/Destination



a. Network layer at source




b. Network layer at destination



c. Network layer at a router


The IP Protocol



The Internet Protocol


- IP is a connection-less, unreliable network layer protocol designed to be used in a connection-less packet switched network such as the Internet.
- IP provides best effort services in the sense
 - There is no guarantee of delivery of error-free packets
 - There is no guarantee of ordered delivery of packets
 - There is no guarantee of delivery of packets, i.e. some packets may be lost, some packets may be duplicated
- IP relies on upper layer transport protocols (TCP) to take care of these problems

IP Packet Format 不用记



The Protocol Field


- The protocol field (8-bits) defines the protocol that is using the services of IP. It defines the final destination protocol the packet should be delivered to. This is important since several protocols could be multiplexed over IP
 - ICMP: 1, IGMP: 2, TCP: 6, EGP: 8, UDP: 17, IPv6: 41, OSPF: 89, etc...



Fragmentation

- IP packet may travel over different networks (LANs and WANs)
- A router de-capsulate an IP packet from the frame it receives, process it, and encapsulate it in another frame
- Frame size and format varies depend on the data link protocol used by the physical network through which the frame is traveling
- MTU (Maximum Transmission Unit) is the maximum size of the data field (payload) in the frame
- If Packet size > MTU, Need for Fragmentation

MTU: Maximum Transfer Unit



F	ra	m	ıe
---	----	---	----

Protocol	MTU (Octets)
Ethernet	1500
Token Ring (4 Mbps)	4464
Token Ring (16 Mbps)	17914
FDDI	4352
X.25	576
PPP	296

the payload of each fragment (in bytes) must be a mulltiple of 8 (except for the last fragement)

Fragmentation (Continued)

- Each fragment has its own header (most of fields are copied, some will change, including the total length, the Flags and the fragmentation offset fields)
- A fragmented datagram may itself be fragmented if it encounters a network with smaller MTU
- A packet can be fragmented by a source host or by any router in the path. Re-assembly of the packet must be done at the destination host because those fragments become independent packets and may travel different routes

Fragmentation and Reassembly

Network links have MTU
 (max.transfer size) largest possible link-level
 frame.


 Different link types, Different MTUs

large IP datagram
 "fragmented" within net

 One packet becomes several packets (fragments)

"Reassembled" only at final destination

 IP header bits used to identify, order related fragments



Fields related to Fragmentation

用于让receiver判断一个packet是不是在一起

 Identification (16 bits): All fragments of a packet has the same ID number which is the same as that of the original packet. The R/x knows that all fragments having the same ID should be assembled into one packet

如果D标志但是下一个router无法送这么大的packet, router会丢掉, 然后发送ICMP


Flags (3 bits):



D: Do not Fragment M: More Fragment

• Fragmentation Offset (13 bits): Relative position of the fragment to the whole packet measured in whole packet measure

Fragmentation Example (cont.)



IP v4. Addressing

- The Internet is made of combination of LANs and WANs connected via routers
- A host needs to be able to communicate with another host without worrying about which physical network must be passed through
- Hosts must therefore be identified uniquely and globally at the network layer
- For efficient and optimum routing, routers must also be identified uniquely and globally at the network layer

IP v4. Addressing (Cont.)


- IPv4 address is a 32-bit address, implemented in software, is used to uniquely and globally identify a host or a router on the Internet
- A device can have more than one IP address if
 it is connected to more than one network
 (multi-homed)

 identify network of host you attached, globle
 unique assigned by ICANN
- An IP address have two parts, the netid and assigned by local adminitor the hostid. They have variable lengths depending on the class of the address
 - All devices on the same network have the same netid

IP Addresses (Example)


A: wired Ethernet interfaces connected by Ethernet switches

- IP address: 32-bit identifier for host, router interface
- Interface: connection between host/router and physical link
 - router's typically have multiple interfaces
 - host typically has one or two interfaces (e.g., wired Ethernet, wireless 802.11)
- IP addresses associated with each interface



B: wireless WiFi interfaces connected by WiFi base station

Classful IP Addressing



First Second Third Fourth byte byte byte byte 0和127期 0 - 127Class A 保留的 128-191 Class B 192–223 Class C 224-239 Class D Class E 240-255

a. Binary notation

b. Dotted-decimal notation

Number of Blocks/Size of Blocks in Classful IP Addressing

Class	Number of Blocks	Block Size	Application
A	128	16,777,216	Unicast
В	16,384	65,536	Unicast
С	2,097,152	256	Unicast
D	1	268,435,456	Multicast
Е	1	268,435,456	Reserved

In classful addressing, a large part of the available addresses are wasted. It is hence being replaced by "Classless IP Addressing"

USC NETWORK: 128.125.

Special IP Addresses

<u>Special Address</u>	<u>Netid</u>	<u>Hostid</u>	Source/Destination
network itself Network Address	75.0.0.0—>75.3. Specific	.1.128 All 0's	None
 Direct Broadcast 	Specific	All 1's	你知道network add 的时候广播 Destination
Address when you know the	ne address of netwo	rk,75.255.255.255	
 Limited Broadcast 	All 1's	<i>All 1's</i>	$Destination^{-rac{14}{18}}$
Address ^{255.255.255.255}	broadcast on this r	network	
This host on this	All 0's	All 0's	$Source egin{array}{c} { t KDHCPh} \\ { t Fightarrow} \end{array}$
<i>network</i> 0.0.0.0			
Specific host on	All 0's	Specific	Destination
this network 75.3.1.12	8->0.3.1.128host-i	d	
Loopback address	<i>127</i>	Any	Destination
use to test protocol in your machine, 常用: 127.0.0.1	do not leave your	machine, not leave y	your NIC

Private IP Addressing

- One of the problems in IP network address allocation is that many hosts do not require access to hosts in other networks

 Assigning Globally unique public IP addresses for such hosts may be wasteful
- IETF proposed the use of Private IP addresses that are <u>not</u> advertised outside the private network.


	netid	Rang	ge net broadcast	Total		在同一个网络里private ip是unique 的,在不同网络可以相同
	10.0.0.0	to	10.255.255.255			^{1 network} Private IP Addresses
3	172.16.0.0	to	172.31.255.255	2^{20}	16个	are non-routable network,2 ⁻ 16个host
2	192.168.0.0	to	192.168.255.255	2^{16}	2-8	个network,2 ⁻ 8个host

В


NAT: Network Address Translation

- NAT is a protocol that maintains a translation table for mapping an internal private IP address to a globally unique IP addresses and vice versa
- May be static (one-to-one) or dynamic (from a pool of global IP addresses)
- Implemented in the border (access) router separating the private network and the public Internet or as a stand-alone multi-homed Server
- NAT is a special type of Proxy Server. It was introduced with Windows 2000

NAT Implementation



NAT Address Translation



NAT & PAT NAT only只看IP header,不看payload N&P: 会看payload的port number

NAT translation table 1: host 10.0.0.1 2: NAT router WAN side addr LAN side addr sends datagram to changes packet 138.76.29.7, 5001 10.0.0.1, 3345 128.119.40.186, 80 source addr from 加一个port number (choosen 10.0.0.1, 3345 to randomly by) 138.76.29.7, 5001, 5: 10.0.0.1, 3345 updates table D: 128.119.40.186, 80 10.0.0.1 5: 138.76.29.7, 5001 D: 128.119.40.186, 80 10.0.0.4 10.0.0.2 138.76.29.7 5: 128.119.40.186.80 4 5: 128.119.40.186.80 D: 10.0.0.1, 3345 10.0.0.3 D: 138.76.29.7, 5001 3 4: NAT router changes datagram 3: Reply arrives dest addr from dest. address: 138.76.29.7, 5001 to 10.0.0.1, 3345 138.76.29.7, 5001 EE450, USC, Zahid 27

Motivation for NAT

- Local network uses just one IP address as far as outside world is concerned:
- Range of addresses not needed from ISP: just one
 IP address for all devices
- can change addresses of devices in local network without notifying outside world
- can change ISP without changing addresses of devices in local network
- devices inside local net not explicitly addressable or visible by outside world (a security plus)

USC network: 128.125.0.0 (B)

Subnetting

dividing a network into smaller size network callled subnet

• Subnetting is the process of creating multiple segments within a single IP network address a subnet is a network (just smaller size),

Space 两个subnet需要一个router

subnetting is transparent to the rest of the world 从外思


subnet会被作

- From the perspective of a node outside the head network, all nodes on any of the subnetworks appear to be on the original single network
- Internet routing tables are not affected by subnetting, I.e. routing tables need not be overloaded with information about routes to all internal subnets, just information to the access router/gateway in the routing table: we see the following:


Subnetting (Continued)

- Classes A, B and C in IP addressing are designed with two levels of hierarchy (netid & hostid)
- Problem: An organization with a class B address can not have more than network and all 2^{16} hosts are attached to that network \Rightarrow A nightmare in managing this network, single broadcast domain, security issues, etc...
- Subnetting create another level of hierarchy (netid, subnetid and hostid). Delivery of IP packets involves three steps; <u>delivery to the site router</u>, <u>delivery to the subnet router</u>, <u>delivery to the host</u>

Example of Subnetting



Example of Subnetting (How many?)



all devices in the same subnet must have same subnet mask; devices on different subnet may have same subnet mask;

if no subnet: A(255.0.0.0) B(255.255.0.0)

Subnet Masking


- Subnetting is achieved by "stealing" some bits from the hostid field to represent the subnet portion of the address
- Those bits that are used for the subnetid are identified through the use of a subnet mask
- Masking is the process of extracting the address of the physical network (if subnetting is not used) or the subnet address (if subnetting is used) from an IP address Subnet mask相同不一定在同一个subnet
- A subnet mask is a 32-bit pattern having a "1" in every netid and subnetid locations and a "0" in every hostid location_{EE450, USC, Zahid} USC example subnet mask:255.255.224.0

Subnet Masking (Continued)

- Subnet masking is performed (both at the host and at the router) by applying "bit-wise-AND" operation between the IP address and the subnet mask 最后结果: subnet address
- Example 1: Class B network without subnetting
 - 141.14.2.21
- 10001101.00001110.00000010.00010101
- 255.255.0.0
- 11111111111111111.00000000.00000000
- "Bit-wise and" 10001101.00001110.00000000.00000000



Example of Subnetting



Subnet Router Routing Table

Partial Table in Router 128,96,33,1

Subnet Number	Subnet Mask	Next Hop	
128.96.34.0	255.255.255.128	Left Router	IP address of R1
128.96.34.128	255.255.255.128	Left Interface	
128.96.33.0	255.255.255.0	Right Interface	

for each table entry do

if (DestAddr & Subnet Mask) = SubnetNumber

if NextHop is an Interface

deliver packet directly to DestAddr

else

deliver packet to Router

smaller block can be aggregated in to bigger blocks (sometime know as supernetting Cassess IP Addressing

- To overcome IP Address depletion and allow more organizations ability to access the Internet #bits of host: 32-n
- Get rid of classes and assign addresses in "Blocks". The size of the block (The # of IP addresses in the block) depends on the organization demand power of 2: 2°(32-n) (18 is larger than /22)
- There are some restrictions on these blocks

Restrictions of Address Blocks

- The number of addresses in a block must be a power of 2 (1, 2, 4, 8, etc...)
- The addresses in the block are contiguous, i.e. one after the other paper of the other paper.
- The first address in the block (in decimal) must be divisible by the size of the block

CIDR Notation

CIDR: Classless Inter Domain Routing

- Network and Subnet portions of address of arbitrary length
- address format: a.b.c.d/x, where x is # bits in network and subnet portion of address known as network prefix

200.23.16.0/23

total: 512 addresses (256x2)



/n == masksubnet mask: /23 or

255.255.254.0

Subnet part


block:

32-23

EE450, USC, Zahid

Host part

Example: A block of Size 16



In IPv4 addressing, a block of addresses can be defined as w.x.y.z /n in which w.x.y.z defines one of the addresses and the /n defines the mask. The number of address in the block is 2³²⁻ⁿ

The <u>first address</u> in the block can be found by setting the rightmost 32 - n bits to 0s. Hence the first address in the block represents the Network/Subnet address of the organization

The <u>last address</u> in the block can be found by setting the rightmost 32 - n bits to 1s. Hence the last address in the block represents the broadcast address in the organization network


Example of Classless IP Addressing

• An ISP gets a block of IP addresses. The Block is 200.23.16.0/20. The size of the block is 2^{12} = 4096. The ISP has 8 customers (organizations), each requiring a "block" of size 512

ISP's block	<u>11001000</u>	00010111	00010000	00000000	200.23.16.0/20
Organization 0	<u>11001000</u>	00010111	<u>0001000</u> 0	00000000	200.23.16.0/23
Organization 1	<u>11001000</u>	00010111	<u>0001001</u> 0	00000000	200.23.18.0/23
Organization 2	<u>11001000</u>	00010111	<u>0001010</u> 0	00000000	200.23.20.0/23
Organization 7	<u>11001000</u>	00010111	<u>0001111</u> 0	00000000	200.23.30.0/23

Example of Classless IP Addressing

• Organization was assigned a block 17.12.40.0/26 classles (Size of block is 64). Organization has three addressable devices: 30, 14, 14 departments. Three subnets of sizes 32, 16 and 16



Hierarchical Addressing

Hierarchical addressing allows efficient advertisement of routing information

