

Transfer Cases

Like New - Only Better

Assembly Numbers Matter



New Process Assembly Tag

Chrysler numbers may have 2 letters at the end of the 8-digit number.



Late Model GM/Chrysler Assembly Tag GM/Chrysler use 8-digit assembly numbers

000000

0000-000 O

BorgWarner Assembly Tag

Ford assembly numbers are a 4 letter-digit combination followed by a dash and 2 letters.

The ETE Difference

Thoroughly inspected case halves for cracks, stripped threads, and wear.

Carefully inspected internal parts, including chain stretch and main shaft.

Fully remanufactured to OE quality or better with new seals and certified spec bearings.

Completely tested for performance, including torque testing of viscous clutches.

Processed as individual units from teardown to testing.

Available for foreign and domestic applications.

Shift motors included with select units.

Covered by ETE REMAN's hassle-free warranty.



3 Year/Unlimited Mileage
Hassle-Free
Nationwide
Parts and Labor Warranty