

PDM30		
MoTeC Superseal A (34-pin) — MoTeC #65044	female	34-pin
OUT15	1	
2		
3		
4		
5		
6		
7		
8		
9		
10		
11		
12		
13		
14		
15		
16		
17		
18		
19		
20		
21		
22		
23		
24		
25		
26		
27		
28		
29		
30		
31		
32		
33		
34		

W97		
1x	20 AWG	18.4 m
PDM30:1:OUT15 1:BUWH Rear_Backup_Camera:1:+12V		
#97 Rear Backup Camera (BLU/WHT)		

Rear_Backup_Camera	
Camera connector (PN TBD) 4-pin	
1	+12V
2	GND
3	VID+
4	VID-

Ignition_Coil_3	
D510C — WPCOL40 / GM 12162000 (4-pin) 4-pin	
1	+12V
2	GND
3	SIG
4	GND2
Pigtail WPCOL40	

Ignition_Coil_5	
D510C — WPCOL40 / GM 12162000 (4-pin) 4-pin	
1	+12V
2	GND
3	SIG
4	GND2
Pigtail WPCOL40	

Ignition_Coil_7	
D510C — WPCOL40 / GM 12162000 (4-pin) 4-pin	
1	+12V
2	GND
3	SIG
4	GND2
Pigtail WPCOL40	

Ignition_Coil_2	
D510C — WPCOL40 / GM 12162000 (4-pin) 4-pin	
1	+12V
2	GND
3	SIG
4	GND2
Pigtail WPCOL40	

Ignition_Coil_4	
D510C — WPCOL40 / GM 12162000 (4-pin) 4-pin	
1	+12V
2	GND
3	SIG
4	GND2
Pigtail WPCOL40	

Ignition_Coil_6	
D510C — WPCOL40 / GM 12162000 (4-pin) 4-pin	
1	+12V
2	GND
3	SIG
4	GND2
Pigtail WPCOL40	

Ignition_Coil_8	
D510C — WPCOL40 / GM 12162000 (4-pin) 4-pin	
1	+12V
2	GND
3	SIG
4	GND2
Pigtail WPCOL40	

Ignition_Coil_1	
D510C — WPCOL40 / GM 12162000 (4-pin) 4-pin	
1	+12V
2	GND
3	SIG
4	GND2
Pigtail WPCOL40	

Oil_Pressure_Sensor	
3-pin oval sealed — WPOIL40 / GM 1267313 3-pin	
1	+5V
2	SIG
3	GND
Pigtail WPOIL40	

MAP_Sensor	
Bosch 3-pin sealed — GM 55573248 / ACDelco PT2293 3-pin	
1	+5V
2	SIG
3	GND

ETB	
6-pin sealed — GM 13580085 mates GM 1260510 6-pin	
1	MotorA
2	MotorB
3	TPS1
4	TPS2
5	+5V
6	GND

Fuel_Pressure_Sensor	
3-pin (PN TBD) 3-pin	
1	+5V
2	SIG
3	GND

W5		
1x	20 AWG	2.5 m
M130:3:A03 1:WH Ignition_Coil_3:3:SIG		
#5 Ignition Coil 3 (WHT)		

W7		
1x	20 AWG	2.5 m
M130:4:A04 1:WHWH Ignition_Coil_5:3:SIG		
#7 Ignition Coil 5 (WHT/WHT)		

W4a		
1x	18 AWG	4.6 m
M130:1:A01 1:BN ETB:2:MotorB		
#4a ETB TAC Motor 2 (BRN)		

W4e		
1x	22 AWG	4.6 m
M130:2:A02 1:GY ETB:5:+6V		
#4e ETB 5V Reference (GRY)		

W8		
1x	20 AWG	2.5 m
M130:5:A05 1:WHBK Ignition_Coil_7:3:SIG		
#8 Ignition Coil 7 (WHT/BLK)		

W9		
1x	20 AWG	2.5 m
M130:6:A06 1:WHRD Ignition_Coil_2:3:SIG		
#9 Ignition Coil 2 (WHT/RED)		

W10		
1x	20 AWG	2.5 m
M130:7:A07 1:WHBU Ignition_Coil_4:3:SIG		
#10 Ignition Coil 4 (WHT/BLU)		

W11		
1x	20 AWG	2.5 m
M130:8:A08 1:WHYE Ignition_Coil_6:3:SIG		
#11 Ignition Coil 6 (WHT/YEL)		

W12		
1x	20 AWG	2.5 m
M130:9:A12 1:WHVT Ignition_Coil_8:3:SIG		
#12 Ignition Coil 8 (WHT/VIO)		

W24		
1x	20 AWG	2.5 m
M130:10:A13 1:WHOG Ignition_Coil_1:3:SIG		
#24 Ignition Coil 1 (WHT/ORG)		

W102		
1x	22 AWG	4.6 m
M130:11:A14 1:VT Oil_Pressure_Sensor:2:SIG		
#102 Oil Pressure Sensor (ECU) (VIO)		

W4c		
1x	22 AWG	4.6 m
M130:11:A14 1:GN ETB:3:TPS1		
#4c ETB TPS1 Signal (DK GRN)		

W108		
1x	22 AWG	4.6 m
M130:12:A15 1:VTWH MAP_Sensor:2:SIG		
#108 MAP Sensor (VIO/WHT)		

W112		
1x	22 AWG	4.6 m
M130:13:A16 1:VTBK Fuel_Pressure_Sensor:2:SIG		
#112 Fuel Pressure Sensor (VIO/BLK)		

W4d		
1x	22 AWG	4.6 m
M130:14:A17 1:VT ETB:4:TPS2		
#4d ETB TPS2 Signal (PPL)		

W4b		
1x	18 AWG	4.6 m
M130:15:A18 1:YE ETB:1:MotorA		
#4b ETB TAC Motor 1 (YEL)		

W4f		
1x	22 AWG	4.6 m
M130:31:B15 1:BK ETB:6:GND		
#4f ETB Signal Ground (BLK)		

W13		
1x	18 AWG	4.6 m
M130:16:A19 1:GN Fuel_Injector_1:2:CTRL		
#13 Fuel Injector 1 (GRN)		

W14		
1x	18 AWG	4.6 m
M130:17:A20 1:GNWH Fuel_Injector_2:2:CTRL		
#14 Fuel Injector 2 (GRN/WHT)		

W15		
1x	18 AWG	4.6 m
M130:18:A21 1:GNBK Fuel_Injector_3:2:CTRL		
#15 Fuel Injector 3 (GRN/BLK)		

W16		
1x	18 AWG	4.6 m
M130:19:A22 1:GNRD Fuel_Injector_4:2:CTRL		
#16 Fuel Injector 4 (GRN/RED)		

W17		
1x	18 AWG	4.6 m
M130:20:A27 1:GNBU Fuel_Injector_5:2:CTRL		
#17 Fuel Injector 5 (GRN/BLU)		

W18		
1x	18 AWG	4.6 m
M130:21:A28 1:GNYE Fuel_Injector_6:2:CTRL		
#18 Fuel Injector 6 (GRN/YEL)		

W19		
1x	18 AWG	4.6 m
M130:22:A29 1:GNVT Fuel_Injector_7:2:CTRL		
#19 Fuel Injector 7 (GRN/VIO)		

W20		
1x	18 AWG	4.6 m
M130:23:A30 1:GNOG Fuel_Injector_8:2:CTRL		
#20 Fuel Injector 8 (GRN/ORG)		

W99			
2x	22 AWG	+ S	4.6 m
M130:24:B01 1:WH Crank_Position_Sensor:2:SIG			
2:BK			
Shield			
#99 Crank Position Sensor — 22 AWG M27500-style shielded 2C, drain to sensor ground			

W101			
2x	22 AWG	+ S	4.6 m
M130:25:B02 1:WH Cam_Position_Sensor:2:SIG			
2:BK			
Shield			
#101 Cam Position Sensor — 22 AWG M27500-style shielded 2C, drain to sensor ground			

W109		
1x	22 AWG	4.6 m
M130:26:B03 1:BN Intake_Air_Temp_Sensor:1:SIG		
#109 Intake Air Temp Sensor (TAN)		

W110		
1x	22 AWG	4.6 m
M130:27:B04 1:BNWH Coolant_Temp_Sensor:1:SIG		
#110 Coolant Temp Sensor (ECU) (TAN/WHT)		

W113		
1x	22 AWG	4.6 m
M130:28:B05 1:BNBK Oil_Temperature_Sensor:1:SIG		
#113 Oil Temperature Sensor (TAN/BLK)		

W103			
2x	22 AWG	+ S	4.6 m
M130:29:B07 1:WH Knock_Sensor_Bank_1:1:SIG			
2:BK			
Shield			
#103 Knock Sensor Bank 1 — 22 AWG M27500-style shielded 2C, drain to sensor ground			

W104			
2x	22 AWG	+ S	4.6 m
M130:30:B13 1:WH Knock_Sensor_Bank_2:1:SIG			
2:BK			
Shield			
#104 Knock Sensor Bank 2 — 22 AWG M27500-style shielded 2C, drain to sensor ground			

Crank_Position_Sensor	
Metri-Pack 3-pin gray — WPCCKP40 / GM 1261562 3-pin	
1	+5V
2	SIG
3	GND
Pigtail WPCCKP40	

Cam_Position_Sensor	
Metri-Pack 3-pin — WPCMP30 / GM 1259172 3-pin	
1	+5V
2	SIG
3	GND
Pigtail WPCMP30	

Intake_Air_Temp_Sensor	
2-pin (LS3 IAT — GM PN TBD) 2-pin	
1	SIG
2	GND

Coolant_Temp_Sensor	
Metri-Pack 150.2 2-pin sealed — WPCTS30 / GM 1923656 2-pin	
1	SIG
2	GND
Pigtail WPCTS30	

Oil_Temperature_Sensor	
2-pin (PN TBD) 2-pin	
1	SIG
2	GND

Knock_Sensor_Bank_1	
2-pin sealed metric — WPKNO40 / GM 1262373 2-pin	
1	SIG
2	GND
Pigtail WPKNO40	

Knock_Sensor_Bank_2	
2-pin sealed metric — WPKNO40 / GM 1262373 2-pin	
1	SIG
2	GND
Pigtail WPKNO40	