


Appearance Configuration in IGEL OS 12

This article shows how to configure the appearance of the on-screen keyboard in IGEL OS.

The layout for the normal keyboard is used for the on-screen keyboard.

Menu path: **User Interface > Input > Touchscreen > On-screen keyboard > Appearance**



Show function keys

☑ The on-screen keyboard features the function keys [F1] ... [F12]. (Default)

Show navigation keys

☑ The on-screen keyboard features the arrow keys for navigating on the screen. (Default)

Show Numpad

☑ The on-screen keyboard features the number block.

☐ The on-screen keyboard does not feature the number block. (Default)

Enable switching to alternative layout

☒ The on-screen keyboard has an additional key by which the user can toggle between the normal layout and a reduced layout. The reduced layout resembles the numpad, with the following differences:

- Additional backspace key [←]
- Additional tab key [⇥]
- Additional space key []
- Additional escape key [Esc]
- Return key [↵] instead of [Enter] key

☐ Switching to the reduced layout is not possible. (Default)