## Move problem on the touch screen

When you move the head manually, there is coordinate limit in x and y axis. If you move the head only in one direction, the head will stop moving at some limit point. It is normal. The limit point will be not in the side point if you don't home the x and y axis first.

When printer starts, it will take time to let it be normal like the computer starts. So if we click move button on touch screen at once after it starts, there will be no respond. And if you click more times, the touch screen freeze.

For this problem, please wait a while to click the menu on the touch screen.