Fax:+86 575 88489635

Skype: bradenking0202



How to upload screen firmware to Bibo 3D printer's touch screen

Note: uploading firmware needs windows system computer or virtual PC windows system on the Mac and SD card (class4, smaller than 16GB)!!! You can use the SD card sent with the printer, though it is for 3d printing and may be failed in updating the firmware. Please have a spare SD card too if possible before updating

- 1, Unzip the touch screen firmware file.
- 2, Please copy these files as the photo below (not one folder but its contents) into SD card directly (to the root (main) folder of your SD Card), and the SD card should be empty (no files) first before copying.

mks_font	2018/9/18 18:23	文件夹	
mks_pic	2018/9/19 11:16	文件夹	
mks_config.txt	2018/12/30 10:30	文本文档	7 KB
mkstft28.bin	2018/9/19 10:58	KuaiZipMount.bin	228 KB
MksWifi.bin	2018/5/5 10:45	KuaiZipMount.bin	336 KB

Copy operation should be done in windows system or virtual PC windows system on the **Mac**, as Mac users meet the touch screen firmware uploading problem.

- 3, Please insert the SD card into the printer.
- 4, Please turn the power on.(If the power has already been on, please power off first, then power on)

Mobile:+86 133 25759139

E-Mail: bibo@ourbibo.com

- 5. These files will be uploaded into printer automatically.
- 6, Now new screen firmware is uploaded successfully.