

James Stallkamp

CS373

Lab 4

Hardware Hacking


To start this lab my first thought was simply to try and identify which pins were active at all. I connected my logic analyzer and teensys and started up the logic software. At first I tried connecting a random pin and checking for any signal, however after checking three or four pins I found nothing at all.

My next idea was to try and see if there was any signal on the pins at all, to do this I grabbed a digital multi meter and checked for voltage on each pin. I ended up on this idea because it was much faster to probe the pins rather than connect a pin and set up the logic analyzer. This did in fact reveal several pins that had signal on them.

I found several pins with line voltage on them, I tried connecting to those pins and using the logic analyzer, several of them had signals but I did find the 5v pin which stood out and some other pins that still gave no signal.


I attempted to use several of the analyzers built into the software to decode the signals but I was completely in the dark and nothing produced anything understandable.

I then went to this pin out diagram



Teensy® 4.0 Back Side

Additional pins and features available on the back side



For solutions to the most common issues and technical support, please visit:

www.pjrc.com/help

Teensy 4.0 System Requirements:
PC computer with Windows 7, 8, 10 or later
or Ubuntu Linux 14.04 or later
or Macintosh OS-X 10.8 or later
USB Micro-B Cable



I quickly realized that most of the pins that yielded any signal were serial ports. I then set the analyzer to serial mode with all default settings and one of them yielded a message!

I eventually was able to find the baud rates for each signal and found these results.

14 serial 4800 baud serial port This is not

17 serial 4800 baud serial port unfortunately try a different pin

15 nothing Rec/Trans

16 nothing Rec/Trans

20 serial port 9600 baud When all else fails try serial ports

21 nothing

22 nothing

23 nothing

12 nothing

11 nothing

10 nothing

9 nothing

8 serial 19200 baud The secret message is THERE: IS NO SPOON Nearly Done with CS373

7 nothing

6 serial port 9600 baud When all else fails try serial ports

5

4

3

2

1



With that I was finished, The secret message is THERE: IS NO SPOON Nearly Done with CS373.