Transferring gyro data from XML file to Excel

- 1. Open Excel and open the XML file
- 2. Copy data under /wait-for-notification/assert-value/@value
- 3. Create a new sheet and paste the data into the A column
- 4. Select the A column, go to Data and select Text to Columns
- 5. Select fixed width and create a break line after the 8th value (split in half)
- 6. Make sure to select Text format for both halves of the data
- 7. Click destination and click on the B column and press finish, data should be split evenly
- 8. <u>To get millis value:</u>

Select D1 and paste this formula:

= HEX2DEC(RIGHT(A1,8))

- 9. Drag the corner down the whole length of the data to fill the remaining cells
- 10. Go into D1 and subtract the value in the cell in the formula Example: = HEX2DEC(RIGHT(A1, 8)) 199234 (whatever value is in E1)
- 11. Double click D1 corner to change the whole column, now you're done with millis values.
- 12. To get gyro values:

In E1 paste this formula:

=IF(HEX2DEC(C1) > HEX2DEC("7FFFFFFF"), HEX2DEC(C1) - HEX2DEC("FFFFFFFF") -1, HEX2DEC(C1)) /1000000

- 13. Double click E1 corner and gyro values should fill in
- 14. Select D and E columns and create a scatter plot
- 15. Delete outlier rows, resize plot if desired.