

Ethernet Basics

by Sophia



WHAT'S COVERED

In this lesson, you will examine the concepts and characteristics of Ethernet communications.

Specifically, this lesson will cover the following:

- 1. Local Area Network Basics
 - 1a. Ethernet Basics
 - 1b. Collision Domain
 - 1c. Broadcast Domain
 - 1d. CSMA/CD
 - 1e. Broadband/Baseband
 - 1f. Bit Rate vs. Baud Rate
 - 1g. Wavelength
 - 1h. Half- and Full-Duplex Ethernet

1. Local Area Network Basics

Networks and networking have grown exponentially over the last twenty years. They have had to quickly evolve to keep up with huge increases in basic user needs ranging from sharing data and printers to more advanced demands like videoconferencing. Unless everyone who needs to share network resources is located in the same office area, which is an increasingly uncommon situation, the challenge is to connect the sometimes large number of networks together so all users can share the networks' resources.

1a. Ethernet Basics

Ethernet is a contention-based media-access method that allows all hosts on a network to share the same bandwidth of a link. Ethernet is popular because it is readily scalable, meaning that it is comparatively easy to integrate faster versions, such as **Fast Ethernet** and **Gigabit Ethernet**, into an existing network infrastructure. It is also relatively simple to implement in the first place, and with it, troubleshooting is reasonably straightforward.



Ethernet uses both Layer 2 (Data Link) and Layer 1 (Physical) specifications, and this part of this tutorial will give you both the Layer 2 and Layer 1 information you need to effectively implement, troubleshoot, and maintain an Ethernet network.

In the following sections, we will also cover some basic terms used in networking with Ethernet technologies. Let's start with collision domains.



Ethernet

A set of network cabling and network access (CSMA/CD) protocol standards for logical bus topology computer networks invented by Xerox but now controlled by the 802.3 subcommittee of the IEEE.

Fast Ethernet

100 Mbps Ethernet.

Gigabit Ethernet

1000 Mbps Ethernet.

1b. Collision Domain

The term **collision domain** is a particular area wherein one device sends a frame out on a network segment and every other device on that same physical network segment receives it. If two devices on one physical segment transmit at the same time, a **collision** occurs when each device's signals interfere with another on the wire and forces the devices to retransmit later. Collisions may have a negative effect on network performance, so they are something we want to minimize.



The situation we just described is typically found in a **hub** environment where each host segment connects to a hub that represents only one collision domain and one broadcast domain. What is a broadcast domain?



Collision Domain

The area of an Ethernet network where a collision can occur.

Collision

An Ethernet condition of multiple interfaces transmitting simultaneously.

Hub

A Layer 1 device that is a multiport repeater.

1c. Broadcast Domain

A **broadcast** is a transmission address to all stations on a network. A **broadcast domain** refers to the set of all devices on a network segment that receive the broadcasts sent on that segment. Even though a broadcast domain is typically a boundary delimited by network routers, it can also reference a logical division of a network

segment where all hosts can reach each other via a Layer 2 **MAC** address broadcast. We will cover collision domains and broadcast domains in more detail later in the course.



Broadcast

A transmission addressed to all stations.

Broadcast Domain

The area of a network where a broadcast will be received by all stations.


MAC Address

Media Access Control address; A unique identifying number assigned to most network devices.

1d. CSMA/CD

Ethernet networking uses Carrier Sense Multiple Access with Collision Detection (CSMA/CD), a media access control method that helps devices share the bandwidth evenly without having two devices transmit at the same time on the network medium. CSMA/CD was created to overcome the problem of those collisions that occur when frames are transmitted simultaneously from different hosts. Collision management is crucial because when a host transmits in a CSMA/CD network, all the other hosts on the network receive and examine that transmission. Only bridges, switches, and routers, but not hubs, can effectively prevent a collision from impacting the entire network.

So, how does the CSMA/CD protocol work? Let us start by taking a look at the diagram below, where a collision has occurred in the network.



When a host wants to transmit over the network, it first checks for the presence of a digital signal on the wire, which is called "carrier". If all is clear, meaning that no other host is transmitting, the host will then proceed with its transmission. The transmitting host constantly monitors the wire to make sure no other hosts begin transmitting. If the host detects a collision, it sends out an extended jam signal that causes all hosts on the segment to stop sending data.

The hosts respond to that jam signal by waiting a while before attempting to transmit again. A back-off algorithm determines when the colliding stations can retransmit. If collisions keep occurring after 15 tries, the hosts attempting to transmit will then stop transmitting that frame.

- A jam signal informs all devices that a collision occurred.
- The collision invokes a random back-off algorithm.
- Each device on the Ethernet segment stops transmitting for a short time until the timers expire.
- All hosts have equal priority to transmit after the timers have expired.

And following are the effects of having a CSMA/CD network that has sustained heavy collisions:

- Delay
- · Low throughput

Congestion



Carrier Sense Multiple Access With Collision Detection (CSMA/CD)

Ethernet's media access control protocol.

Back off

To defer transmission.

1e. Broadband/Baseband

We have two ways to send analog and digital signals down a wire: broadband and baseband. We hear the term "broadband" a lot these days because that is pretty much what everyone uses at home. It allows us to have both our analog voice and digital data carried on the same network cable or physical medium. Broadband allows us to send multiple frequencies of different signals down the same wire at the same time, which is called **frequency-division multiplexing**, and to send both analog and digital signals.

Baseband is what all LANs use. This is where all the bandwidth of the physical media is used by only one signal. For example, Ethernet uses only one digital signal at a time, and it requires all the available bandwidth. If multiple signals are sent from different hosts at the same time, we get collisions.



Frequency-Division Multiplexing

Combining transmissions from multiple stations onto a single communications channel carrying multiple frequencies.

1f. Bit Rate vs. Baud Rate

Bit rate is a measure of the number of data bits (0s and 1s) transmitted in one second in either a digital or analog signal. A figure of 56,000 bits per second (bps) means 56,000 0s or 1s can be transmitted in one second, which we simply refer to as **bps**. Note the lowercase 'b' in bps; the uppercase in **Bps** means bytes per second.

In previous decades, we used the term **baud rate** frequently, but that was replaced by bps because it was more accurate. One baud is one electronic state change per second, for example, from 0.2 volts to 3 volts or from binary 0 to 1. However, since a single state change can involve more than a single bit of data, the bps unit of measurement has replaced it as a more accurate definition of how much data you are transmitting or receiving.



Bit Rate

The frequency at which bits (binary digits) pass a given physical or metaphorical point, measured in bps (bits per second).

bps

Bits per second.

Bps


Bytes per second.

Baud Rate

The number of signaling events per second.

1g. Wavelength

With electromagnetic radiation, radio waves, light waves, or even infrared waves make characteristic patterns as they travel through space. Patterns can have different wavelengths, as shown in the illustration below.



Each wave pattern has a certain shape and length. The distance between peaks (high points) is called wavelength. If two wave patterns are different, we would say they do not have the same wavelength and that is the way we tell different kinds of electromagnetic energy apart. We can use this to our advantage in electronics by sending traffic on different wavelengths at the same time.



Wavelength

The length of a single cycle of a wave, as measured by the distance between one peak or trough of a wave and the next.

1h. Half- and Full-Duplex Ethernet

Half-duplex Ethernet is defined in the original IEEE 802.3 Ethernet specification. Basically, when you run half-duplex, you are using only one wire pair with a digital signal either transmitting or receiving.



This really is not all that different from full duplex because you can both transmit and receive; you just do not get to do that at the same time running half duplex as you can if you are running full duplex.

Here is how it works: If a host hears a digital signal, it uses the CSMA/CD protocol to detect collisions and to permit retransmitting if a collision does occur. Half-duplex Ethernet, typically 10BaseT, is only about 30 to 40%


permit retransmitting if a collision does occur. Half-duplex Ethernet, typically 10BaseT, is only about 30 to 40% efficient because a large 10BaseT network will usually provide only 3 Mbps to 4 Mbps at most. Although it is true that 100 Mbps Ethernet can and sometimes does run half duplex, it is just not very common to find that happening anymore.

In contrast, full-duplex Ethernet uses two pairs of wires at the same time instead of just one wire pair like half duplex employs. Plus, full duplex uses a point-to-point connection between the transmitter of the sending device and the receiver of the receiving device, which in most cases is a switch. This means that with full-duplex data transfer, you not only get higher data-transfer speeds, but you also get collision prevention.

You do not need to worry about collisions because now it is like a freeway with multiple lanes instead of the single-lane road provided by half duplex. Full-duplex Ethernet is supposed to offer 100 % efficiency in both directions, for example, you can get 20 Mbps with a 10 Mbps Ethernet running full duplex or 200 Mbps for Fast Ethernet. But this rate is something known as an aggregate rate, which is the total amount of bandwidth available from all ports.

- · With a connection from a switch to a host
- · With a connection from a switch to a switch
- With a connection from a host to a host using a crossover cable

When a full-duplex Ethernet port is powered on, it first connects to the remote end and then negotiates with the other end of the Fast Ethernet link. This is called an *auto-detect mechanism*. This mechanism first decides on the exchange capability, which means it checks to see if it can run at 10, 100, or even 1000 Mbps. It then checks to see if it can run full duplex, and if it cannot, it will run half-duplex instead. Hosts auto-detect by default both the speed (in Mbps) and the duplex type available, but you can manually set both the speed and duplex type on the network interface card (NIC), as shown here.



Today, it is pretty rare to go into a NIC configuration on a host and change these settings, but this example demonstrates that you can do that if you want.



Half-duplex Ethernet shares a collision domain and provides a lower effective throughput than full-duplex Ethernet, which typically has a higher effective throughput.

Lastly, remember these important points:

- There are no collisions in full-duplex mode.
- A dedicated switch port is required for each full-duplex host.
- The host network card and the switch port must both be capable of operating in full-duplex mode.



SUMMARY

In this lesson, you learned about **networking basics**. These included components like ethernet collision domain, a broadcast domain, and about Ethernet's media access control protocol CSMA/CD. In the next lesson you will learn about Ethernet frame formatting, and binary, decimal, and hexadecimal conversion.

Source: This content and supplemental material has been adapted from CompTIA Network+ Study Guide: Exam N10-007, 4th Edition. Source Lammle: CompTIA Network+ Study Guide: Exam N10-007, 4th Edition - Instructor Companion Site (wiley.com)



TERMS TO KNOW

Back off

To defer transmission.

Baud Rate

The number of signaling events per second.

Bit Rate

The frequency at which bits (binary digits) pass a given physical or metaphorical point, measured in bps (bits per second).

Bps

Bytes per second.

Broadcast

A transmission addressed to all stations.

Broadcast Domain

The area of a network where a broadcast will be received by all stations.

Carrier Sense Multiple Access With Collision Detection (CSMA/CD)

Ethernet's media access control protocol.

Collision

An Ethernet condition of multiple interfaces transmitting simultaneously.

Collision Domain

The area of an Ethernet network where a collision can occur.

Ethernet

A set of network cabling and network access (CSMA/CD) protocol standards for logical bus topology computer networks invented by Xerox but now controlled by the 802.3 subcommittee of the IEEE.

Fast Ethernet

100 Mbps Ethernet.

Frequency-Division Multiplexing

Combining transmissions from multiple stations onto a single communications channel carrying multiple frequencies.

Gigabit Ethernet

1000 Mbps Ethernet.

Hub

A Layer 1 device that is a multiport repeater.

MAC Address

Media Access Control address; A unique identifying number assigned to most network devices.

Wavelength

The length of a single cycle of a wave, as measured by the distance between one peak or trough of a wave and the next.

bps

Bits per second.