31	25	24	19 15	14 12	11	7	6	0	_		
fun	ct7	rs2	rs1	funct3	rd		орс	ode	R类		
	imm[11:0]		rs1	funct3	rd	rd opcode		rd		ode	I类
imm[imm[11:5] rs2		rs1	funct3	imm[4:0]	imm[4:0]		ode	S类		
imm[12	imm[12 10:5] rs2		rs2 rs1 funct3 imm[4:1 11]		1]	орс	ode	SB类			
imm[31:12]					rd		орс	ode	U类		
	imm[2	20 10:1 11	rd		орс	ode	UJ类				

RV32I 基本指令集

							•
		imm[31:12]			rd	0110111	LUI
		imm[31:12]			rd	0010111	AUIPC
imm[20 10:1 11			19:12]		rd	1101111	JAL
imm[11:0]			rs1	000	rd	1100111	JALR
imm[1]	2 10:5]	rs2	rs1	000	imm[4:1 11]	1100011	BEQ
	2 10:5]	rs2	rs1	001	imm[4:1 11]	1100011	BNE
	2 10:5]	rs2	rs1	100	imm[4:1 11]	1100011	BLT
	2 10:5]	rs2	rs1	101	imm[4:1 11]	1100011	BGE
	2 10:5]	rs2	rs1	110	imm[4:1 11]	1100011	BLTU
imm[1:		rs2	rs1	111	imm[4:1 11]	1100011	BGEU
[imm[11:0		rs1	000	rd	0000011	LB
	imm[11:0		rs1	001	rd	0000011	LH
	imm[11:0		rs1	010	rd	0000011	LW
	imm[11:0		rs1	100	rd	0000011	LBU
	imm[11:0	-	rs1	101	rd	0000011	LHU
imm		rs2	rs1	000	imm[4:0]	0100011	SB
imm		rs2	rs1	001	imm[4:0]	0100011	SH
	[11:5]	rs2	rs1	010	imm[4:0]	0100011	SW
1111111	imm[11:0		rs1	000		0010011	ADDI
		•		010	rd	0010011	SLTI
	imm[11:0 imm[11:0		rs1 rs1	010	rd	0010011	SLTIU
		•			rd		1
	imm[11:0	•	rs1	100	rd	0010011	XORI
	imm[11:0	-	rs1	110	rd	0010011	ORI
000/	imm[11:0		rs1	111	rd	0010011	ANDI
	0000	shamt	rs1	001	rd	0010011	SLLI
	0000	shamt	rs1	101	rd	0010011	SRLI
	0000	shamt	rs1	101	rd	0010011	SRAI
	0000	rs2	rs1	000	rd	0110011	ADD
	0000	rs2	rs1	000	rd	0110011	SUB
	0000	rs2	rs1	001	rd	0110011	SLL
	0000	rs2	rs1	010	rd	0110011	SLT
	0000	rs2	rs1	011	rd	0110011	SLTU
	0000	rs2	rs1	100	rd	0110011	XOR
	0000	rs2	rs1	101	rd	0110011	SRL
	0000	rs2	rs1	101	rd	0110011	SRA
	0000	rs2	rs1	110	rd	0110011	OR
	0000	rs2	rs1	111	rd	0110011	AND
0000 Pred		Succ	00000	000	00000	0001111	FENCE
0000 0000		0000	00000	001	00000	0001111	FENCE.I
00000000000		00000	000	00000	1110011	ECALL	
00000000001			00000	000	00000	1110011	EBREA
csr			rs1	001	rd	1110011	CSRRW
csr			rs1	010	rd	1110011	CSRRS
csr			rs1	011	rd	1110011	CSRRC
	csr		zimm	101	rd	1110011	CSRRW
	csr		zimm	110	rd	1110011	CSRRSI
	csr		zimm	111	rd	1110011	CSRRCI
					· · · · · · · · · · · · · · · · · · ·		

31	25	24	19 15	14 12	11	7	6	0	_
funct7		funct7 rs2		funct3	rd		opcode		R类
imm[11:0]			rs1	funct3	rd	орс	ode	I类	
imm[:	11:5]	rs2	rs1	funct3	imm[4:	0]	орс	ode	S类

RV64I基本指令集(除了RV32I之外)

imm[11:	rs1	110	rd	0000011	LWU				
imm[11:	imm[11:0]			rd	0000011	LD			
imm[11:5]	rs2	rs1	011	imm[4:0]	0100011	SD			
000000	shamt	rs1	001	rd	0010011	SLLI			
000000	shamt	rs1	101	rd	0010011	SRLI			
010000	010000 shamt		101	rd	0010011	SRAI			
imm[11:	imm[11:0]			rd	0011011	ADDIW			
0000000	shamt	rs1	001	rd	0011011	SLLIW			
0000000	shamt	rs1	101	rd	0011011	SRLIW			
0100000	shamt	rs1	101	rd	0011011	SRAIW			
0000000	rs2	rs1	000	rd	0111011	ADDW			
0100000	0100000 rs2		000	rd	0111011	SUBW			
0000000	rs2	rs1	001	rd	0111011	SLLW			
0000000	rs2	rs1	101	rd	0111011	SRLW			
0100000	rs2	rs1	101	rd	0111011	SRAW			

RV32M标准扩展

0000001	rs2	rs1	000	rd	0110011	MUL
0000001	rs2	rs1	001	rd	0110011	MULH
0000001	rs2	rs1	010	rd	0110011	MULHSU
0000001	rs2	rs1	011	rd	0110011	MULHU
0000001	rs2	rs1	100	rd	0110011	DIV
0000001	rs2	rs1	101	rd	0110011	DIVU
0000001	rs2	rs1	110	rd	0110011	REM
0000001	rs2	rs1	111	rd	0110011	REMU

RV64M标准扩展(除了RV32M之外)

0000001	rs2	rs1	000	rd	0111011	MULW
0000001	rs2	rs1	100	rd	0111011	DIVW
0000001	rs2	rs1	101	rd	0111011	DIVUW
0000001	rs2	rs1	110	rd	0111011	REMW
0000001	rs2	rs1	111	rd	0111011	REMUW

RV32A标准扩展

00010	а	rl	00000	rs1	010	rd	0101111	LR.W
00011	а	rl	rs2	rs1	010	rd	0101111	SC.W
00001	а	rl	rs2	rs1	010	rd	0101111	AMOSWAP.W
00000	а	rl	rs2	rs1	010	rd	0101111	AMOADD.W
00100	а	rl	rs2	rs1	010	rd	0101111	AMOXOR.W
01100	а	rl	rs2	rs1	010	rd	0101111	AMOAND.W
01000	а	rl	rs2	rs1	010	rd	0101111	AMOOR.W
10000	а	rl	rs2	rs1	010	rd	0101111	AMOMIN.W
10100	а	rl	rs2	rs1	010	rd	0101111	AMOMAX.W
11000	а	rl	rs2	rs1	010	rd	0101111	AMOMINU.W
11100	а	rl	rs2	rs1	010	rd	0101111	AMOMAXU.W