

DOORTRONIX SLIDE WIRING DIAGRAM (FULL BREAKOUT)

W	X	Y	Z
12 VAC	12 VAC		

1 AMP TOTAL
ACCESSORY POWER

BREAKAWAY PROXIMITY
SWITCHES N.C.

NORMALLY OPEN	RELAY COMMON	NORMALLY CLOSED
T	U	V

RELAY / ELECTRIC LOCK OUTPUT

ON / OFF / HOLD
ROCKER SWITCH

SAFETY BEAM
CONTROL
N.O.

SAFETY BEAMS

EXT. ACTIVATION
SENSOR

INT. ACTIVATION
SENSOR

E	BREAKAWAY
F	COMMON
G	BEAMS / SAFETY
H	COMMON
I	EXTERIOR ACTIVATE
J	COMMON
K	INTERIOR ACTIVATE
L	COMMON

4	COMMON
5	SECURITY / MISC 2
6	COMMON
7	REDUCED OPEN
8	COMMON
9	SEL. SWITCH 1
10	COMMON
11	SEL. SWITCH 2
12	SEL. SWITCH 3

NOTES: TO TURN ON KEYPAD, SIMULTANEOUSLY PRESS THE
TWO LOWER BUTTONS FOR 3 SECONDS.

BREAKAWAY LOGIC N.C. (bL = nC)

FUNCTION SWITCH 3 POSITION ROCKER (FS = 03)

FUNCTION SWITCH 4 POSITION ROTARY (FS = 24)

POWER BOOST - HOLD CLOSE FORCE (Q 1-04)

DIAGNOSTIC CODES

1d	ONE WAY TRAFFIC
2d	TWO WAY TRAFFIC
bA	BREAKAWAY
Ea	EXTERIOR ACTIVATE
EO	EASY OPEN
Fc	FULLY CLOSED
FO	FULLY OPEN
Ho	HOLD OPEN
IA	INTERIOR ACTIVATE
LC	LEARN CLOSING
Ld	LOCKED DOOR
Ln	LENGTH (INCHES)
Lo	LEARN OPENING

LS	LEARN STALL
oF	OFF
oP	OPENING DURING CLOSING
oS	OPENING SPEED MODE
PO	PARTIALLY OPEN
ro	REDUCED OPENING
SA	SAFETY BEAMS
SC	SLOW CLOSING
SE	SECURITY ENTRY
St	STALLED
tA	TEST ACTIVATE
tS	THRESHOLD SENSOR
US	UNDERSIZED



DOORTRONIX INC
5783 COUNTY ROAD 1219
MALAKOFF TX 75148
P: 888 453 5196
www.doortronixusa.com
info@doortronix.com