


DOORTRONIX SLIDE WIRING DIAGRAM (FIXED SIDELITE)



NOTES: TO TURN ON KEYPAD, SIMULTANEOUSLY PRESS THE TWO LOWER BUTTONS FOR 3 SECONDS.

BREAKAWAY LOGIC N.C. ($bL = nC$)

FUNCTION SWITCH 3 POSITION ROCKER ($FS = 03$)

FUNCTION SWITCH 4 POSITION ROTARY ($FS = 24$)

POWER BOOST - HOLD CLOSE FORCE ($Q 1-04$)



DOORTRONIX INC
5783 COUNTY ROAD 1219
MALAKOFF TX 75148
P: 888 453 5196
www.doortronixusa.com
info@doortronix.com

DIAGNOSTIC CODES

<i>1d</i>	ONE WAY TRAFFIC	<i>L5</i>	LEARN STALL
<i>2d</i>	TWO WAY TRAFFIC	<i>oF</i>	OFF
<i>bA</i>	BREAKAWAY	<i>oP</i>	OPENING DURING CLOSING
<i>Ea</i>	EXTERIOR ACTIVATE	<i>oS</i>	OPENING SPEED MODE
<i>Eo</i>	EASY OPEN	<i>Po</i>	PARTIALLY OPEN
<i>Fc</i>	FULLY CLOSED	<i>ro</i>	REDUCED OPENING
<i>Fo</i>	FULLY OPEN	<i>SA</i>	SAFETY BEAMS
<i>Ho</i>	HOLD OPEN	<i>SC</i>	SLOW CLOSING
<i>IA</i>	INTERIOR ACTIVATE	<i>SE</i>	SECURITY ENTRY
<i>LC</i>	LEARN CLOSING	<i>St</i>	STALLED
<i>Ld</i>	LOCKED DOOR	<i>tA</i>	TEST ACTIVATE
<i>Ln</i>	LENGTH (INCHES)	<i>tS</i>	THRESHOLD SENSOR
<i>Lo</i>	LEARN OPENING	<i>US</i>	UNDERSIZED