

ΤΜΗΜΑ ΜΗΧ. ΠΛΗΡΟΦΟΡΙΚΗΣ κ ΤΛΠ.


ΜΙΚΡΟΕΠΕΞΕΡΓΑΣΤΕΣ

Διδάσκων: Κοντογιάννης Σωτήριος

ΕΡΓΑΣΤΗΡΙΟ 8

ΑΣΚΗΣΗ 1: Να δημιουργήσετε ένα πρόγραμμα σε C το οποίο θα χρησιμοποιεί την βιβλιοθήκη SPI ώστε να μεταφέρει μέσω της SPI θύρας εισόδου εξόδου δύο arduino uno (master – slave) Το μήνυμα "Hello world!".

Συνδεσμολογία:





ΤΜΗΜΑ ΜΗΧ. ΠΛΗΡΟΦΟΡΙΚΗΣ κ ΤΛΠ.

ΜΙΚΡΟΕΠΕΞΕΡΓΑΣΤΕΣ

Διδάσκων: Κοντογιάννης Σωτήριος

Υπόδειξη 1 spi_server:

```
#include <SPI.h>
void setup (void)
  Serial.begin(115200);
  digitalWrite(SS, HIGH);
  SPI.begin ();
  SPI.setClockDivider(SPI_CLOCK_DIV8);
void loop (void)
  char c;
  // enable Slave Select
  digitalWrite(SS, LOW); // SS is pin 10
  // send test string
  for (const char * p = "Hello, world!\n" ; c = *p; p++) {
    SPI.transfer (c);
    Serial.print(c);
  // disable Slave Select
  digitalWrite(SS, HIGH);
 delay (1000);
```

Υπόδειξη 1 spi_client:



ΤΜΗΜΑ ΜΗΧ. ΠΛΗΡΟΦΟΡΙΚΗΣ κ ΤΛΠ.

ΜΙΚΡΟΕΠΕΞΕΡΓΑΣΤΕΣ

Διδάσκων: Κοντογιάννης Σωτήριος

```
#include <SPI.h>
 char buf [100];
 volatile byte pos;
 volatile boolean process it;
 void setup (void)
 {
   Serial.begin (115200);
   // have to send on master in, *slave out*
   pinMode(MISO, OUTPUT);
   // turn on SPI in slave mode
   SPCR \mid = \_BV(SPE);
   // get ready for an interrupt
   pos = 0; // buffer empty
   process_it = false;
   // now turn on interrupts
   SPI.attachInterrupt();
 }
// SPI interrupt routine
ISR (SPI_STC_vect)
 byte c = SPDR; // grab byte from SPI Data Register
 if (pos < sizeof buf)</pre>
    buf [pos++] = c;
    if (c == '\n')
      process_it = true;
  }
}
void loop (void)
{
 if (process_it)
  {
    buf [pos] = 0;
    Serial.println (buf);
    pos = 0;
    process_it = false;
  }
}
```



ΤΜΗΜΑ ΜΗΧ. ΠΛΗΡΟΦΟΡΙΚΗΣ κ ΤΛΠ.

ΜΙΚΡΟΕΠΕΞΕΡΓΑΣΤΕΣ

Διδάσκων: Κοντογιάννης Σωτήριος

<u>ΑΣΚΗΣΗ 2:</u> Να δημιουργήσετε ένα πρόγραμμα σε C/assembly το οποίο θα χρησιμοποιεί την βιβλιοθήκη SPI ώστε να μεταφέρει μέσω της SPI θύρας εισόδου εξόδου δύο arduino uno (master – slave) Τον αριθμό 0x01.

SERVER:

```
#include <avr/io.h>
#include <util/delay.h>
#define SPI_PORT PORTB
#define SPI_DDR DDRB
#define SPI_CS PINB2
unsigned char SPI_WriteRead(unsigned char dataout)
{
 unsigned char datain;
  // Start transmission (MOSI)
  SPDR = dataout;
  // Wait for transmission complete
 while(!(SPSR & (1<<SPIF)));</pre>
  // Get return Value;
  datain = SPDR;
  // Latch the Output using rising pulse to the RCK Pin
  SPI PORT |= (1<<SPI CS);
    _delay_us(1);
                               // Hold pulse for 1 micro second
 // Disable Latch
  SPI PORT &= \sim(1<<SPI CS);
   // Return Serial In Value (MISO)
  return datain;
void setup()
  Serial.begin(9600);
  // Set MOSI and SCK as output, others as input
  SPI_DDR = (1 << DDB3) | (1 << DDB5) | (1 << DDB2);
  // Latch Disable (RCK Low)
  SPI PORT &= \sim(1<<SPI CS);
  // Enable SPI, Master, set clock rate fck/2 (maximum)
  SPCR = (1 << SPE) | (1 << MSTR) | (1 < DORD);
  SPSR = (1 < < SPI2X);
}
void loop()
  // Latch Disable (RCK Low)
  SPI PORT &= \sim(1<<SPI CS);
   Serial.println("Starting Transmission:");
  SPI WriteRead('0');
  _delay_ms(1000);
```



IIAN ΔΥΤ. MAKEΔONIAΣ XEIM. EΞAM. 2014-2015

ΤΜΗΜΑ ΜΗΧ. ΠΛΗΡΟΦΟΡΙΚΗΣ κ ΤΛΠ.

ΜΙΚΡΟΕΠΕΞΕΡΓΑΣΤΕΣ

Διδάσκων: Κοντογιάννης Σωτήριος

CLIENT:

```
#include <avr/io.h>
#include <util/delay.h>
#define SPI_PORT PORTB
#define SPI_DDR DDRB
#define SPI_CS PINB2
unsigned char cnt;
unsigned char SPI_WriteRead(unsigned char dataout)
  unsigned char datain;
  // Start transmission (MOSI)
  SPDR = dataout;
  // Wait for transmission complete
  while(!(SPSR & (1<<SPIF)));</pre>
  // Get return Value;
  datain = SPDR;
  // Latch the Output using rising pulse to the RCK Pin
  SPI PORT |= (1<<SPI CS);
                               // Hold pulse for 1 micro second
     _delay_us(1);
  // Disable Latch
  SPI PORT &= \sim(1<<SPI CS);
   // Return Serial In Value (MISO)
  return datain;
}
void setup()
  Serial.begin(9600);
  /* Set MISO output, all others input */
  SPI_DDR \mid = (1 < DDB4);
  /* Enable SPI, the ATmega is in Slave mode at startUp */
  SPCR \mid = (1 << SPE);
  Serial.println("Receiving Transmission:");
void loop()
  cnt=SPI_WriteRead(0);
  Serial.println(cnt);
__delay_ms(500);
}
```



ΤΜΗΜΑ ΜΗΧ. ΠΛΗΡΟΦΟΡΙΚΗΣ κ ΤΛΠ.

ΜΙΚΡΟΕΠΕΞΕΡΓΑΣΤΕΣ

Διδάσκων: Κοντογιάννης Σωτήριος

ASSEMBLY SERVER:

```
spi3.h
```

```
/*
 * Global register variables.
 */
#ifdef __ASSEMBLER__
/* Assembler-only stuff */
#else /* !ASSEMBLER */
/* C-only stuff */
#include <stdint.h>
#include <wString.h> // for String type
extern "C" void spi_send(void);
extern "C" void spi_init(void);
#endif /* ASSEMBLER */
```

spi3.ino

```
#include "spi3.h"

void setup()
{
    Serial.begin(9600);
    while (!Serial) {}
    spi_init();
        Serial.println("Server Start");
    delay(1000);
}

void loop()
{
    Serial.println("Sending data");
    spi_send();
    delay(2000);
}
```



ΤΜΗΜΑ ΜΗΧ. ΠΛΗΡΟΦΟΡΙΚΗΣ κ ΤΛΠ.

ΜΙΚΡΟΕΠΕΞΕΡΓΑΣΤΕΣ

Διδάσκων: Κοντογιάννης Σωτήριος

code.S

```
#define __SHR_OFFSET 0
/*Automatically subtract 0x20 from I/O addresses
*/
#include <avr/io.h>
#include <avr/interrupt.h>
#include "spi3.h"
#define SPI_PORT PORTB
#define SPI_DDR DDRB
#define SPI_CS PINB2
.section .data
.section .text
.global spi_init
spi init:
; DECLARE MASTER SPI :
LDI R16, (1<<DDB2) | (1<<DDB3) | (1<<DDB5)
OUT DDRB,R16
LDI R17, (1<<SPE) (1<<MSTR); (1<<DORD)
OUT SPCR,R17
LDI R18, (1<<SPI2X)
```

```
OUT SPSR,R18
.global spi_send
spi_send:
send:cbi PORTB,SPI_CS
ldi r19,0x04
out SPDR,r19
nop
nop
nop
ldi r20,0x00
wait: inc r20
cpi r20,0xFF
breg mend
rjmp wait
mend:sbi PORTB,2
ret
.end
```