
CONNECTORS
LIGHT SENSORS
NOISE SENSORS
SOLAR
BATTERY
CHARGER
BQ25798RQNR
STM32L476
NANO SIM
LDO
JLCJLCJLCJLC
SMS3.3.TCT
RESET1
RESET2
BOOT1
+3.3V
DBG
PSM1
H1
H2
H3
H4