← Week 3 Overview

Assignment 3: A Cricket

Logistics

Assigned: Wed, Sep 21

Due: Wed, Sep 28

1 The idea

- The idea
- The background
 - Spec sheets
 - The TMP36
 - Analog Reference
 - Arrays and averages
 - Filtering
- The assignment
 - The basic system
 - The filter
 - The cricket part
 - Guidelines
- The check-in
 - The rubric

Crickets chirp at a rate proportional to external temperature: you can calculate the temperature from the rate at which crickets chirp to within a degree or so. Of course you don't always have access to a cricket, What with today's rapidly moving world, it's come time to build a digital cricket, so that we may do what nature does more precisely and accurately.

2 The background


2.1 Spec sheets

Every electrical component has a **specification sheet** (a **spec** sheet). It lists everything you'd want to know about that component and then some. Your Arduino kits include the TMP36 temperature sensor.

Pages 1 and 3 of the spec sheet have all the information you need to complete this assignment.

2.2 The TMP36

The is fairly simply. When a voltage is provided across the two outer pins (in the right orientation), the center pin produces an output voltage based on the temperature.



You must wire the temperature sensor in the correct way or it will get hot. With the pins *facing* you and the flat end pointed up, the pin on the far left is power, and the pin on the far right is ground. Attach the power pin to +5V and the ground pin to ground.

The temperature sensor will burn you if you wire it incorrectly. Double dieck your connections before powering the Arduino.

The output voltage is independent of the supply voltage: it is a linear function of ambient temperature. At 25°C the TMP36 outputs a specific voltage (written in Table 1 on page 3 of the spec sheet) and as the temperature changes the output voltage changes based on a scale factor ($\frac{\pi V}{C}$, also in Table 1 of the spec sheet). You can use a linear equation to find out the temerature in Celsius using the measured voltage and these two values from the table.

For example, the table also provides data for another sensor, the TMP35. For the TMP35, the temperatire in Celsius .

is:

For TMP36 $T_{C} = 25^{\circ}C + (V_{measured} - .25V) \cdot 100^{\frac{1}{2}C}$ For TMP36 $T_{C} = 25^{\circ}C + (V_{measured} - .25V) \cdot 100^{\frac{1}{2}C}$ Simplify: $T_{C} = V_{measured} + 100 \text{ C/V} - 50 \text{ C}$

where τ_C is temperature in \cdot_C and $v_{measured}$ is the sensor voltage in volts (remember, $\frac{1}{V} = \frac{1000}{100} = \frac{mV}{V}$). Of course, the above could be simplified to just:

 $T_C = (V_{measured}) \cdot 100 \frac{^{\circ}C}{V}$

Using the data from table deriwe the equation for the TMP36.

2.3 Analog Reference

In order to read the temperature output by our sensor, you need to read the voltage into your Arduino. You have experience with analogRead() in an earlier assignment. Now, you will use analogRead() to read a voltage from the temperature sensor.

An analogRead() returns a number between 0 and 1023 that corresponds to a voltage. Usually, the 1023 corresponded to 5V. It turns out that this "upper limit voltage" can be changed. This reference voltage, on our Arduinos at least, can be one of two values: 5V OT LIV.

It's more appropriate to use LIV for the TMP36. Using the equation for the TMP36, LIV corresponds to 60°C (use this to verify your derivation of the equation from above). 60°C is well above the temperature of Wash U's classrooms. More importantly, using the lower reference voltage gives us more resolution which means it will give us a more accurate temperature, so it makes sense to use a lower reference voltage. That is, when we use the 50° reference: $\frac{5V}{1024 locks} \approx .005 \frac{V}{lock}$ whereas with the LIV reference: $\frac{11V}{1024 locks} \approx .001 \frac{V}{lock}$. So the LIV reference allos use to measure changes of about .001°. The one downside of the higher resolution is the inability to measure values greater than LIV, but we don't expect our sensor to measure temperatures that hot for this application (i.e., hoter than 60°C, which is 140°F; the crickets probably aren't accurate at those temperatures either).

Generally this reference should be configured in the setup(). You can use analogReference() to change the reference voltage to INTERNAL.

2.4 Arrays and averages

2.4.1 Filtering

The output from your temperature sensor fluctuates due to a variety of factors (including subtle air currents and "noise" in the sensor). In order to obtain a sensible, stable value from the sensor that represents the actual room tem-

perature we need to filter the output to remove these fluctuations

http://www.electronics-tutorials.ws/filter/filter_2.html

One option is to build physical hardware to filter: the RC filter is one such filter, and would do fairly nicely if this were an electical engineering class. But we want to handle this in software, so we will use a very simple, OK filter: a rolling average.

A rolling average filter determines the filtered value from the arithmetic mean of the N most recent measured values. In mathematical speak:

$$y_t = \frac{1}{N} \sum_{i=0}^{N-1} x_{t-i}$$

Where y_i is the filtered value at time t and x_i is the measured value at time t.

It's only possible to compute the rolling average if you store the N most recent data points, and the easiest way to do this is with an **array**.

3 The assignment

3.1 The basic system

1. Wire an LED output to the digital output pin of your choice (avoiding digital output pins 0 and 1), include a series resistor, and attach it to ground (this is the same as the discrete LEDs we wired in studio). Make sure you can turn it on and off.

2. Connect the center, output pin of your temperature sensor to an analog pin. Then attach the power pin to +5V and the ground pin to GND. If you hold the pins of your temperature sensor towards you and point the flat notch up, the power pin is on the left and the ground pin is on the right.

Make sure you can analogRead() from it, even if you haven't set analogReference() yet.

- 3. Write delta time code to read the temperature at 4 Hz (do a analogRead() 4 times a second). Test your work so far by using Serial.print() to display the value from analogRead().

 My test output:

 15~16 before set analogReference() to INTERNAL,

 74 ~ 80 after
- 4. Set analogReference() to INTERNAL. This will change what each value of analogRead() corresponds to (1023 will now correspond to LIV, not 5V), which will be important when you convert the data.
- 5. Convert the raw analogRead() value into a temperature. Mathematically this is a two step procedure, first converting the raw value into a voltage (i.e., understanding what voltage the temperature probe is generating given the A/D counts returned from analogRead()), then into a temperature from the spec sheet for the TMP36, or by using the equation you derived earlier.

Vmeasured = analogRead()*1.1V/1023 Temp = Vmeasured*100-50

While the counts returned by analogRead() are of type int, you likely will want to use variables of type float to perform the computation and store the resulting temperature value. Print out both the raw A/D counts and the converted temperature value until you are confident that your temperature is right.

Gently pinching the black plastic of the temperature sensor between your fingers should show an increasing temperature.

3.2 The filter

You should now be reading temperature several times per second and printing it out. However, it should be fluctuating because the raw signal is noisy.

Now we will will apply a simple **rolling average** filter to reduce the noise.

- 1. Define a constant at the top of your program called FILTER_COUNTS that specifies a number of values to store in the rolling average. A number between 5 and 10 should be reasonable.
- 2. Then create an array of size FILTER_COUNTS to store the N most recent data points (i.e., N equals FILTER_COUNTS). The simplest way to do this is by maintaining a count of the number of reads you do: whenever you read a temperature, save it to this array at index count % FILTER_COUNTS (i.e., the remainder when count is divided by FILTER_COUNTS).

For example:

```
#define FILTER_COUNTS 4
float temperatures[FILTER_COUNTS];
imt count = 0;

void loop() {
    if(/* delta time code */) {
        readTemp();
        /* more delta time stuff */
    }
}

void readTemp() {
    imt reading = analogRead(/* pin */);
    imt temperature = /* some transform on `reading` */;
    temperatures[count % FILTER_COUNTS] = temperature;
    counts += 1;
}
```

If you update the array each time you read the temperature, its mean is the rolling average.

- 3. Compute and print this rolling average alongside the raw (unfiltered) temperature. Is it more stable? Does it still respond to temperature changes?
- 4. Graph the temperature data (unfiltered and filtered) you get from your Arduino in your favorite graphing program. If you structure your output something like this, with commas separating each field of the data:

24.12,22.65 23.44,22.87 24.04,23.13 22.57,22.99 21.21,22.76

you can copy and paste your output into a text file, save it with the file extension .csv ("Comma Separated Values"), and open it directly in Excel.

Generate a noticeable change (increase) in temperature by holding the temperature sensor and then letting it go. Make sure to graph both the raw values and the filtered values. Also, double check your temperatures to make sure they're reasonable.

3.3 The cricket part

Now you can use the filtered temperature to make a blinking cricket.

1. Dolbear's Law is a formula to calculate the temperature from the amount of cricket chirps in 60 seconds:

$$T_C = 10 + \left(\frac{N_{60} - 40}{7}\right)$$

where r_C is the temperature in Celsius and r_{60} is the number of chirps in a minute

You can solve this in terms of chirps *per second*. By inverting it (1 / chirps per second) you get a period, *seconds per dirp*. If you convert this number into milliseconds per chirp, you can use this as the duration of a delta time iteration

to flash your LED. N = 7*(Tc - 10) + 40 = 7Tc - 30 chirps per minute that is, (7Tc-30)/60 chirps per second, (7Tc-30)/60000 chirps per millisecond

Solve this equation to determine a period, a number that you can use in a separate delta time conditional to flash a cricket LED.

invert it, get: timePeriod = 60000/(7Tc-30) milliseconds per chip BLINK_DURATION = (1/2) * timePeriod = 30000/(7Tc-30)

2. However, even with this number, flashing the LED is not that simple. You need to keep track of whether or not your LED is on (like with a boolean), and then alternate between *two* intervals for this "flash" delta time loop:

If the light is on, wait some time BLINK_DURATION, which should be around 200 milliseconds, then turn off, and

if the light is off, wait for period - BLINK_DURATION and turn back on.

Write the appropriate delta time code (separate from your temperature sampling code) to blink the LED based on temperature. Your program should now asynchronously measure temperature and output data to your PC while blinking the LED.

3. Make sure the blink rate is reasonable.


3.4 Guidelines


1. Make sure to wire the temperature sensor correctly or you will burn yourself.

The pins number from 1 to 3 left to right with the flat side up and the pins facing you.

- 1. Power
- 2. Output
- 3. Ground

Your final circuit should look like this:





Note that this picture has the LED connected to the Arduino pin and the resistor connected to ground. Either order is fine, Arduino pin then LED then resistor then ground, or Arduino pin then resistor then LED then ground.

2. Don't use delay() *at all* in this lab. We will *penalize* you if you do. The delta timing alternative we use is an important concept, and if it is not crystal clear, try reading some more about it and working through examples.

Adafruit has a nice tutorial, as does StackOverflow. Adafruit takes some code from the Arduino tutorial. Work through some problems, try to see if you can understand the idea in a generic form.

- 3. Save all your math work (conversions of voltage to temperature, Dolbear's law, etc). It will be helpful when your numbers aren't coming out right (trust me, they will be wrong the first time).
- 4. The easiest way to check your equations is by plugging in some test values: is the output sensible at 1V? 25 Celsius? Am I blinking at the right rate? Plug at least two values in to make sure everything's working.
- 5. Verify all your numbers again. Graph them. Are they changing as you hold your temperature sensor? Is the average within the range of the noise of your signal?

4 The check-in

1. Make sure your numbers make sense.

- 2. Commit all your code and graphs (make sure to add all the new files to your repo first).
- 3. Follow the checklist below to see if you have everything done before demo your assignment to a TA.
 - The temperature sensor is wired correctly (not burning)
 - analogReference() is set to INTERNAL
 - Temperature is converted properly from analogRead() (degree Celsius)
 - The filter for the rolling average tempertature is set up correctly
 - FILTER_COUNTS is chosen properly
 - The temperature data is clearly graphed and saved with a file (.csv)
 - The number of chirps in a minute is correctly computed by Dolbear's Law
 - Delta time for flashing the LED is chosen reasonably
 - No delay() is used
 - Your sketch flashes the LED properly
 - All of your files are committed
- 4. Assignment Demo



5. Check out with a TA.

```
New files:

assignments
assignment3/
cricket/cricket.ino
A graph of your temperature data (in Excel or something similar)
```

4.1 The rubric

- 100pts: Did the lab they demoed work?
 - Is the circuit wired correctly? (20 points)
 - Do they correctly read the temperature sensor? (15 points)
 - Do they correctly filter the data? (25 points)
 - Did they graph the data with a noticeable temperature change? (20 points)
 - Did they use proper delta-time loops? (20 points)

Generated at 2016-09-19 10:04:22 -0500.

Page written by Ben Stolovitz and Shuya Ma; Updated by Bill Siever. Site design by Ben Stolovitz.