



FLAG MOUNTING TEMPLATE

Alignment note: The top edge of the flag will align with the top edge of this template.



Hardware included:

1x 2.5 inch screw
2x 1.25 inch wall anchor screws
2x wall anchors

Hardware Needed:

Level
Screwdriver / Powered Screw Gun
Tape

Alignment note: the mounted flag will extend 16.9375" past the left edge of this template.

Scan this QR code for step-by-step mounting photos.

Alignment note: the mounted flag will extend 10.125" past the right edge of this template.

Poke through this hole to mark the screw location on the wall.

Holes are 10 inches apart

Poke through this hole to mark the screw location on the wall.

INSTRUCTIONS

- Choose the location on the wall where you would like to hang the flag.
- If you have a stud finder, locate a nearby wall stud and lightly mark its location.
- If you are able to use a stud, mount the French cleat using:
 - One wall anchor with the shorter 1.25" screw and one 2.5" screw into the stud.
- If you are not able to use a stud, mount the French cleat using:
 - Two wall anchors and two shorter 1.25" screws.
- Hold this template against the wall in the desired location.
- Use the offset measurements shown on the template to position the flag where you want it.
 - This helps make sure the flag will be centered properly and will not interfere with nearby walls, trim, etc.
- Place your level along the dotted line. Adjust template until the line is horizontal. Then tape template to wall.
- Mark both hole centers through the paper above to transfer the screw locations to the wall. Remove template.
 - If one hole location is going into a stud, predrill into the stud using a 1/8" drill bit or smaller.
 - For any hole location that does not land on a stud, install a wall anchor at the marked location.
 - Make sure each wall anchor is seated flush with the wall and is not protruding.
- Start each screw through the French cleat just so the tip slightly protrudes through the back side.
- Use the protruding screw tips to locate the marked holes or wall anchors, then press the cleat into position.
- For wall anchor locations, fasten the French cleat using the shorter 1.25" screws.
- For stud locations, fasten the cleat through the drywall into the stud using the 2.5" screw.
- Tighten both screws until snug. The cleat should sit flat and not wobble or shift. But do not overtighten.
- Once the French cleat is secured to the wall, hang the flag on the cleat and make sure it is fully seated.