# CSE 210: Computer Architecture Lecture 4: Introduction to MIPS

Stephen Checkoway

Oberlin College

Oct. 11, 2021

Slides from Cynthia Taylor

#### **Announcements**

Problem Set 1 due Friday at 11:59 pm

Office hours Tuesday 13:30 – 14:30

# Why you should learn (a little) assembly

Learn what your computer is fundamentally capable of

 By learning about how high level mechanisms are created in assembly, we learn what is fast, what is slow . . .

 Might use it for reverse engineering, embedded systems, compilers

#### The MIPS Instruction Set

- Used as the example throughout the book
- Stanford MIPS commercialized by MIPS Technologies (owned by John L. Hennessy, who wrote your book.)
- Used in Embedded Systems
  - Applications in consumer electronics, network/storage equipment, cameras, printers, ...
- Typical of many modern ISAs

# Three Types of Instruction

• Arithmetic (R)

• Immediate (I)

• Jump (J)

## Arithmetic and Logical Operations

- Add and subtract, three operands
  - Two sources and one destination

```
add a, b, c # a = b + c
sub a, b, c # a = b - c
and a, b, c # a = b & c (bit-wise AND)
```

All arithmetic and logical operations have this form

# Convert to MIPS: f = (g + h) - (i + j);

```
A. add f, g, h sub f, i, j
```

D. More than one of these is correct

## Register Operands

- Arithmetic instructions use register operands
- MIPS has a 32 × 32-bit register file
  - Numbered 0 to 31
  - 32-bit data called a "word"

## Aside: MIPS Register Convention

Name	Register Number	Usage
\$zero	0	constant 0 (hardware)
\$at	1	reserved for assembler
\$v0 - \$v1	2-3	returned values
\$a0 - \$a3	4-7	arguments
\$t0 - \$t7	8-15	temporaries
\$s0 - \$s7	16-23	saved values
\$t8 - \$t9	24-25	temporaries
\$gp	28	global pointer
\$sp	29	stack pointer
\$fp	30	frame pointer
\$ra	31	return addr (hardware)

### Register Operand Example

• C code:

```
f = (g + h) - (i + j);
-f, ..., j in $s0, ..., $s4
```

Compiled MIPS code:

```
add $t0, $s1, $s2
add $t1, $s3, $s4
sub $s0, $t0, $t1
```

## Questions about Arithmetic Operations?

#### Memory Instructions

```
• lw $t0, 0(\$t1)
-$t0 = Mem[\$t1+0]
```

• sw 
$$$t0, 0($t1)$$
  
-Mem[ $$t1+0$ ] =  $$t0$ 

 These instructions are the cornerstones of our being able to go to and from memory

#### Accessing the Operands

There are typically two locations for operands – registers (internal storage - \$t0, \$a0) and memory. In each column we have which - reg or mem - is better. Which row is correct?

	Faster access	Fewer bits to specify address	More locations
Α	Mem	Mem	Reg
В	Mem	Reg	Mem
С	Reg	Mem	Reg
D	Reg	Reg	Mem
Е	None of the above		

#### Load-store architectures

can do: can't do add r1=r2+r3 add r1=r2+M(address) and load r3, M(address)

- ⇒ forces heavy dependence on registers, which is exactly what you want in today's CPUs
- more instructions
- + fast implementation

## Memory Operands

- Main memory used for composite data
  - Arrays, structures, dynamic data
- Memory is byte addressed
  - Each address identifies an 8-bit byte
- Words are aligned in memory
  - Address of a word must be a multiple of 4

#### **Memory Organization**

- Viewed as a large, single-dimension array, with an address.
- A memory address is an index into the array
- "Byte Addressing" means that the index points to a byte of memory.

8 bits of data

• • •

### **Memory Organization**

- Bytes are nice, but most data items use larger "words"
- For MIPS, a word is 32 bits or 4 bytes.

0	32 bits of data
4	32 bits of data
8	32 bits of data
12	32 bits of data

Registers hold 32 bits of data

- 2<sup>32</sup> bytes with byte addresses from 0 to 2<sup>32</sup> 1
- $2^{30}$  words with byte addresses 0, 4, 8, ...  $2^{32}$  4

Processor X is 8 bit **byte-addressable**. If you have a pointer at address 0000 0000 0000 1000 and you increment it by one (0000 0000 0000 1001). What does the new pointer (0000 0000 0000 1001) point to, relative to the original pointer (0000 0000 0000 1000)?

- A) The next word in memory
- B) The next byte in memory
- C) Either the next word or byte depends on if you use that address for a load byte or load word
- D) Pointers are a high level construct they don't make sense pointing to raw memory addresses.
- E) None of the above.

Processor Y is 32 bit word-addressable. If you have a pointer at address 00 0000 0000 1000 and you increment it by one (00 0000 0000 1001). What does the new pointer (00 0000 0000 1001) point to, relative to the original pointer (00 0000 0000 1000)?

- A) The next word in memory
- B) The next byte in memory
- C) Either the next word or byte depends on if you use that address for a load byte or load word
- D) Pointers are a high level construct they don't make sense pointing to raw memory addresses.
- E) None of the above.

# Reading

Next lecture: Assembly

-2.3

Problem Set 1: Due Friday at 11:59pm via gradescope