















A1200 keyboard FFC <-> DB37 adapter. One board design for both ends; join two with a straight-through DB37 male-male cable.

FFC pin n -> DB37 pin (n+1)/2 for odd n, 19+n/2 for even n. DB17 DISK, DB18 FLOPPY, DB19 PWRLED, DB35-37 GND.

Amiga-side board: fit D1-D34 and close JP1 (shell to GND). Keyboard-side board: D1-D34 optional, leave JP1 open.

GND only exists via J2 (from the A1200 LED header); the FFC carries no ground.

J4: 3.5in floppy power from the PSU, Amiga-side board only. Only the two GND pins are used, so a reversed plug never lands +12V on anything.

Sheet: /
File: A1200KB-DB37.kicad_sch

Title: A1200 keyboard FFC to DB37 adapter

Size: A3	Date:	Rev: 1
KiCad E.D.A. 10.0.1		Id: 1/1