Loading project into Fusion 360

- 1. Create a new folder in Fusion 360 and navigate there
- 2. Click the "Upload: button and select the Assembly v13.f3z file from this download 3. After import, open the Assembly file and all parts should be present and aligned properly.