



Your Construction Runner app

A simple guide for operatives and anyone who uses the phone app on site.

Version 1.0 · September 2026

iPhone and Android · Construction Runner

Support: info@construction-runner.com

This guide is for you

If you work on site, this is the app you use every day. You do **not** log in on the website – the Construction Runner app on your phone is where you sign in, complete induction, read RAMS and briefings, and finish your tasks.

Keep this on your phone or print it. Ask your supervisor if you get stuck.

What you need to do

First time on the app

1. Install **Construction Runner** from the App Store or Google Play.
2. Sign in (or Register with your company invite code), then wait until your administrator approves you.
3. Set Location to **Always** (iPhone) or **Allow all the time** (Android).
4. Open Profile → **My Inductions** and complete induction for your site.
5. Add an emergency contact under Profile → **My Info**.

Every day on site

1. Home → **Check In / Out** → pick your site → stand inside the boundary → **Sign In**.
2. Open **Safety** and acknowledge any new briefings or RAMS (**Sign & acknowledge**).
3. Do your **Tasks**. Use Deliveries / Assets / Messages if you need them.
4. When you leave, tap **Sign Out** – or walk out of the site fence and the app will sign you out.

1. Get the app and sign in

1. Search **Construction Runner** on the App Store (iPhone) or Google Play (Android) and install it.
2. Open the app. Enter your work email and password, then tap **Sign In**.
3. Optional: tick **Remember me**. You can also turn on Face ID later in Settings.
4. New? Tap **New user? Register here**. Enter Full Name, Company invite code (from your supervisor), and a password, then **Register**.

Waiting for approval. After you register you will see that your administrator must approve you. You cannot Sign In on site until they do. Ask your supervisor if it takes too long.

Forgot Password? On the sign-in screen tap Forgot Password?, enter your email, tap Send, then use the link in your email.




Figure 1. Sign in to Construction Runner. Register here if you are new – you still need approval before you can use the app.

2. Turn location to Always (do this once)

The app only uses location to know when you are inside the site and when you leave. It does not track you around town or keep a location history.

The first time you Check In, you will see **Always location required** (iPhone) or **Allow all the time required** (Android). Tap **Continue**.

Phone	What to tap
iPhone	First: Allow While Using the App . Then: Change to Always Allow . In Settings → Construction Runner → Location, it must say Always .
Android	Settings → Permissions → Location → Allow all the time .

While Using or **Allow Once** is not enough. The app cannot sign you out after you leave site, so Sign In stays locked until location is Always / Allow all the time.




Figure 2. Allow Always location so you are never left signed in after you leave site.

3. The Home screen


After you are in, you land on **Home**. Across the bottom you have six tabs:

Home · Safety · Deliveries · Assets · Messages · Tasks

The **...** menu (top right on most screens) has Profile, Settings, Help and Sign Out.

On Home you will see if you are Signed in, Signed out, or Absent today. Tap:

- **Check In / Out** – Sign in or out at your site
- **My Tasks** – work assigned to you
- **Briefings** – toolbox talks waiting for your signature



Construction Runner app

Operatives work from the mobile app on iPhone and Android. Web login for operatives is not available — the app is the daily tool for attendance, safety and site work.


- Six tabs: Home, Safety, Deliveries, Assets, Messages, Tasks
- Profile menu: My Inductions, My Info, Settings
- Works offline for some lists; sign-in needs a live location

Figure 3. Home – start Check In / Out from here. (Illustrated layout; labels match the live app.)

4. Sign in when you arrive

1. Home → **Check In / Out**.
2. Tap the **Select site** pill at the top and choose today's site.
3. Wait until the map says **Inside Site Boundary**. If it says Outside, walk onto the site and tap Refresh location (in ●●●).
4. If the site needs induction and you have not done it, complete **Site induction** then tap **Complete induction**.
5. If RAMS appear, tap **Accept & Sign In**.
6. Tap **Sign In**. Wait for "Signing you in, please wait..."

You must be **inside the blue boundary** to Sign In. You cannot check in from the van park if that is outside the geofence.



Check In / Out

Open Home → Check In / Out. Choose the site, wait until the map shows you are inside the blue boundary, then tap Sign In.

1. Set Location to **Always** (iPhone) or **Allow all the time** (Android).
2. Complete site induction if the site requires it.
3. Accept RAMS, then Sign In.
4. Leaving the geofence signs you out automatically.

Figure 4. Check In / Out. Stand inside the site boundary, then Sign In.

Sign out when you leave

- Open Check In / Out and tap **Sign Out**, or
- Walk out of the site fence – you should be signed out automatically (“You left the site – signed out automatically”).

If you have no signal, Sign Out can wait and sync later. Do not stay “signed in” overnight if you have left site.

Need a day off the site? Use **Mark as absent / Lock this day** (this locks sign-in until midnight GMT).


5. Induction for each site

Open **...** → Profile → **My Inductions**. This is how you start induction on a new site (for example if you move from one job to another).

- **Not Started** – tap **Start Induction**
- **Completed** – you are good (it lasts 365 days)
- **Expired** – do it again

Induction steps: Read site safety information → Acknowledge RAMS and risk assessments → Confirm you understand site rules → **Complete induction**.

If the site has induction required, you cannot finish Sign In until induction is Completed.



My Inductions

Profile → My Inductions is how someone starts induction on a new site. Statuses: Not Started, Completed, Expired (365 days from completion).


If a site has induction required, Check In will send them through Site induction before they can Sign In.

Figure 5. My Inductions – start induction here for any company site.

6. Safety – what you must open on site

Tap the **Safety** tab (hard-hat icon). Work through anything new:


Open this	What you do
Briefings	Read toolbox talks under To acknowledge. Sign, then tap Sign & acknowledge .
RAMS Documents	Read risk assessments. Acknowledge the same way. You may also accept RAMS during Sign In.
Site Rules	Read PPE, emergency and conduct rules. You can Save as favourite.
Safety checklist	Complete today's checks if your site uses them.
Alerts	Open new alerts – they are marked read when you open them.
Near Miss Reports	If something almost went wrong: New report → fill in → photos (Camera or gallery) → Submit Report .
COSHH	Look up hazardous substances and PPE.



Safety tab

This is your site safety folder. Open it every day after you Sign In. Acknowledge new briefings and RAMS, read site rules, and report a near miss if something almost went wrong.

Figure 6. Safety tab – briefings, RAMS, rules, alerts and near miss.



Acknowledge briefings & RAMS

Safety → Briefings (or RAMS Documents). Anything under **To acknowledge** is waiting for you. Open it, read it, sign, then tap **Sign & acknowledge**.

You may also be asked to accept RAMS as part of Sign In (RA/MS Acceptance → Accept & Sign In).

Figure 7. Anything under To acknowledge is waiting for your signature.

Create Near Miss Report

What happened

Cable tray almost struck operative when being lifted...

Where

Kidbrooke Village — Level 3

Photos

Camera or gallery

Submit Report

Home Safety Deliveries Assets Messages Tasks

Report a near miss


Safety → Near Miss Reports → New report. Fill in what happened, add photos from Camera or gallery, then tap **Submit Report**.

If you are offline, the report can wait and sync when you have signal.

Figure 8. Near miss – Submit Report. It can sync later if you have no signal.

7. Tasks, deliveries, assets, messages

- **Tasks** – work for you. Tap a task and set **Open**, **In progress** or **Done**. You can also open My Tasks from Home.
- **Deliveries** – New delivery, add Proof of delivery and Picture of load, then **Submit delivery**.
- **Assets** (My Assets) – kit assigned to you. View & add images, Report inspection, Close inspection.
- **Messages** – conversations with your supervisors. Tap the send icon to reply.



Tasks, deliveries, messages

The **Tasks** tab lists work assigned to you. Tap a task and set it to Open, In progress or Done.


Deliveries — submit a delivery with proof photos. **Assets** — kit assigned to you and inspections. **Messages** — talks with your supervisors.

Figure 9. Tasks – mark Open, In progress or Done.

8. Your profile

☰ → Profile

- **Personal Info** – name and photo. Save personal info.
- **My Info** – emergency contact, medical, competency card, declarations. You can Sign In without this, but fill it in so the site can reach someone if you are hurt.
- **My Inductions** – start or renew site induction.
- **User Settings** – Dark Mode, Face ID, notifications, password, language, Download My Data, Sign Out.



Profile and My Info

Open the ... menu and tap Profile. Keep Personal Info and My Info up to date — especially emergency contact and medical notes. This is not a gate for Sign In, but your supervisor needs it if something happens on site.

My Inductions is in the same menu. Settings has Face ID, notifications, language and Sign Out.

Figure 10. Profile – My Info and My Inductions live here.

9. If you are offline

- You need internet the first time you Sign In to the app.
- After that, some lists still open with no signal (they may be out of date). Pull to refresh when you are back online.
- Sign Out and near-miss reports can wait in a queue and sync later.
- Check In still needs a live location and a connection to finish.

10. Supervisors using the app

If you are a supervisor you use the same Check In, Safety and Tasks. You also get **Supervisor Tools** on Home (a drawer) and you can add a task with the + button. Site lists follow the sites your Super Admin ticked for you.

If something is not working

What you see	What to do
Pending approval / cannot Sign In after register	Ask your supervisor to approve you in Pending approvals.
Sign In stays locked / needs Always	iPhone: Location = Always. Android: Allow all the time. Then return to the app.
Outside Site Boundary	Walk onto the site. Refresh location. You cannot Sign In from outside the fence.
Asked to complete induction	Finish Site induction, or Profile → My Inductions → Start Induction.
Did not auto sign out	Location is probably still While Using. Change to Always, then Sign Out manually this time.
You're offline	Use Wi-Fi or mobile data for Check In. Other items may sync when you have signal.
Forgot password	Forgot Password? on the sign-in screen.

Need help? Ask your supervisor, or email info@construction-runner.com.

Construction Runner App Guide v1.0 – September 2026. For people who use the phone app. Figures are illustrated layouts that match live button names.