AVAPS Drop Log

Project: ARR2021 Mission: TRANSIT 2 Flight ID: 20210119N2

Take Off: _____ Landing: _____ Flt Dir: HENNINGER COUNTRY Launcher S/N: 02

Drop #	Sonde Serial #	Rcvr #	Press Offset	Launch Time	Operator	Charge $$ To	Comments	Good ?
1	203240123	1	Ø	0116	SCP	AOC		
2								
3								
4								
5								
6								
7								
8								
9								
10								
11								
12								
13								
14								
15								
16								
17								
18								
19								
20								
21								
22								
23								
24								
25								
26								
27								
28								
29								
30								
31								

Drop #	Sonde Serial #	Rcvr #	Press Offset	Launch Time	Operator	Charge $$ To	Comments	Good ?
32								
33								
34								
35								
36								
37								
38								
39								
40								
41								
42								
43								
44								
45								
46								
47								
48								
49								
50								

Drop Station Operator Notes

Charge $$ To Options (DO NOT USE FUNDING CODES):
AOC, NWS, HRD, NESDIS, IR/SST, AR, STAN (Stanford), SAT (JPSS/NESDIS/HRD)

AVAPS Pre-Flight Check:

- If time-permits, verify cabin pressure sensor w/ lab standard
- Start AVAPS., then start Soundings and set the Project Name and Full Flight ID (example: 20120823N2).
- Verify the Frequency band allocation as required:
  Band A: 53rd WRS - Band B: N42RF - Band C: N43RF - Band D: N49RF - Band E: Unallocated
- Select the **GPS Reference** tab from the **Soundings Displays** page and verify good GPS data
- Perform a prelaunch check on each channel, look for reasonable data and no CRC error status lights.
- Verify data is available on Remote AVAPS, then terminate the sonde.
- Verify the AVAPS Data mission folder has been created
- Verify AVAPS PC Time is correct – if time is off by >4sec, no data will display
- Early launch detects are caused usually by remanufactured sondes with the chute riser line not properly coiled below the PCB ear. This may also cause fast falls. If this is suspected, repack the riser line as time permits
- Perform RH Regeneration on all sondes – Multiple RD41 sondes may be processed at once

AVAPS Launch:

- Select a sonde frequency in the Green band and away from other sondes
- Enter sonde pressure error offset if 0.4mB or greater using cabin pressure sensor – warning, this can not be used during a climb
- If the Cal lab pressure standard and the cabin pressure standard match, apply pressure offset +/- 0.1 mB
- Wait until GPS available (green) on the pre-launch screen before continuing.
- Select "begin data collection" and verify good data with winds prior to putting sonde in launch tube
- On N42 & N43, remove about ½ of the ribbon. Do not shorten the ribbon on N49. Loosen ribbon and extend end of ribbon to near, but not over, the sensor end of the sonde. Place excess orange tape on end of ribbon to form a pocket.
- Place the sonde in the launch tube, sensor arm up, with the power pin socket facing right
- Verify the sonde is actively tracking GPS data prior to launch and no early launch detect

AVAPS Drop Log

30/35

3 FF
1 late LD
1 no LD
1 bad H
1 bad TH

Project: ~~[illegible]~~ ARR 21 Mission: AAR #1 Flight ID: 202/01/22N1

Take Off: _____ Landing: _____ Flt Dir: Hemme Lundry Launcher S/N: [illegible]

Drop #	Sonde Serial #	Rcvr #	Press Offset	Launch Time	Operator	Charge $$ To	Comments	Good ?
1	203 540 050	1	Ø	2228	SCP	AR		✓
2	203 440 051	2	Ø	2237				✓
3	203 310 168	3	Ø	2247				✓
4	202 730 018	4	Ø	2257				✓
5	203 440 052	1	Ø	2307			fast fall	X
6	203 540 049	2	Ø	2309			backup for 5	✓
7	203 540 092	3	-0.6	2317				✓
8	203 431 818	4	Ø	2327				✓
9	203 210 057	1	Ø	2337			fast fall	X
10	203 540 052	2	Ø	2338			backup for 9	✓
11	203 210 059	3	Ø	2347				✓
12	203 540 046	4	Ø	2357				✓
13	203 150 503	1	Ø	0007				✓
14	201 651 035	2	Ø	0018				✓
15	203 431 815	3	Ø	0029				✓
16	203 440 022	4	Ø	0040				✓
17	203 540 081	1	Ø	0051				✓
18	202 730 059	2	Ø	0104			late launch detect	X
19	202 730 115	3	Ø	0104			backup for 18	✓
20	203 431 786	4	Ø	0114				✓
21	203 540 100	1	Ø	0121				✓
22	203 431 811	2	Ø	0129				✓
23	203 431 817	3	Ø	0137				✓
24	203 520 218	4	Ø	0146				✓
25	203 210 058	1	Ø	0154				✓
26	202 311 637	2	Ø	0202				✓
27	202 311 596	3	-0.8	0211				✓
28	203 240 573	4	Ø	0219				✓
* 29	201 651 022	1	Ø	0229				✓
30	203 240 574	2	Ø	0237			~~[illegible]~~ No LD	X
31	203 431 766	3	Ø	0239			fast fall	X

might have marked as 30 - no launch detect
should be 29 - good
[illegible] had to clear 30 [illegible] to make [illegible] room)

30 might also be marked as 29 good in comments?

Drop #	Sonde Serial #	Rcvr #	Press Offset	Launch Time	Operator	Charge $$ To	Comments	Good ?
32	201 520 287	4	Ø	0240	SCP	AR	Hu Fr 30	✓
33	201 520 297	2	Ø	246	|	|		✓
34	202 730 060	1	Ø	0256	|	|		✓
35	201 520 260	3	Ø	0304	|	|		✓
36								
37								
38								
39								
40								
41								
42								
43								
44								
45								
46								
47								
48								
49								
50								

Drop Station Operator Notes

Charge $$ To Options (DO NOT USE FUNDING CODES):
AOC, NWS, HRD, NESDIS, IR/SST, AR, STAN (Stanford), SAT (JPSS/NESDIS/HRD)

AVAPS Pre-Flight Check:

- If time-permits, verify cabin pressure sensor w/ lab standard
- Start AVAPS., then start Soundings and set the Project Name and Full Flight ID (example: 20120823N2).
- Verify the Frequency band allocation as required:
  Band A: 53rd WRS - Band B: N42RF - Band C: N43RF - Band D: N49RF - Band E: Unallocated
- Select the **GPS Reference** tab from the **Soundings Displays** page and verify good GPS data
- Perform a prelaunch check on each channel, look for reasonable data and no CRC error status lights.
- Verify data is available on Remote AVAPS, then terminate the sonde.
- Verify the AVAPS Data mission folder has been created
- Verify AVAPS PC Time is correct – if time is off by >4sec, no data will display
- Early launch detects are caused usually by remanufactured sondes with the chute riser line not properly coiled below the PCB ear. This may also cause fast falls. If this is suspected, repack the riser line as time permits
- Perform RH Regeneration on all sondes – Multiple RD41 sondes may be processed at once

AVAPS Launch:

- Select a sonde frequency in the Green band and away from other sondes
- Enter sonde pressure error offset if 0.4mB or greater using cabin pressure sensor – warning, this can not be used during a climb
- If the Cal lab pressure standard and the cabin pressure standard match, apply pressure offset +/- 0.1 mB
- Wait until GPS available (green) on the pre-launch screen before continuing.
- Select "begin data collection" and verify good data with winds prior to putting sonde in launch tube
- On N42 & N43, remove about ½ of the ribbon. Do not shorten the ribbon on N49. Loosen ribbon and extend end of ribbon to near, but not over, the sensor end of the sonde. Place excess orange tape on end of ribbon to form a pocket.
- Place the sonde in the launch tube, sensor arm up, with the power pin socket facing right
- Verify the sonde is actively tracking GPS data prior to launch and no early launch detect

AVAPS Drop Log

Project: AAR 21 Mission: 2 Flight ID: 20210123N1

Take Off: _____ Landing: _____ Flt Dir: RH/AL Launcher S/N: 02

30/33

1 fast

2 no LD

Drop #	Sonde Serial #	Rcvr #	Press Offset	Launch Time	Operator	Charge $$ To	Comments	Good ?
1	203 520 374	1	Ø	2134	SCP	AR		✓
2	203 530 372	2	Ø	2141				✓
3	203 520 375	3	Ø	2148			fast fall	X
4	203 520 384	4	Ø	2149			b/u for 3	✓
5	203 530 362	1	Ø	2156				✓
6	203 540 004	2	Ø	2204				✓
7	203 520 314	3	Ø	2212				✓
8	203 250 855	4	Ø	2219				✓
9	203 530 410	1	Ø	2228				✓
10	203 520 496	2	Ø	2236				✓
11	203 520 373	3	Ø	2245			fast / no LD	X
12	201 521 076	4	Ø	2246			b/u for 11	✓
13	202 730 074	1	Ø	2253				✓
14	203 540 080	2	Ø	2301				✓
15	202 730085	3	Ø	2310				✓
16	202 730 103	4	Ø	2323				✓
17	201 520 828	1	Ø	2337				✓
18	202 730 055	2	Ø	2349				✓
19	202 530 135	3	Ø	0002				✓
20	203 210 056	4	Ø	0014				✓
21	201 520 268	1	Ø	0026				✓
22	201 520 230	2	Ø	0032				✓
23	202730058	3	-0.4	0040				✓
24	201 651 038	4	Ø	0048				✓
25	203 240 579	1	Ø	0056			no LD	X
26	202 730 075	2	Ø	0057			b/u for 25	✓
27	203 310 561	3	Ø	0103				✓
28	203 540 076	4	Ø	0111				✓
29	202 720 944	1	Ø	0119				✓
30	203 240 572	2	Ø	0127				✓
31	203 520 494	3	Ø	0136				✓

85
85
70
20
50
33
17

23

Drop #	Sonde Serial #	Rcvr #	Press Offset	Launch Time	Operator	Charge $$ To	Comments	Good ?
32	203 540 045	4	Ø	0143	SCP	AR		✓
33	203 540 051	1	Ø	0151	SCP	AR		✓
34								
35								
36								
37								
38								
39								
40								
41								
42								
43								
44								
45								
46								
47								
48								
49								
50								

Drop Station Operator Notes

Charge $$ To Options (DO NOT USE FUNDING CODES):
AOC, NWS, HRD, NESDIS, IR/SST, AR, STAN (Stanford), SAT (JPSS/NESDIS/HRD)

AVAPS Pre-Flight Check:

- If time-permits, verify cabin pressure sensor w/ lab standard
- Start AVAPS., then start Soundings and set the Project Name and Full Flight ID (example: 20120823N2).
- Verify the Frequency band allocation as required:
  Band A: 53rd WRS - Band B: N42RF - Band C: N43RF - Band D: N49RF - Band E: Unallocated
- Select the **GPS Reference** tab from the **Soundings Displays** page and verify good GPS data
- Perform a prelaunch check on each channel, look for reasonable data and no CRC error status lights.
- Verify data is available on Remote AVAPS, then terminate the sonde.
- Verify the AVAPS Data mission folder has been created
- Verify AVAPS PC Time is correct – If time is off by >4sec, no data will display
- Early launch detects are caused usually by remanufactured sondes with the chute riser line not properly coiled below the PCB ear. This may also cause fast falls. If this is suspected, repack the riser line as time permits
- Perform RH Regeneration on all sondes – Multiple RD41 sondes may be processed at once

AVAPS Launch:

- Select a sonde frequency in the Green band and away from other sondes
- Enter sonde pressure error offset if 0.4mB or greater using cabin pressure sensor – warning, this can not be used during a climb
- If the Cal lab pressure standard and the cabin pressure standard match, apply pressure offset +/- 0.1 mB
- Wait until GPS available (green) on the pre-launch screen before continuing.
- Select "begin data collection" and verify good data with winds prior to putting sonde in launch tube
- On N42 & N43, remove about ½ of the ribbon. Do not shorten the ribbon on N49. Loosen ribbon and extend end of ribbon to near, but not over, the sensor end of the sonde. Place excess orange tape on end of ribbon to form a pocket.
- Place the sonde in the launch tube, sensor arm up, with the power pin socket facing right
- Verify the sonde is actively tracking GPS data prior to launch and no early launch detect

AVAPS Drop Log

Project: AAR21 Mission: 3 Flight ID:

Take Off: 1913Z Landing: Flt Dir: RH/AL Launcher S/N: 02

30/30

Drop #	Sonde Serial #	Rcvr #	Press Offset	Launch Time	Operator	Charge $$ To	Comments	Good ?
1	203 520 460	1	Ø	2030	SCP	AR		✓
2	203 530 366	2	Ø	2037				✓
3	203 431 754	3	Ø	2044				✓
4	203 530 361	4	Ø	2054				✓
5	203 520 498	1	Ø	2101				✓
6	204 120 595	2	Ø	2110				✓
7	203 530 472	3	Ø	2118				✓
8	203 440 032	4	Ø	2127				✓
9	203 431 754	1	Ø	2135				✓
10	203 540 003	2	Ø	2144				✓
11	203 520 493	3	Ø	2152				✓
12	203 540 072	4	Ø	2200				✓
13	203 520 380	1	Ø	2208				✓
14	203 520 379	2	Ø	2216				✓
15	202 730 051	3	Ø	2224				✓
16	202 730 078	4	-0.4	2233				✓
17	202 730 077	1	-0.4	2240				✓
18	203 440 050	2	Ø	2248				✓
19	202 730 054	3	Ø	2256				✓
20	203 440 066	4	Ø	2303				✓
21	203 520 376	1	Ø	2311				✓
22	202 730 083	2	Ø	2318				✓
23	201 520 267	3	Ø	2326				✓
24	202 740 676	4	Ø	2332				✓
25	202 721 651	1	Ø	2340				✓
26	202 740 677	2	Ø	2350				✓
27	203 431 770	3	Ø	0000				✓
28	202 721 627	4	Ø	0009				✓
29	202 910 362	1	Ø	0020				✓
30	202 740 678	2	Ø	0029				✓
31								

Drop #	Sonde Serial #	Rcvr #	Press Offset	Launch Time	Operator	Charge $$ To	Comments	Good ?
32								
33								
34								
35								
36								
37								
38								
39								
40								
41								
42								
43								
44								
45								
46								
47								
48								
49								
50								

Drop Station Operator Notes

Charge $$ To Options (DO NOT USE FUNDING CODES):
AOC, NWS, HRD, NESDIS, IR/SST, AR, STAN (Stanford), SAT (JPSS/NESDIS/HRD)

AVAPS Pre-Flight Check:

- If time-permits, verify cabin pressure sensor w/ lab standard
- Start AVAPS., then start Soundings and set the Project Name and Full Flight ID (example: 20120823N2).
- Verify the Frequency band allocation as required:
  Band A: 53rd WRS - Band B: N42RF - Band C: N43RF - Band D: N49RF - Band E: Unallocated
- Select the **GPS Reference** tab from the **Soundings Displays** page and verify good GPS data
- Perform a prelaunch check on each channel, look for reasonable data and no CRC error status lights.
- Verify data is available on Remote AVAPS, then terminate the sonde.
- Verify the AVAPS Data mission folder has been created
- Verify AVAPS PC Time is correct – if time is off by >4sec, no data will display
- Early launch detects are caused usually by remanufactured sondes with the chute riser line not properly coiled below the PCB ear. This may also cause fast falls. If this is suspected, repack the riser line as time permits
- Perform RH Regeneration on all sondes – Multiple RD41 sondes may be processed at once

AVAPS Launch:

- Select a sonde frequency in the Green band and away from other sondes
- Enter sonde pressure error offset if 0.4mB or greater using cabin pressure sensor – warning, this can not be used during a climb
- If the Cal lab pressure standard and the cabin pressure standard match, apply pressure offset +/- 0.1 mB
- Wait until GPS available (green) on the pre-launch screen before continuing.
- Select "begin data collection" and verify good data with winds prior to putting sonde in launch tube
- On N42 & N43, remove about ½ of the ribbon. Do not shorten the ribbon on N49. Loosen ribbon and extend end of ribbon to near, but not over, the sensor end of the sonde. Place excess orange tape on end of ribbon to form a pocket.
- Place the sonde in the launch tube, sensor arm up, with the power pin socket facing right
- Verify the sonde is actively tracking GPS data prior to launch and no early launch detect

AVAPS Drop Log

Project: ARR 21 Mission: 4 Flight ID: 20210125N1

Take Off: _____ Landing: _____ Flt Dir: RH/AL Launcher S/N: _____

19/22

2 FF
1 no LD

Drop #	Sonde Serial #	Rcvr #	Press Offset	Launch Time	Operator	Charge $$ To	Comments	Good ?
1	204 140 951	1	Ø	2146	SCP	AR		✓
2	202 910 370	2	Ø	2152				✓
3	203 431 753	3	Ø	2158				✓
4	202 910 364	4	Ø	2205				✓
5	202 730 079	1	Ø	2211				✓
6	202 910 389	2	Ø	2218				✓
7	201 520 295	3	Ø	2225				✓
8	202 721 623	4	Ø	2232				✓
9	203 540 074	1	Ø	2239			no LD	X
10	202 910 387	2	Ø	2241			b/u for 9	✓
11	203 520 382	3	Ø	2245				✓
12	202 910 372	4	Ø	2251				✓
13	202910 417	1	Ø	2257				✓
14	203 520 508	2	Ø	2304				✓
15	203431 781	3	Ø	2311				✓
16	202 910 371	4	Ø	2319			late LD/FF,	X
17	203520 507	1	Ø	2319			FF, b/u for 16	X
18	203 520 506	2	Ø	2322			b/u for 17	✓
19	203 530 469	4	Ø	2327			late LD	✓
20	203 520 176	1	Ø	2332				✓
21	202721318	3	Ø	2339				✓
22	203 520 495	2	Ø	2346				✓
23								
24								
25								
26								
27								
28								
29								
30								
31								

Drop #	Sonde Serial #	Rcvr #	Press Offset	Launch Time	Operator	Charge $$ To	Comments	Good ?
32								
33								
34								
35								
36								
37								
38								
39								
40								
41								
42								
43								
44								
45								
46								
47								
48								
49								
50								

Drop Station Operator Notes

Charge $$ To Options (DO NOT USE FUNDING CODES):
AOC, NWS, HRD, NESDIS, IR/SST, AR, STAN (Stanford), SAT (JPSS/NESDIS/HRD)

AVAPS Pre-Flight Check:

- If time-permits, verify cabin pressure sensor w/ lab standard
- Start AVAPS., then start Soundings and set the Project Name and Full Flight ID (example: 20120823N2).
- Verify the Frequency band allocation as required:
  Band A: 53rd WRS - Band B: N42RF - Band C: N43RF - Band D: N49RF - Band E: Unallocated
- Select the **GPS Reference** tab from the **Soundings Displays** page and verify good GPS data
- Perform a prelaunch check on each channel, look for reasonable data and no CRC error status lights.
- Verify data is available on Remote AVAPS, then terminate the sonde.
- Verify the AVAPS Data mission folder has been created
- Verify AVAPS PC Time is correct – if time is off by >4sec, no data will display
- Early launch detects are caused usually by remanufactured sondes with the chute riser line not properly coiled below the PCB ear. This may also cause fast falls. If this is suspected, repack the riser line as time permits
- Perform RH Regeneration on all sondes – Multiple RD41 sondes may be processed at once

AVAPS Launch:

- Select a sonde frequency in the Green band and away from other sondes
- Enter sonde pressure error offset if 0.4mB or greater using cabin pressure sensor – warning, this can not be used during a climb
- If the Cal lab pressure standard and the cabin pressure standard match, apply pressure offset +/- 0.1 mB
- Wait until GPS available (green) on the pre-launch screen before continuing.
- Select "begin data collection" and verify good data with winds prior to putting sonde in launch tube
- On N42 & N43, remove about ½ of the ribbon. Do not shorten the ribbon on N49. Loosen ribbon and extend end of ribbon to near, but not over, the sensor end of the sonde. Place excess orange tape on end of ribbon to form a pocket.
- Place the sonde in the launch tube, sensor arm up, with the power pin socket facing right
- Verify the sonde is actively tracking GPS data prior to launch and no early launch detect

AVAPS Drop Log

Project: ARR 21 Mission: 5 Flight ID: 20210126N1

Take Off: _____ Landing: _____ Flt Dir: AL/RH Launcher S/N: _____

30/31

1 no LD

Drop #	Sonde Serial #	Rcvr #	Press Offset	Launch Time	Operator	Charge $$ To	Comments	Good ?
1	202 721 317	1	Ø	2100	SCP	AR		✓
2	203 520 315	2	Ø	2108				✓
3	203 420 234	3	Ø	2116				✓
4	203 350 276	4	Ø	2124			no LD	X
5	203 350 273	1	Ø	2125			b/u for 4	✓
6	203 210 178	2	Ø	2132				✓
7	203 420 272	3	Ø	2139				✓
8	203 420 302	4	Ø	2147				✓
9	203 420 230	1	Ø	2155				✓
10	203 350 264	2	Ø	2202				✓
11	203 320 223	3	Ø	2210				✓
12	203 420 267	4	Ø	2217				✓
13	202 910 354	1	Ø	2226				✓
14	202 910 368	2	Ø	2231				✓
15	203 830 646	3	Ø	2238				✓
16	202 910 367	4	Ø	2243				✓
17	203 540 098	1	Ø	2249				✓
18	201 520 231	2	Ø	2256				✓
19	202910 415	3	Ø	2302				✓
20	203 830 644	4	Ø	2309				✓
21	202 721 656	1	Ø	2316				✓
22	202 730 056	2	-0.4	2323				✓
23	202 910 373	3	Ø	2330				✓
24	202 830 390	4	Ø	2337				✓
25	202 830 386	1	Ø	2345				✓
26	203 530 471	2	Ø	2353				✓
27	203 830 645	3	Ø	0000				✓
28	203 510 318	4	Ø	0007				✓
29	203 240 577	1	Ø	0015				✓
30	203 451 402	2	Ø	0023				✓
31	203 830 650	3	Ø	0032				✓

Drop #	Sonde Serial #	Rcvr #	Press Offset	Launch Time	Operator	Charge $$ To	Comments	Good ?
32								
33								
34								
35								
36								
37								
38								
39								
40								
41								
42								
43								
44								
45								
46								
47								
48								
49								
50								

Drop Station Operator Notes

Charge $$ To Options (DO NOT USE FUNDING CODES):
AOC, NWS, HRD, NESDIS, IR/SST, AR, STAN (Stanford), SAT (JPSS/NESDIS/HRD)

AVAPS Pre-Flight Check:

- If time-permits, verify cabin pressure sensor w/ lab standard
- Start AVAPS., then start Soundings and set the Project Name and Full Flight ID (example: 20120823N2).
- Verify the Frequency band allocation as required:
  Band A: 53rd WRS - Band B: N42RF - Band C: N43RF - Band D: N49RF - Band E: Unallocated
- Select the **GPS Reference** tab from the **Soundings Displays** page and verify good GPS data
- Perform a prelaunch check on each channel, look for reasonable data and no CRC error status lights.
- Verify data is available on Remote AVAPS, then terminate the sonde.
- Verify the AVAPS Data mission folder has been created
- Verify AVAPS PC Time is correct – if time is off by >4sec, no data will display
- Early launch detects are caused usually by remanufactured sondes with the chute riser line not properly coiled below the PCB ear. This may also cause fast falls. If this is suspected, repack the riser line as time permits
- Perform RH Regeneration on all sondes – Multiple RD41 sondes may be processed at once

AVAPS Launch:

- Select a sonde frequency in the Green band and away from other sondes
- Enter sonde pressure error offset if 0.4mB or greater using cabin pressure sensor – warning, this can not be used during a climb
- If the Cal lab pressure standard and the cabin pressure standard match, apply pressure offset +/- 0.1 mB
- Wait until GPS available (green) on the pre-launch screen before continuing.
- Select "begin data collection" and verify good data with winds prior to putting sonde in launch tube
- On N42 & N43, remove about ½ of the ribbon. Do not shorten the ribbon on N49. Loosen ribbon and extend end of ribbon to near, but not over, the sensor end of the sonde. Place excess orange tape on end of ribbon to form a pocket.
- Place the sonde in the launch tube, sensor arm up, with the power pin socket facing right
- Verify the sonde is actively tracking GPS data prior to launch and no early launch detect

AVAPS Drop Log

Project: ARR21 Mission: 6 Flight ID: 20210127N1

Take Off: _____ Landing: _____ Flt Dir: RH/AL Launcher S/N: 02

22/23

1 no LD/FF

Drop #	Sonde Serial #	Rcvr #	Press Offset	Launch Time	Operator	Charge $$ To	Comments	Good ?
1	201651052	1	Ø	2137	SCP	AR		✓
2	202720649	2	Ø	2144				✓
3	202730093	3	Ø	2152				✓
4	202730084	4	Ø	2200				✓
5	202721725	1	Ø	2208				✓
6	202 730 094	2	Ø	2216				✓
7	202 740 673	3	Ø	2224				✓
8	202 720 652	4	Ø	2231				✓
9	202 910 401	1	Ø	2239				✓
10	202 910 406	2	+0.5	2245				✓
11	202 740 675	3	Ø	2250				✓
12	202 830 388	4	Ø	2256				✓
13	203 451 394	1	Ø	2302				✓
14	202 910 402	2	Ø	2308				✓
15	202 910 353	3	Ø	2314				✓
16	203 451 410	4	Ø	2321				✓
17	202 910 363	1	Ø	2328				✓
18	203 350 259	2	-0.4	2237			NO LD / FF	X
19	203 510 231	3	Ø	2238			b/u for 18	✓
20	203 510 190	4	Ø	2343				✓
21	202 721 723	1	Ø	2351				✓
22	203 830 649	2	Ø	2359				✓
23	202 910 397	3	Ø	0006				✓
24								
25								
26								
27								
28								
29								
30								
31								

Drop #	Sonde Serial #	Rcvr #	Press Offset	Launch Time	Operator	Charge $$ To	Comments	Good ?
32								
33								
34								
35								
36								
37								
38								
39								
40								
41								
42								
43								
44								
45								
46								
47								
48								
49								
50								

Drop Station Operator Notes

Charge $$ To Options (DO NOT USE FUNDING CODES):
AOC, NWS, HRD, NESDIS, IR/SST, AR, STAN (Stanford), SAT (JPSS/NESDIS/HRD)

AVAPS Pre-Flight Check:

- If time-permits, verify cabin pressure sensor w/ lab standard
- Start AVAPS., then start Soundings and set the Project Name and Full Flight ID (example: 20120823N2).
- Verify the Frequency band allocation as required:
  Band A: 53rd WRS - Band B: N42RF - Band C: N43RF - Band D: N49RF - Band E: Unallocated
- Select the **GPS Reference** tab from the **Soundings Displays** page and verify good GPS data
- Perform a prelaunch check on each channel, look for reasonable data and no CRC error status lights.
- Verify data is available on Remote AVAPS, then terminate the sonde.
- Verify the AVAPS Data mission folder has been created
- Verify AVAPS PC Time is correct – if time is off by >4sec, no data will display
- Early launch detects are caused usually by remanufactured sondes with the chute riser line not properly coiled below the PCB ear. This may also cause fast falls. If this is suspected, repack the riser line as time permits
- Perform RH Regeneration on all sondes – Multiple RD41 sondes may be processed at once

AVAPS Launch:

- Select a sonde frequency in the Green band and away from other sondes
- Enter sonde pressure error offset if 0.4mB or greater using cabin pressure sensor – warning, this can not be used during a climb
- If the Cal lab pressure standard and the cabin pressure standard match, apply pressure offset +/- 0.1 mB
- Wait until GPS available (green) on the pre-launch screen before continuing.
- Select "begin data collection" and verify good data with winds prior to putting sonde in launch tube
- On N42 & N43, remove about ½ of the ribbon. Do not shorten the ribbon on N49. Loosen ribbon and extend end of ribbon to near, but not over, the sensor end of the sonde. Place excess orange tape on end of ribbon to form a pocket.
- Place the sonde in the launch tube, sensor arm up, with the power pin socket facing right
- Verify the sonde is actively tracking GPS data prior to launch and no early launch detect

AVAPS Drop Log

Project: ARR 21 Mission: 7 Flight ID: 20210131N1

Take Off: Landing: Flt Dir: RH/AL Launcher S/N: 02

30/32

1 no LD

1 bad winds

Drop #	Sonde Serial #	Rcvr #	Press Offset	Launch Time	Operator	Charge $$ To	Comments	Good ?
1	203431 518	1	Ø	2047	SCP	AR		✓
2	203420 266	2	Ø	2054				✓
3	203420 231	3	Ø	2100				✓
4	203420 265	4	Ø	2106				✓
5	203431 515	1	Ø	2112				✓
6	203451 420	2	Ø	2118				✓
7	203451 430	3	Ø	2124				✓
8	203 440 002	4	Ø	2130				✓
9	203451 419	1	Ø	2136				✓
10	203 420 268	2	Ø	2142				✓
11	202720 945	3	Ø	2148				✓
12	202720 653	4	+0.4	2154				✓
13	202 910 398	1	Ø	2201				✓
14	202720 654	2	Ø	2207			No LD (came 17 late)	X
15	202730 095	3	Ø	2208			B/U for 14	✓
16	202 720 910	4	Ø	2213				✓
17	202721 724	1	Ø	2219			bad winds	X
18	202 720 946	2	Ø	2221			b/u for 15	✓
19	203 840 231	2	Ø	2225				✓
20	202 720 637	3	Ø	2230				✓
21	203 840 233	4	Ø	2234				✓
22	203 451 408	1	Ø	2239				✓
23	202 720 907	2	Ø	2244				✓
24	203 420 260	3	Ø	2250			~~late LD~~	✓
25	202 910 352	4	Ø	2255			late LD	✓
26	202 910 400	6	Ø	2300				✓
27	203 451 371	1	Ø	2305				✓
28	203 830 548	2	Ø	2311				✓
29	202 620 946	3	Ø	2316				✓
30	202 720 640	4	Ø	2322				✓
31	203 840 232	1	Ø	2327				✓

7-04

Drop #	Sonde Serial #	Rcvr #	Press Offset	Launch Time	Operator	Charge $$ To	Comments	Good ?
32	262 720 639	2	Ø	2332	SCR	AR		✓
33								
34								
35								
36								
37								
38								
39								
40								
41								
42								
43								
44								
45								
46								
47								
48								
49								
50								

Drop Station Operator Notes

Charge $$ To Options (DO NOT USE FUNDING CODES):
AOC, NWS, HRD, NESDIS, IR/SST, AR, STAN (Stanford), SAT (JPSS/NESDIS/HRD)

AVAPS Pre-Flight Check:

- If time-permits, verify cabin pressure sensor w/ lab standard
- Start AVAPS., then start Soundings and set the Project Name and Full Flight ID (example: 20120823N2).
- Verify the Frequency band allocation as required:
  Band A: 53rd WRS - Band B: N42RF - Band C: N43RF - Band D: N49RF - Band E: Unallocated
- Select the **GPS Reference** tab from the **Soundings Displays** page and verify good GPS data
- Perform a prelaunch check on each channel, look for reasonable data and no CRC error status lights.
- Verify data is available on Remote AVAPS, then terminate the sonde.
- Verify the AVAPS Data mission folder has been created
- Verify AVAPS PC Time is correct – if time is off by >4sec, no data will display
- Early launch detects are caused usually by remanufactured sondes with the chute riser line not properly coiled below the PCB ear. This may also cause fast falls. If this is suspected, repack the riser line as time permits
- Perform RH Regeneration on all sondes – Multiple RD41 sondes may be processed at once

AVAPS Launch:

- Select a sonde frequency in the Green band and away from other sondes
- Enter sonde pressure error offset if 0.4mB or greater using cabin pressure sensor – warning, this can not be used during a climb
- If the Cal lab pressure standard and the cabin pressure standard match, apply pressure offset +/- 0.1 mB
- Wait until GPS available (green) on the pre-launch screen before continuing.
- Select "begin data collection" and verify good data with winds prior to putting sonde in launch tube
- On N42 & N43, remove about ½ of the ribbon. Do not shorten the ribbon on N49. Loosen ribbon and extend end of ribbon to near, but not over, the sensor end of the sonde. Place excess orange tape on end of ribbon to form a pocket.
- Place the sonde in the launch tube, sensor arm up, with the power pin socket facing right
- Verify the sonde is actively tracking GPS data prior to launch and no early launch detect

AVAPS Drop Log

Project: ARR21 Mission: 8 Flight ID: 20210201N1

Take Off: _____ Landing: _____ Flt Dir: RH/AL Launcher S/N: 02

30/31

NO LD

Drop #	Sonde Serial #	Rcvr #	Press Offset	Launch Time	Operator	Charge $$ To	Comments	Good ?
1	203 451 395	1	-0.5	2041	SCP	AR		✓
2	202 610 675	2	Ø	2047				✓
3	202 610 674	3	Ø	2052				✓
4	202 640 028	4	Ø	2058				✓
5	202 640 020	1	Ø	2104				✓
6	202 620 957	2	Ø	2109				✓
7	202 610 687	3	Ø	2115				✓
8	202 620 532	4	Ø	2120				✓
9	202 610 678	1	Ø	2127				✓
10	202 640 023	2	Ø	2131				✓
11	202 630 766	3	Ø	2136				✓
12	203 451 422	4	Ø	2140				✓
13	202 740 674	1	Ø	2147				✓
14	202 720 638	2	Ø	2153				✓
15	203 431 547	3	Ø	2200				✓
16	203 540 601	4	Ø	2207				✓
17	202 720 659	1	Ø	2213				✓
18	203 420 269	2	Ø	2220				✓
19	202 620 988	3	+0.5	2227				✓
20	202 720 642	4	Ø	2233				✓
21	202 720 641	1	Ø	2240				✓
22	203 451 417	2	Ø	2247				✓
23	202 640 029	3	Ø	2253				✓
24	202 620 959	4	Ø	2300			NO LD	X
25	202 640 034	1	Ø	2302				✓
26	202 640 025	2	Ø	2306				✓
27	202 640024	3	Ø	2313				✓
28	202 830 345	4	Ø	2320				✓
29	202 640089	1	Ø	2327				✓
30	203 840 237	2	Ø	2333				✓
31	202 620 956	3	Ø	2342				✓

Drop #	Sonde Serial #	Rcvr #	Press Offset	Launch Time	Operator	Charge $$ To	Comments	Good ?
32								
33								
34								
35								
36								
37								
38								
39								
40								
41								
42								
43								
44								
45								
46								
47								
48								
49								
50								

Drop Station Operator Notes

Charge $$ To Options (DO NOT USE FUNDING CODES):
AOC, NWS, HRD, NESDIS, IR/SST, AR, STAN (Stanford), SAT (JPSS/NESDIS/HRD)

AVAPS Pre-Flight Check:

- If time-permits, verify cabin pressure sensor w/ lab standard
- Start AVAPS., then start Soundings and set the Project Name and Full Flight ID (example: 20120823N2).
- Verify the Frequency band allocation as required:
  Band A: 53rd WRS - Band B: N42RF - Band C: N43RF - Band D: N49RF - Band E: Unallocated
- Select the **GPS Reference** tab from the **Soundings Displays** page and verify good GPS data
- Perform a prelaunch check on each channel, look for reasonable data and no CRC error status lights.
- Verify data is available on Remote AVAPS, then terminate the sonde.
- Verify the AVAPS Data mission folder has been created
- Verify AVAPS PC Time is correct – if time is off by >4sec, no data will display
- Early launch detects are caused usually by remanufactured sondes with the chute riser line not properly coiled below the PCB ear. This may also cause fast falls. If this is suspected, repack the riser line as time permits
- Perform RH Regeneration on all sondes – Multiple RD41 sondes may be processed at once

AVAPS Launch:

- Select a sonde frequency in the Green band and away from other sondes
- Enter sonde pressure error offset if 0.4mB or greater using cabin pressure sensor – warning, this can not be used during a climb
- If the Cal lab pressure standard and the cabin pressure standard match, apply pressure offset +/- 0.1 mB
- Wait until GPS available (green) on the pre-launch screen before continuing.
- Select "begin data collection" and verify good data with winds prior to putting sonde in launch tube
- On N42 & N43, remove about ½ of the ribbon. Do not shorten the ribbon on N49. Loosen ribbon and extend end of ribbon to near, but not over, the sensor end of the sonde. Place excess orange tape on end of ribbon to form a pocket.
- Place the sonde in the launch tube, sensor arm up, with the power pin socket facing right
- Verify the sonde is actively tracking GPS data prior to launch and no early launch detect

AVAPS Drop Log

Project: ARR 2021 Mission: #1 Flight ID: 20210221N1

Take Off: 0723Z Landing: _____ Flt Dir: Hathaway Launcher S/N: 002

Drop #	Sonde Serial #	Rcvr #	Press Offset	Launch Time	Operator	Charge $$ To	Comments	Good ?
1	201651033	1	Ø	2051	JW			✓
2	201520262	2	Ø	2100				✓
3	202311600	3	Ø	2108				✓
4	202721629	4	Ø	2116				✓
5	202721628	1	Ø	2125				✓
6	203310486	2	Ø	2132				✓
7	192540937	3	Ø	2140				✓
8	192540716	4	Ø	2147				✓
9	192940017	1	Ø	2155				✓
10	193020221	2	Ø	2202				✓
BAD 11	192540938	3	Ø	2209			T, DP & H ↓	✗
12	202720943	4	Ø	2210				✓
13	201651030	1	Ø	2216				✓
14	202721654	2	Ø	2223				✓
15	202311621	3	Ø	2230				✓
16	201520286	4	Ø	2236				✓
17	192940591	1	Ø	2243				✓
18	191930447	2	.5	2250				✓
19	202730117	3	Ø	2257				✓
20	192950649	4	Ø	2304				✓
BAD 21	202270431	1	Ø	2311			PTH ↓	✗
22	201520827	2	Ø	2312				✓
23	202910333	3	Ø	2318				✓
24	203310485	4	Ø	2325				✓
25	202910385	1	Ø	2233			Lost 35K Late Launch Det	✓
26	202311617	2	Ø	2340				✓
27	192940588	3	-.4	2348				✓
28	202910334	4	Ø	2356				✓
29	202721653	1	Ø	0003				✓
30	202721652	2	Ø	0011				✓
31	202311566	3	Ø	0018				✓
32	192540929	4	Ø	0025				✓

Drop #	Sonde Serial #	Rcvr #	Press Offset	Launch Time	Operator	Charge $$ To	Comments	Good ?
32								
33								
34								
35								
36								
37								
38								
39								
40								
41								
42								
43								
44								
45								
46								
47								
48								
49								
50								

Drop Station Operator Notes

Charge $$ To Options (DO NOT USE FUNDING CODES):
AOC, NWS, HRD, NESDIS, IR/SST, AR, STAN (Stanford), SAT (JPSS/NESDIS/HRD)

AVAPS Pre-Flight Check:

- If time-permits, verify cabin pressure sensor w/ lab standard
- Start AVAPS., then start Soundings and set the Project Name and Full Flight ID (example: 20120823N2).
- Verify the Frequency band allocation as required:
  Band A: 53rd WRS - Band B: N42RF - Band C: N43RF - Band D: N49RF - Band E: Unallocated
- Select the **GPS Reference** tab from the **Soundings Displays** page and verify good GPS data
- Perform a prelaunch check on each channel, look for reasonable data and no CRC error status lights.
- Verify data is available on Remote AVAPS, then terminate the sonde.
- Verify the AVAPS Data mission folder has been created
- Verify AVAPS PC Time is correct – if time is off by >4sec, no data will display
- Early launch detects are caused usually by remanufactured sondes with the chute riser line not properly coiled below the PCB ear. This may also cause fast falls. If this is suspected, repack the riser line as time permits
- Perform RH Regeneration on all sondes – Multiple RD41 sondes may be processed at once

AVAPS Launch:

- Select a sonde frequency in the Green band and away from other sondes
- Enter sonde pressure error offset if 0.4mB or greater using cabin pressure sensor – warning, this can not be used during a climb
- If the Cal lab pressure standard and the cabin pressure standard match, apply pressure offset +/- 0.1 mB
- Wait until GPS available (green) on the pre-launch screen before continuing.
- Select "begin data collection" and verify good data with winds prior to putting sonde in launch tube
- On N42 & N43, remove about ½ of the ribbon. Do not shorten the ribbon on N49. Loosen ribbon and extend end of ribbon to near, but not over, the sensor end of the sonde. Place excess orange tape on end of ribbon to form a pocket.
- Place the sonde in the launch tube, sensor arm up, with the power pin socket facing right
- Verify the sonde is actively tracking GPS data prior to launch and no early launch detect

AVAPS Drop Log

Project: ARR 2021 Mission: #2 Flight ID: 20210222N1

Take Off: _____ Landing: _____ Flt Dir: Hathaway Launcher S/N: 02

	Drop #	Sonde Serial #	Rcvr #	Press Offset	Launch Time	Operator	Charge $$ To	Comments	Good ?
	1	192620484	1	Ø	2323	JW	AR		✓
	2	192540718	2	Ø	2331				✓
	3	192610977	3	Ø	2340				✓
	4	202910390	4	Ø	2349				✓
	5	193020120	1	Ø	2358				✓
	6	203830474	2	Ø	0007				✓
	7	203840128	3	Ø	0016				✓
	8	204120013	4	Ø	0026				✓
	9	192950661	1	Ø	0035				✓
Bad →	10	204330210	2	Ø	0044			Bad PTH	X
	11	203830473	3	Ø	0045				✓
	12	202721632	4	Ø	0053				✓
	13	202910356	1	Ø	0102				✓
	14	203840138	2	Ø	0112				✓
	15	204031134	3	Ø	0120				✓
	16	192940096	4	Ø	0130				✓
	17	192620163	1	-.8	0141				
	18	203240787	2	Ø	0152			Bad PTH	X
	19	204120015	3	Ø	0152			Tumble	X
	20	203840229	4	Ø	0200				✓
	21	204120014	1	Ø	0208				✓
	22	204311130	2	Ø	0215				✓
	23	203840115	3	Ø	0223				✓
TAPE	24	192620166	4	Ø	0231				✓
	25	192540715	1	Ø	0239				✓
TAPE	26	202311649	2	Ø	0246				✓
	27	192540719	3	Ø	0253				✓
	28	192620336	4	Ø	0301				✓
	29	203830581	1	Ø	0308			FF	X
	30	203631824	2	Ø	0315			PTH	X
	31	203840129	3	Ø	0315				

Drop #	Sonde Serial #	Rcvr #	Press Offset	Launch Time	Operator	Charge $$ To	Comments	Good ?
32	203830470	4	Ø		JW	AR	PTH	
33	203840121	1	Ø					
34	192940127	5	Ø					
35								
36								
37								
38								
39								
40								
41								
42								
43								
44								
45								
46								
47								
48								
49								
50								

Drop Station Operator Notes

Charge $$ To Options (DO NOT USE FUNDING CODES):
AOC, NWS, HRD, NESDIS, IR/SST, AR, STAN (Stanford), SAT (JPSS/NESDIS/HRD)

AVAPS Pre-Flight Check:

- If time-permits, verify cabin pressure sensor w/ lab standard
- Start AVAPS., then start Soundings and set the Project Name and Full Flight ID (example: 20120823N2).
- Verify the Frequency band allocation as required:
  Band A: 53rd WRS - Band B: N42RF - Band C: N43RF - Band D: N49RF - Band E: Unallocated
- Select the **GPS Reference** tab from the **Soundings Displays** page and verify good GPS data
- Perform a prelaunch check on each channel, look for reasonable data and no CRC error status lights.
- Verify data is available on Remote AVAPS, then terminate the sonde.
- Verify the AVAPS Data mission folder has been created
- Verify AVAPS PC Time is correct – if time is off by >4sec, no data will display
- Early launch detects are caused usually by remanufactured sondes with the chute riser line not properly coiled below the PCB ear. This may also cause fast falls. If this is suspected, repack the riser line as time permits
- Perform RH Regeneration on all sondes – Multiple RD41 sondes may be processed at once

AVAPS Launch:

- Select a sonde frequency in the Green band and away from other sondes
- Enter sonde pressure error offset if 0.4mB or greater using cabin pressure sensor – warning, this can not be used during a climb
- If the Cal lab pressure standard and the cabin pressure standard match, apply pressure offset +/- 0.1 mB
- Wait until GPS available (green) on the pre-launch screen before continuing.
- Select "begin data collection" and verify good data with winds prior to putting sonde in launch tube
- On N42 & N43, remove about ½ of the ribbon. Do not shorten the ribbon on N49. Loosen ribbon and extend end of ribbon to near, but not over, the sensor end of the sonde. Place excess orange tape on end of ribbon to form a pocket.
- Place the sonde in the launch tube, sensor arm up, with the power pin socket facing right
- Verify the sonde is actively tracking GPS data prior to launch and no early launch detect

AVAPS Drop Log

Project: AR2021 Mission: # 3 (2) Flight ID: 20210223N1

Take Off: _____ Landing: _____ Flt Dir: Hathway Launcher S/N: 02

ALL SONDES TAPED

Drop #	Sonde Serial #	Rcvr #	Press Offset	Launch Time	Operator	Charge $$ To	Comments	Good ?
1	204031217	1	Ø	2239	JGW	AR		✓
2	204031210	2	Ø	2246				✓
3	204031131	3	Ø	2253				✓
4	203830670	4	Ø	2258				✓
5	204031228	1	Ø	2306				✓
6	204031215	2	Ø	2314				✓
7	204260613	3	Ø	2322				✓
* 8	204031216	4	Ø	—			NO L/D	X
9	204031212	1	Ø	2331			B/U for 8	✓
10	204031209	2	Ø	2337				✓
11	203830682	3	Ø	2345				✓
12	203830035	4	Ø	2353				✓
13	203750634	1	Ø	0000				✓
14	204260618	2	Ø	0010				✓
15	203830674	3	Ø	—			L/D @ 24K	✓
16	204031218	4	Ø	0018			Backup for 15	✓
17	204260583	1	Ø	0026				✓
18	204031213	2	Ø	0034				✓
19	203840135	3	Ø	0041				✓
20	204031178	4	Ø	0049				✓
21	203830469	1	Ø	0057	GD			✓
22	203840132	2	Ø	0104				✓
23	203750636	3	Ø	0112				✓
24	204031229	4	Ø	0119				✓
25	192540911	1	-2	0126				✓
26	204260608	2	0	0133				✓
27	204031080	3	0	0141				✓
28								
29								
30								
31								

Drop #	Sonde Serial #	Rcvr #	Press Offset	Launch Time	Operator	Charge $$ To	Comments	Good ?
32								
33								
34								
35								
36								
37								
38								
39								
40								
41								
42								
43								
44								
45								
46								
47								
48								
49								
50								

Drop Station Operator Notes

Charge $$ To Options (DO NOT USE FUNDING CODES):
AOC, NWS, HRD, NESDIS, IR/SST, AR, STAN (Stanford), SAT (JPSS/NESDIS/HRD)

AVAPS Pre-Flight Check:

- If time-permits, verify cabin pressure sensor w/ lab standard
- Start AVAPS., then start Soundings and set the Project Name and Full Flight ID (example: 20120823N2).
- Verify the Frequency band allocation as required:
  Band A: 53rd WRS - Band B: N42RF - Band C: N43RF - Band D: N49RF - Band E: Unallocated
- Select the **GPS Reference** tab from the **Soundings Displays** page and verify good GPS data
- Perform a prelaunch check on each channel, look for reasonable data and no CRC error status lights.
- Verify data is available on Remote AVAPS, then terminate the sonde.
- Verify the AVAPS Data mission folder has been created
- Verify AVAPS PC Time is correct – if time is off by >4sec, no data will display
- Early launch detects are caused usually by remanufactured sondes with the chute riser line not properly coiled below the PCB ear. This may also cause fast falls. If this is suspected, repack the riser line as time permits
- Perform RH Regeneration on all sondes – Multiple RD41 sondes may be processed at once

AVAPS Launch:

- Select a sonde frequency in the Green band and away from other sondes
- Enter sonde pressure error offset if 0.4mB or greater using cabin pressure sensor – warning, this can not be used during a climb
- If the Cal lab pressure standard and the cabin pressure standard match, apply pressure offset +/- 0.1 mB
- Wait until GPS available (green) on the pre-launch screen before continuing.
- Select "begin data collection" and verify good data with winds prior to putting sonde in launch tube
- On N42 & N43, remove about ½ of the ribbon. Do not shorten the ribbon on N49. Loosen ribbon and extend end of ribbon to near, but not over, the sensor end of the sonde. Place excess orange tape on end of ribbon to form a pocket.
- Place the sonde in the launch tube, sensor arm up, with the power pin socket facing right
- Verify the sonde is actively tracking GPS data prior to launch and no early launch detect

AVAPS Drop Log

Project: AR Mission: #4 Flight ID: 20210307N1

Take Off: _____ Landing: _____ Flt Dir: Hathaway Launcher S/N: 02

Drop #	Sonde Serial #	Rcvr #	Press Offset	Launch Time	Operator	Charge $$ To	Comments	Good ?
1	203451404	1	Ø	2034	JW	AR	Late L/D	✓
2	202311647	2	Ø	2042				✓
3	202720650	3	Ø	2051				✓
4	202730069	4	Ø	2100				✓
5	202830387	1	Ø	2109				✓
6	202721625	2	Ø	2118				✓
7	202830389	3	Ø	2127				✓
8	203320228	4	Ø	2136			Flighted for 3min	✓
9	203940496	1	Ø	2142			No PTH	X
10	202730118	2	Ø	2143			Back up	✓
11	202311638	3	Ø	2148				✓
12	204450369	5	Ø	2154			GPS doA 42K	X
13	204530815	6	Ø	2159				✓
14	204521388	7	Ø	2205				✓
15	204210014	8	Ø	2211				✓
16	201520263	4	Ø	2217				✓
17	202730057	1	Ø	2222				✓
18	203840127	2	Ø	2228				✓
19	204450385	3	-.5	2234				✓
20	204521413	5	-.2	2242				✓
21	202730068	6	Ø	2248				✓
22	204521414	7	Ø	2254				✓
23	204260862	8	.2	2300				✓
24	203830680	1	Ø	2306				✓
25	204031230	2	Ø	—			No L/D	X
26	204031230	3	Ø	—			No L/D DoA	X
27	202260949	4	Ø	2318			No PTH	X
28	204450351	5	Ø	2319				✓
29	204520782	1	Ø	2326				✓
30	204520774	2	Ø	2331				✓
31	204520797	3	Ø	2341				

ALL SONDES TAPED

Drop #	Sonde Serial #	Rcvr #	Press Offset	Launch Time	Operator	Charge $$ To	Comments	Good ?
32	204450386	4	Ø	2349	JW	AR		✓
33	204521389	1	Ø	2357				✓
34	204521411	2	Ø	0005			No PTU	X
35	204521416	3	Ø	0006				✓
36	204640853	4	Ø	0013				✓
37	202721622	1	Ø	0020				✓
38	203830519	2	Ø	0028				✓
39	203451433	3	Ø	0036				✓
40								
41								
42								
43								
44								
45								
46								
47								
48								
49								
50								

Drop Station Operator Notes

Charge $$ To Options (DO NOT USE FUNDING CODES):
AOC, NWS, HRD, NESDIS, IR/SST, AR, STAN (Stanford), SAT (JPSS/NESDIS/HRD)

AVAPS Pre-Flight Check:

- If time-permits, verify cabin pressure sensor w/ lab standard
- Start AVAPS., then start Soundings and set the Project Name and Full Flight ID (example: 20120823N2).
- Verify the Frequency band allocation as required:
  Band A: 53rd WRS - Band B: N42RF - Band C: N43RF - Band D: N49RF - Band E: Unallocated
- Select the **GPS Reference** tab from the **Soundings Displays** page and verify good GPS data
- Perform a prelaunch check on each channel, look for reasonable data and no CRC error status lights.
- Verify data is available on Remote AVAPS, then terminate the sonde.
- Verify the AVAPS Data mission folder has been created
- Verify AVAPS PC Time is correct – if time is off by >4sec, no data will display
- Early launch detects are caused usually by remanufactured sondes with the chute riser line not properly coiled below the PCB ear. This may also cause fast falls. If this is suspected, repack the riser line as time permits
- Perform RH Regeneration on all sondes – Multiple RD41 sondes may be processed at once

AVAPS Launch:

- Select a sonde frequency in the Green band and away from other sondes
- Enter sonde pressure error offset if 0.4mB or greater using cabin pressure sensor – warning, this can not be used during a climb
- If the Cal lab pressure standard and the cabin pressure standard match, apply pressure offset +/- 0.1 mB
- Wait until GPS available (green) on the pre-launch screen before continuing.
- Select "begin data collection" and verify good data with winds prior to putting sonde in launch tube
- On N42 & N43, remove about ½ of the ribbon. Do not shorten the ribbon on N49. Loosen ribbon and extend end of ribbon to near, but not over, the sensor end of the sonde. Place excess orange tape on end of ribbon to form a pocket.
- Place the sonde in the launch tube, sensor arm up, with the power pin socket facing right
- Verify the sonde is actively tracking GPS data prior to launch and no early launch detect

AVAPS Drop Log

Project: AR Mission: #5 Flight ID: 20210308N1

Take Off: 1825Z Landing: _____ Flt Dir: Hathaway Launcher S/N: 02

ALL SONDES TARED

	Drop #	Sonde Serial #	Rcvr #	Press Offset	Launch Time	Operator	Charge $$ To	Comments	Good ?
	1	204031191	1	Ø	2030	JW	AR		✓
	2	203830678	2	Ø	2038				✓
	3	203820056	3	Ø	2048			F/F	X
	4	204031196	4	Ø				No L/D 30A 34K	X
	5		1						
5	~~6~~	203830034	2	Ø	2101				✓
6	~~7~~	202730119	3	Ø	2110				✓
7	~~8~~	204450370	4	Ø	2116			No PTH	X
8	~~9~~	204031181	1	Ø	2114				✓
9	~~10~~	204031089	5	Ø	—			No L/D	X
10	~~11~~	204031172	6	Ø	2122			Bad Winds	X
11	~~12~~	203830670	7	Ø	2127				✓
12	~~13~~	204031163	8	Ø	2134				✓
13	~~14~~	203640262	2	Ø	2139				✓
14	~~15~~	203631649	3	Ø	2146				✓
15	~~16~~	203830033	4	Ø	2151				✓
16	~~17~~	203631773	5	Ø	2157				✓
17	~~18~~	203830638	6	Ø	2202				✓
18	~~19~~	202640021	7	-.5	2208				✓
19	~~20~~	204520790	8	Ø	2213				✓
20	~~21~~	204031132	1	Ø	2219				✓
21	~~22~~	203631843	2	Ø	—			No L/D	X
22	~~23~~	204031227	3	Ø	2225				✓
23	~~24~~	204031173	4	Ø	2230				✓
24	~~25~~	203830664	5	Ø	—			No L/D	X
25	~~26~~	202610677	6	Ø	2237				✓
26	~~27~~	203830684	7	Ø	2244			Late L/D	X
27	~~28~~	204031174	8	Ø	2243				✓
28	~~29~~	203631772	1	Ø	—			No L/D	X
29	~~30~~	204031137	2	Ø	2249				✓
30	~~31~~	204031136	3	Ø	2254				✓

	Drop #	Sonde Serial #	Rcvr #	Press Offset	Launch Time	Operator	Charge $$ To	Comments	Good ?
31	~~32~~	204120633	5	-.2	2300	JW	AR		✓
32	~~33~~	203830671	6	Ø	2306				✓
33	~~34~~	203640263	7	Ø	2312				✓
34	~~35~~	203840009	8	-.1	2322				✓
35	~~36~~	204031197	1	Ø	2332			No PTH	X
36	~~37~~	204031200	2	Ø	2333			Late Winds	✓
37	~~38~~	203840133	3	Ø	2336				✓
38	39	203830666	4	Ø	2342				✓
39	40	203830679	1	Ø	2352			No PTH	X
40	41	204260 1625	5	Ø	2353				✓
	42								
	43								
	44								
	45								
	46								
	47								
	48								
	49								
	50								

Drop Station Operator Notes

Charge $$ To Options (DO NOT USE FUNDING CODES):
AOC, NWS, HRD, NESDIS, IR/SST, AR, STAN (Stanford), SAT (JPSS/NESDIS/HRD)

AVAPS Pre-Flight Check:

- If time-permits, verify cabin pressure sensor w/ lab standard
- Start AVAPS., then start Soundings and set the Project Name and Full Flight ID (example: 20120823N2).
- Verify the Frequency band allocation as required:
  Band A: 53rd WRS - Band B: N42RF - Band C: N43RF - Band D: N49RF - Band E: Unallocated
- Select the **GPS Reference** tab from the **Soundings Displays** page and verify good GPS data
- Perform a prelaunch check on each channel, look for reasonable data and no CRC error status lights.
- Verify data is available on Remote AVAPS, then terminate the sonde.
- Verify the AVAPS Data mission folder has been created
- Verify AVAPS PC Time is correct – if time is off by >4sec, no data will display
- Early launch detects are caused usually by remanufactured sondes with the chute riser line not properly coiled below the PCB ear. This may also cause fast falls. If this is suspected, repack the riser line as time permits
- Perform RH Regeneration on all sondes – Multiple RD41 sondes may be processed at once

AVAPS Launch:

- Select a sonde frequency in the Green band and away from other sondes
- Enter sonde pressure error offset if 0.4mB or greater using cabin pressure sensor – warning, this can not be used during a climb
- If the Cal lab pressure standard and the cabin pressure standard match, apply pressure offset +/- 0.1 mB
- Wait until GPS available (green) on the pre-launch screen before continuing.
- Select "begin data collection" and verify good data with winds prior to putting sonde in launch tube
- On N42 & N43, remove about ½ of the ribbon. Do not shorten the ribbon on N49. Loosen ribbon and extend end of ribbon to near, but not over, the sensor end of the sonde. Place excess orange tape on end of ribbon to form a pocket.
- Place the sonde in the launch tube, sensor arm up, with the power pin socket facing right
- Verify the sonde is actively tracking GPS data prior to launch and no early launch detect

AVAPS Drop Log

Project: ARR 2021 Mission: #5 Flight ID: 20210310N1

Take Off: _____ Landing: _____ Flt Dir: Hathaway Launcher S/N: 02

REPACKED

ALL SONDE CHUTES

Drop #	Sonde Serial #	Rcvr #	Press Offset	Launch Time	Operator	Charge $$ To	Comments	Good ?
1	202610690	1	Ø	2100	JW	AR		✓
2	202630592	2	Ø	2108			NO PTH	✗
3	202620250	3	Ø	2108			Backup for #2	✓ 2
4	202530188	4	Ø	2116				✓
5	202620910	1	-.3	2124			NO PTH	✗
6	202620424	5	Ø	2124			Backup for #5	✓ 3
7	202630581	2	Ø	2131				✓
8	203420263	3	Ø	2139				✓
9	203350238	4	-.4	2146				✓
10	203420264	1	Ø	2153				✓
11	203420249	2	-.3	2201				✓
12	203451087	3	-.3	2208				✓
13	203350243	4	-.4	2215				✓
14	202620530	1	Ø	2222				✓
15	203510177	2	-.5	2229			FLOATER	✓
16	202530141	3	-.4	2236			FLOATER	✓
17	203420301	4	Ø	2246				✓
18	202621806	1	Ø	2253				✓
19	203420304	2	Ø	2300				✓
20	202520292	3	Ø	2307				✓
21	203510207	4	Ø	2314				✓
22	203350237	1	Ø	2321				✓
23	202610692	2	.3	2329				✓
24	202640075	3	Ø	2336				✓
25	202610691	4	Ø	2343				✓
26	203820058	1	Ø	2350				✓
27	203350244	2	Ø	2357				✓
28	203420247	3	Ø	—			NO L/D	✗
29	202620916	4	Ø	0005			NO PTH	✗
30	202630579	5	Ø	0008				✓
31	202640046	1	Ø	0014			NO PTH	✗

Gabe Helped on 2

Drop #	Sonde Serial #	Rcvr #	Press Offset	Launch Time	Operator	Charge $$ To	Comments	Good ?
32	202530140	2	Ø	0015	JW	AR		✓
33	202620947	3	Ø	0022				✓
34	203350239	4	Ø	0030				✓
35	202640070	1	-.2	0038				✓
36								
37								
38								
39								
40								
41								
42								
43								
44								
45								
46								
47								
48								
49								
50								

Drop Station Operator Notes

Charge $$ To Options (DO NOT USE FUNDING CODES):
AOC, NWS, HRD, NESDIS, IR/SST, AR, STAN (Stanford), SAT (JPSS/NESDIS/HRD)

AVAPS Pre-Flight Check:

- If time-permits, verify cabin pressure sensor w/ lab standard
- Start AVAPS., then start Soundings and set the Project Name and Full Flight ID (example: 20120823N2).
- Verify the Frequency band allocation as required:
  Band A: 53rd WRS - Band B: N42RF - Band C: N43RF - Band D: N49RF - Band E: Unallocated
- Select the **GPS Reference** tab from the **Soundings Displays** page and verify good GPS data
- Perform a prelaunch check on each channel, look for reasonable data and no CRC error status lights.
- Verify data is available on Remote AVAPS, then terminate the sonde.
- Verify the AVAPS Data mission folder has been created
- Verify AVAPS PC Time is correct – if time is off by >4sec, no data will display
- Early launch detects are caused usually by remanufactured sondes with the chute riser line not properly coiled below the PCB ear. This may also cause fast falls. If this is suspected, repack the riser line as time permits
- Perform RH Regeneration on all sondes – Multiple RD41 sondes may be processed at once

AVAPS Launch:

- Select a sonde frequency in the Green band and away from other sondes
- Enter sonde pressure error offset if 0.4mB or greater using cabin pressure sensor – warning, this can not be used during a climb
- If the Cal lab pressure standard and the cabin pressure standard match, apply pressure offset +/- 0.1 mB
- Wait until GPS available (green) on the pre-launch screen before continuing.
- Select "begin data collection" and verify good data with winds prior to putting sonde in launch tube
- On N42 & N43, remove about ½ of the ribbon. Do not shorten the ribbon on N49. Loosen ribbon and extend end of ribbon to near, but not over, the sensor end of the sonde. Place excess orange tape on end of ribbon to form a pocket.
- Place the sonde in the launch tube, sensor arm up, with the power pin socket facing right
- Verify the sonde is actively tracking GPS data prior to launch and no early launch detect

AVAPS Drop Log

Project: ARR 21 Mission: #7 Flight ID: 20210311NA

Take Off: 1940Z Landing: _____ Flt Dir: Holloway Launcher S/N: 02

Drop #	Sonde Serial #	Rcvr #	Press Offset	Launch Time	Operator	Charge $$ To	Comments	Good ?
1	202620547	1	.3	2034	JW	AR		✓
2	202440388	2	Ø	2044				✓
3	203451389	3	-.3	—			NO L/D	X
4	203451390	4	-.3	2054			NO PTH	X
5	203420303	5	Ø	2056				✓
6	203751402	6	Ø	2104				✓
7	203510356	7	Ø	2111			NO PTH	X
8	203350230	8	Ø	2111				✓
9	203451354	1	Ø	2120				✓
10	203420338	2	Ø	2130				✓
11	202630337	3	Ø	2139				✓
12	202621803	4	Ø	2149			NO PTH	X
13	202620422	1	Ø	2149				✓
14	203510302	2	Ø	2158				✓
15	202420533	3	Ø	2207				✓
16	203751400	4	Ø	2217				✓
17	203630235	1	Ø	2227				✓
18	202630341	2	Ø	2237				✓
19	202610693	3	Ø	2246				✓
20	202520294	4	.2	2254				✓
21	202610694	1	.2	2305				✓
22	202440387	2	Ø	2314			FF	X
23	203630326	3	Ø	2322	2316	203 850 050		✓
24	203751401	5	Ø	2332			LATE L/D	X
25	203420262	4	Ø	2330				✓
26	203830667	6	Ø	2338				✓
27	203420340	1	Ø	2347				✓
28	202610577	2	Ø	2355				✓
29	202640027	3	Ø	0004				✓
30	203451392	4	-.4	0012			NO PTH	X
31	202630340	1	.3	—			NO L/D	

Drop #	Sonde Serial #	Rcvr #	Press Offset	Launch Time	Operator	Charge $$ To	Comments	Good ?
32	202620526	5	Ø	0015	JW	AW		✓
33	203820051	2	Ø	0021				✓
34	203630334	6	Ø	0029				✓
35	203420305	3	Ø	0038				✓
36	202610689	4	-.2	0046				✓
37	203350233	1	-.4	0054				✓
38								
39								
40								
41								
42								
43								
44								
45								
46								
47								
48								
49								
50								

Drop Station Operator Notes

Charge $$ To Options (DO NOT USE FUNDING CODES):
AOC, NWS, HRD, NESDIS, IR/SST, AR, STAN (Stanford), SAT (JPSS/NESDIS/HRD)

AVAPS Pre-Flight Check:

- If time-permits, verify cabin pressure sensor w/ lab standard
- Start AVAPS., then start Soundings and set the Project Name and Full Flight ID (example: 20120823N2).
- Verify the Frequency band allocation as required:
  Band A: 53rd WRS - Band B: N42RF - Band C: N43RF - Band D: N49RF - Band E: Unallocated
- Select the **GPS Reference** tab from the **Soundings Displays** page and verify good GPS data
- Perform a prelaunch check on each channel, look for reasonable data and no CRC error status lights.
- Verify data is available on Remote AVAPS, then terminate the sonde.
- Verify the AVAPS Data mission folder has been created
- Verify AVAPS PC Time is correct – if time is off by >4sec, no data will display
- Early launch detects are caused usually by remanufactured sondes with the chute riser line not properly coiled below the PCB ear. This may also cause fast falls. If this is suspected, repack the riser line as time permits
- Perform RH Regeneration on all sondes – Multiple RD41 sondes may be processed at once

AVAPS Launch:

- Select a sonde frequency in the Green band and away from other sondes
- Enter sonde pressure error offset if 0.4mB or greater using cabin pressure sensor – warning, this can not be used during a climb
- If the Cal lab pressure standard and the cabin pressure standard match, apply pressure offset +/- 0.1 mB
- Wait until GPS available (green) on the pre-launch screen before continuing.
- Select "begin data collection" and verify good data with winds prior to putting sonde in launch tube
- On N42 & N43, remove about ½ of the ribbon. Do not shorten the ribbon on N49. Loosen ribbon and extend end of ribbon to near, but not over, the sensor end of the sonde. Place excess orange tape on end of ribbon to form a pocket.
- Place the sonde in the launch tube, sensor arm up, with the power pin socket facing right
- Verify the sonde is actively tracking GPS data prior to launch and no early launch detect

AVAPS Drop Log

Project: ARR 21 Mission: 7 Flight ID: 20210312N1

Take Off: 1945Z Landing: _____ Flt Dir: Hathaway Launcher S/N: 02

	Drop #	Sonde Serial #	Rcvr #	Press Offset	Launch Time	Operator	Charge $$ To	Comments	Good ?
	1	203 830 592	1	Ø	2035	JW	AR	NO PTH	X
	2	204 130 043	2	Ø	2036			Back UP 1	✓
	3	204 120 651	3	Ø	2045				✓
Repeat	4	204 260 616	4	Ø	2054				✓
	5	204 130 104	1	Ø	2103			NO PTH	X
	6	204 030 664	2	Ø	2103			Back UP 4	✓
	7	204 130 041	3	Ø	2112				✓
R	8	203 840 928	4	Ø	2121				✓
	9	204 121 029	1	Ø	2130				✓
	10	204 130 096	2	Ø	2139				✓
	11	203 830 593	3	Ø	2148			NO PTH	X
R	12	203 840 124	4	Ø	2149			Back UP 9	✓
	13	203 830 594	1	Ø	—			NO L/D	X
	14	203 840 250	2	Ø	2158			Back UP 10	✓
	15	204 130 078	3	Ø	2204				✓
R	16	203 830 578	4	Ø	2215				✓
	17	203 840 117	1	Ø	2224				✓
	18	203 840 118	2	Ø	—			NO L/D	X
	19	203 940 493	3	Ø	—			NO L/D	X
R	20	204 121 027	4	Ø	2236				✓
	21	204 130 025	5	Ø	2242			NO PTH	
	22	204 130 073	6	Ø	2243			LATE L/D	✓
	23	203 840 238	7	Ø	2249	GD			✓
R	24	203 840 249	8	Ø	2258				✓
	25	203 830 579	1	Ø	2309				✓
R	26	203 830 575	2	0	2318				✓
	27	203 810 261	3	-.3	2329				✓
R	28	203 830 597	4	-.5	2341			LATE L/D	✓
R	29	203 840 015	1	-0	2340				✓
R	30	204 030 615	2	.2	2350				✓
R	31	204 121 031	3	0	—			NO L/D	

	Drop #	Sonde Serial #	Rcvr #	Press Offset	Launch Time	Operator	Charge $$ To	Comments	Good ?
R	32	204130 105	4	0	0003	GD		LATE c/b	✓
R	33	202 640 026	1	0	0011				✓
R	34	203 440 005	2	0	0022				✓
R	35	203 830 582	3	0	0032				✓
	36	203320 225	4	1	0043				✓
	37	203 240 117	1	0	0053				✓
	38	203 350 262	2	-.8	0104			LATE GPS	✓
	39	203 240 642	3	1	0113				✓
	40								
	41								
	42								
	43								
	44								
	45								
	46								
	47								
	48								
	49								
	50								

Drop Station Operator Notes

Charge $$ To Options (DO NOT USE FUNDING CODES):
AOC, NWS, HRD, NESDIS, IR/SST, AR, STAN (Stanford), SAT (JPSS/NESDIS/HRD)

AVAPS Pre-Flight Check:

- If time-permits, verify cabin pressure sensor w/ lab standard
- Start AVAPS., then start Soundings and set the Project Name and Full Flight ID (example: 20120823N2).
- Verify the Frequency band allocation as required:
  Band A: 53rd WRS - Band B: N42RF - Band C: N43RF - Band D: N49RF - Band E: Unallocated
- Select the **GPS Reference** tab from the **Soundings Displays** page and verify good GPS data
- Perform a prelaunch check on each channel, look for reasonable data and no CRC error status lights.
- Verify data is available on Remote AVAPS, then terminate the sonde.
- Verify the AVAPS Data mission folder has been created
- Verify AVAPS PC Time is correct – if time is off by >4sec, no data will display
- Early launch detects are caused usually by remanufactured sondes with the chute riser line not properly coiled below the PCB ear. This may also cause fast falls. If this is suspected, repack the riser line as time permits
- Perform RH Regeneration on all sondes – Multiple RD41 sondes may be processed at once

AVAPS Launch:

- Select a sonde frequency in the Green band and away from other sondes
- Enter sonde pressure error offset if 0.4mB or greater using cabin pressure sensor – warning, this can not be used during a climb
- If the Cal lab pressure standard and the cabin pressure standard match, apply pressure offset +/- 0.1 mB
- Wait until GPS available (green) on the pre-launch screen before continuing.
- Select "begin data collection" and verify good data with winds prior to putting sonde in launch tube
- On N42 & N43, remove about ½ of the ribbon. Do not shorten the ribbon on N49. Loosen ribbon and extend end of ribbon to near, but not over, the sensor end of the sonde. Place excess orange tape on end of ribbon to form a pocket.
- Place the sonde in the launch tube, sensor arm up, with the power pin socket facing right
- Verify the sonde is actively tracking GPS data prior to launch and no early launch detect

AVAPS Drop Log

Project: ARR21 Mission: #18 Flight ID: 20210313N1

Take Off: 1930Z Landing: _____ Flt Dir: Hathaway Launcher S/N: Ø2

	Drop #	Sonde Serial #	Rcvr #	Press Offset	Launch Time	Operator	Charge $$ To	Comments	Good ?
Repack	1	203830637	1	-.2	2034	JW	AR	Late PTH	✓
	2	203210052	2	Ø	2034			Backup	✓
	3	202640003	3	Ø	2042				✓
Repack	4	203240094	4	Ø	2051				✓
	5	203150669	1	Ø	2059				✓
Repack	6	203520178	2	Ø	2108				✓
	7	203150292	3	Ø	2117				✓
	8	203150501	4	Ø	2126				✓
Repack	9	203631642	1	Ø	2135				✓
	10	203420300	2	Ø	2144				✓
REPACK	11	203520067	3	Ø	2153				✓
	12	203210050	4	Ø	2201				✓
REPACK	13	203150294	1	Ø	2210				✓
	14	203210049	2	Ø	2218				✓
REPACK	15	203431794	3	Ø	2227				✓
	16	203431804	4	Ø	2236				✓
REPACK	17	203540054	1	Ø	2243			FLOATER	✓
	18	203510178	2	Ø	2252				✓
REPACK	19	203210054	3	-.3	2302				✓
	20	203431788	4	Ø	2315				✓
	21	203631621	1	Ø	2328				✓
REPACK	22	203431793	2	Ø	2341				✓
	23	202620531	3	.4	2354				✓
	24	203431789	4	Ø	0007				✓
	25	203510315	1	-.4	0020				✓
	26	203350279	2	-.3	0034				✓
REPACK	27	203150618	3	Ø	0047				✓
	28	203810239	4	Ø	0101				✓
REPACK	29	203305275	1	-.3	0115				✓
	30	203350263	2	-.4	0128				✓
REPACK	31	202620557	3	Ø	0142				✓

Drop #	Sonde Serial #	Rcvr #	Press Offset	Launch Time	Operator	Charge $$ To	Comments	Good ?
32								
33								
34								
35								
36								
37								
38								
39								
40								
41								
42								
43								
44								
45								
46								
47								
48								
49								
50								

Drop Station Operator Notes

Charge $$ To Options (DO NOT USE FUNDING CODES):
AOC, NWS, HRD, NESDIS, IR/SST, AR, STAN (Stanford), SAT (JPSS/NESDIS/HRD)

AVAPS Pre-Flight Check:

- If time-permits, verify cabin pressure sensor w/ lab standard
- Start AVAPS., then start Soundings and set the Project Name and Full Flight ID (example: 20120823N2).
- Verify the Frequency band allocation as required:
  Band A: 53rd WRS - Band B: N42RF - Band C: N43RF - Band D: N49RF - Band E: Unallocated
- Select the **GPS Reference** tab from the **Soundings Displays** page and verify good GPS data
- Perform a prelaunch check on each channel, look for reasonable data and no CRC error status lights.
- Verify data is available on Remote AVAPS, then terminate the sonde.
- Verify the AVAPS Data mission folder has been created
- Verify AVAPS PC Time is correct – if time is off by >4sec, no data will display
- Early launch detects are caused usually by remanufactured sondes with the chute riser line not properly coiled below the PCB ear. This may also cause fast falls. If this is suspected, repack the riser line as time permits
- Perform RH Regeneration on all sondes – Multiple RD41 sondes may be processed at once

AVAPS Launch:

- Select a sonde frequency in the Green band and away from other sondes
- Enter sonde pressure error offset if 0.4mB or greater using cabin pressure sensor – warning, this can not be used during a climb
- If the Cal lab pressure standard and the cabin pressure standard match, apply pressure offset +/- 0.1 mB
- Wait until GPS available (green) on the pre-launch screen before continuing.
- Select "begin data collection" and verify good data with winds prior to putting sonde in launch tube
- On N42 & N43, remove about ½ of the ribbon. Do not shorten the ribbon on N49. Loosen ribbon and extend end of ribbon to near, but not over, the sensor end of the sonde. Place excess orange tape on end of ribbon to form a pocket.
- Place the sonde in the launch tube, sensor arm up, with the power pin socket facing right
- Verify the sonde is actively tracking GPS data prior to launch and no early launch detect

AVAPS Drop Log

20210315N1

Project: ARR21 Mission: LAL Return Flight ID: 20210305N1

Take Off: 0726z Landing: _____ Flt Dir: Holloway Launcher S/N: Ø2

Drop #	Sonde Serial #	Rcvr #	Press Offset	Launch Time	Operator	Charge $$ To	Comments	Good ?
1	203310167	1	Ø	1959	JW	AR		✓
2	203240096	2	Ø	2009				✓
3	203240091	3	Ø	2021				✓
4	203240090	4	Ø	2034				✓
5	203310162	1	Ø	1645				✓
6	203420339	2	Ø	2057				✓
7	203540069	3	Ø	2108				✓
8	203431809	4	Ø	2120				✓
9	203520092	1	-.3	2131				✓
10	203240640	2	Ø	2143				✓
11								
12								
13								
14								
15								
16								
17								
18								
19								
20								
21								
22								
23								
24								
25								
26								
27								
28								
29								
30								
31								

AVAPS Drop Log

Project: HURR 21 Mission: ~~20210603N1~~ SHAKEDOWN Flight ID: 20210603N1

Take Off: _____ Landing: _____ Flt Dir: Hausman Launcher S/N: _____

Drop #	Sonde Serial #	Rcvr #	Press Offset	Launch Time	Operator	Charge $$ To	Comments	Good ?
1	201 730 024	1-8	-0.5	1527	CFY GD	SEB		✓
2								
3								
4								
5								
6								
7								
8								
9								
10								
11								
12								
13								
14								
15								
16								
17								
18								
19								
20								
21								
22								
23								
24								
25								
26								
27								
28								
29								
30								
31								

Drop #	Sonde Serial #	Rcvr #	Press Offset	Launch Time	Operator	Charge $$ To	Comments	Good ?
32								
33								
34								
35								
36								
37								
38								
39								
40								
41								
42								
43								
44								
45								
46								
47								
48								
49								
50								

Drop Station Operator Notes

Charge $$ To Options (DO NOT USE FUNDING CODES):
AOC, NWS, HRD, NESDIS, IR/SST, AR, STAN (Stanford), SAT (JPSS/NESDIS/HRD)

AVAPS Pre-Flight Check:

- If time-permits, verify cabin pressure sensor w/ lab standard
- Start AVAPS., then start Soundings and set the Project Name and Full Flight ID (example: 20120823N2).
- Verify the Frequency band allocation as required:
  Band A: 53rd WRS - Band B: N42RF - Band C: N43RF - Band D: N49RF - Band E: Unallocated
- Select the **GPS Reference** tab from the **Soundings Displays** page and verify good GPS data
- Perform a prelaunch check on each channel, look for reasonable data and no CRC error status lights.
- Verify data is available on Remote AVAPS, then terminate the sonde.
- Verify the AVAPS Data mission folder has been created
- Verify AVAPS PC Time is correct – if time is off by >4sec, no data will display
- Early launch detects are caused usually by remanufactured sondes with the chute riser line not properly coiled below the PCB ear. This may also cause fast falls. If this is suspected, repack the riser line as time permits
- Perform RH Regeneration on all sondes – Multiple RD41 sondes may be processed at once

AVAPS Launch:

- Select a sonde frequency in the Green band and away from other sondes
- Enter sonde pressure error offset if 0.4mB or greater using cabin pressure sensor – warning, this can not be used during a climb
- If the Cal lab pressure standard and the cabin pressure standard match, apply pressure offset +/- 0.1 mB
- Wait until GPS available (green) on the pre-launch screen before continuing.
- Select "begin data collection" and verify good data with winds prior to putting sonde in launch tube
- On N42 & N43, remove about ½ of the ribbon. Do not shorten the ribbon on N49. Loosen ribbon and extend end of ribbon to near, but not over, the sensor end of the sonde. Place excess orange tape on end of ribbon to form a pocket.
- Place the sonde in the launch tube, sensor arm up, with the power pin socket facing right
- Verify the sonde is actively tracking GPS data prior to launch and no early launch detect