"Quality Pumps Since 1939"

Product information presented here reflects conditions at time of publication. Consult factory regarding discrepancies or inconsistencies.

ZOELLER® ENGINEERED PRODUCTS

MAIL TO: P.O. BOX 16347 • Louisville, KY 40256-0347
SHIP TO: 3649 Cane Run Road • Louisville, KY 40211-1961
(502) 778-2731 • 1 (800) 928-PUMP • FAX (502) 774-3624

visit our web site: http://www.zoeller.com

SECTION: Z6.00.110
ZM1074
0903
Supersedes
0600

FILE COPY
JOB NO.

START-UP REPORT
ZOELLER ENGINEERED PRODUCTS PUMPING SYSTEMS

I. PROJECT INFORMATION - Completed by Installing Contractor

JOB NAME: Cora Apts
LOCATION: 19 W. Harrison St. Sea, WA (Address/City, State)
ENGINEER: (Firm's Name)
INSTALLING CONTRACTOR: ONE Way Plumbing (Company's Name)
START-UP: Hollabaugh Bros. (Company's name)
127 10th st S. Kirkland, WA (Address/City/State)
INSTALLATION DATE: 7-6-17
START UP DATE: 8-10-17

II. EQUIPMENT INFORMATION - Completed by Installing Contractor

Tag No. or Location I.D.:

PUMP NAMEPLATE DATA

P/N 140-0002 Model No.: N140-F Voltage 115 Phase 1 BHP 1 RATED FLA 12
Serial No. Pump 1: (or) Date of Mfg. Pump 1: 0417
Serial No. Pump 2: (or) Date of Mfg. Pump 2: 0417

Control Panel: 10-0092 Zoeller (Model No. Serial No.) NEMA 4 Duplex (Type)
Float Switches: Zoeller (Manufacturer) (Model No.) 3 (Quantity)
Basin: 60" X 72" (Dimensions) Additional Information:

Pump Mount: ☐ Rail ☐ Free Standing ☐ Suspended

Installation Type: ☐ Field Assembled ☐ Pre Packaged

III. INSTALLER CHECKLIST - The following should be completed before start-up by installing contractor.

- [x] Impeller turns freely by hand
- [x] Pump rotation correct (3 phase only)
- [x] Equipment in good condition
- [x] Pit Clean
- [x] Check valve, discharge pipe, and vent pipe installed
- [x] 3/16" vent hole drilled in discharge pipe
- [x] Access cover/Hatch Installed
- [x] Panel securely installed and electrical connections tight
- [x] Single phase starting capacitors installed
- [x] Short circuit protections 20 Amps
- [ ] ~~Thermal overload protections ____ Amps~~ N/A
- [x] Proper wiring connected to controller 14 Gage 35 Length
- [x] Float positions from bottom of pit
  #1 24 in. (off) #2 36 in. (on) #3 ___ in. (Alarm/override) #4 50 in. (Alarm)

IV. START-UP VERIFICATION LIST

- [x] To be check by the start up technician with installers assistance.
- [x] Discharge pipe installed. 2 in.
- [x] Vent pipe installed. 3 in.
- [x] Check Valve installed in correct location and direction
- [x] 3/16" vent hole drilled in discharge pipe
- [x] Pit clean
- [x] Access opening large enough for pump removal
- [x] Panel and internal wiring securely installed
- [x] Panel and junction box interior dry & sealed
- [x] Power supply cable length 35 Ft.
- [x] Float switches away from turbulence and hang-ups
- [x] Low water level above volute top (#1 off switch)
- [x] Pumps respond properly to hand-off-auto switch
- [x] Alarm respond properly to test - off - normal switch
- [x] Panel matches pump horsepower
- [x] Circuit breakers operational
- [x] Thermal overloads correctly set to match name plate amps
- [x] Operator has installation and maintenance manual
- [x] Operator has control panel schematic

V. ELECTRICAL READINGS:

SINGLE PHASE:		Pump #1	Pump #2
Voltage supply (Pump off)	L1-L2	~~120~~ V.	~~120~~ V.
Voltage supply (Pump on)	L1-L2	116 V.	119 V.
Amp draw (Pump on)	L1	11.2 A.	11.4 A.
	L2	11.2 A.	11.4 A.
THREE PHASE:			
Voltage Supply (Pump off)	L1-L2	___ V.	___ V.
	L2-L3	___ V.	___ V.
	L1-L3	___ V.	___ V.
Voltage Supply (Pump on)	L1-L2	___ V.	___ V.
	L2-L3	___ V.	___ V.
	L1-L3	___ V.	___ V.
Amp Draw (Pump on)	L1	___ A.	___ A.
	L2	___ A.	___ A.
	L3	___ A.	___ A.

VI. FUNCTIONAL TEST

P1 73.44 GPM @ 15 'TDH
P2 73.44 GPM @ 15 'TDH

VII. SUMMARIZATION

COMMENTS:

I certify this start-up report to be accurate:

Justin Stenwick (Name) 8-10-17 (Date)

Others present during Start-Up:
- ☐ Engineer
- ☒ Contractor
- ☐ Operator
- ☐ Other

FILE COPY

© Copyright 2003 Zoeller Co. All rights reserved.

"Quality Pumps Since 1939"

Product information presented here reflects conditions at time of publication. Consult factory regarding discrepancies or inconsistencies.

ZOELLER® ENGINEERED PRODUCTS

MAIL TO: P.O. BOX 16347 • Louisville, KY 40256-0347
SHIP TO: 3649 Cane Run Road • Louisville, KY 40211-1961
(502) 778-2731 • 1 (800) 928-PUMP • FAX (502) 774-3624

visit our web site: http://www.zoeller.com

SECTION: Z6.00.110
ZM1074
0903
Supersedes
0600

FILE COPY
JOB NO.

START-UP REPORT
ZOELLER ENGINEERED PRODUCTS PUMPING SYSTEMS

I. PROJECT INFORMATION - Completed by Installing Contractor

JOB NAME: Cora Apts. LOCATION: 19 W. Harrison st. Sea, WA (Address/City, State)

ENGINEER: (Firm's Name) INSTALLING CONTRACTOR: One Way Plumbing (Company's Name)

START-UP: Hollabaugh Bros. (Company's name) 127 10th st S. Kirkland, WA (Address/City/State)

INSTALLATION DATE: 7-6-17 START UP DATE: 8-10-17

II. EQUIPMENT INFORMATION - Completed by Installing Contractor

Tag No. or Location I.D.: IX 161-B

PUMP NAMEPLATE DATA

P/N 161-0077 Model No.: IX 161 Voltage 208V Phase 1PH BHP 1/2 RATED FLA 8.8

Serial No. Pump 1: (or) Date of Mfg. Pump 1: 0417X

Serial No. Pump 2: (or) Date of Mfg. Pump 2: 0417X

Control Panel: 10-1297 Zoeller (Manufacturer) (Model No. Serial No.) Class 1 Div 1 Duplex (Type)

Float Switches: Zoeller (Manufacturer) (Model No.) 3 (Quantity)

Basin: 60" X 72" (Dimensions) Additional Information:

Pump Mount: ☐ Rail ☒ Free Standing ☐ Suspended

Installation Type: ☒ Field Assembled ☐ Pre Packaged

III. INSTALLER CHECKLIST - The following should be completed before start-up by installing contractor.

- ☒ Impeller turns freely by hand
- ☒ Pump rotation correct (3 phase only)
- ☒ Equipment in good condition
- ☒ Pit Clean
- ☒ Check valve, discharge pipe, and vent pipe installed
- ☒ 3/16" vent hole drilled in discharge pipe
- ☒ Access cover/Hatch Installed
- ☒ Panel securely installed and electrical connections tight
- ☒ Single phase starting capacitors installed
- ☒ Short circuit protections 10 Amps
- ☒ Thermal overload protections ____ Amps IN Panel
- ☒ Proper wiring connected to controller 14 Gage 35 Length
- ☒ Float positions from bottom of pit
  #1 30 in. (off) #2 40 in. (on) #3 ____ in. (Alarm/override) #4 50 in. (Alarm)

IV. START-UP VERIFICATION LIST

- ☒ To be check by the start up technician with installers assistance.
- ☒ Discharge pipe installed. 2 in.
- ☒ Vent pipe installed. 3 in.
- ☒ Check Valve installed in correct location and direction
- ☒ 3/16" vent hole drilled in discharge pipe
- ☒ Pit clean
- ☒ Access opening large enough for pump removal
- ☒ Panel and internal wiring securely installed
- ☒ Panel and junction box interior dry & sealed
- ☒ Power supply cable length 35 Ft.
- ☒ Float switches away from turbulence and hang-ups
- ☒ Low water level above volute top (#1 off switch)
- ☒ Pumps respond properly to hand-off-auto switch
- ☒ Alarm respond properly to test - off - normal switch
- ☒ Panel matches pump horsepower
- ☒ Circuit breakers operational
- ☒ Thermal overloads correctly set to match name plate amps
- ☒ Operator has installation and maintenance manual
- ☒ Operator has control panel schematic

V. ELECTRICAL READINGS:

SINGLE PHASE:	Pump #1	Pump #2
Voltage supply (Pump off)	~~L1-L2 212 V.~~ Q	~~L1-L2 212 V.~~ Q
Voltage supply (Pump on)	L1-L2 206 V.	L1-L2 206 V.
Amp draw (Pump on)	L1 8.2 A.	L1 8.2 A.
	L2 8.2 A.	L2 8.2 A.
THREE PHASE:		
Voltage Supply (Pump off)	L1-L2 ____ V.	L1-L2 ____ V.
	L2-L3 ____ V.	L2-L3 ____ V.
	L1-L3 ____ V.	L1-L3 ____ V.
Voltage Supply (Pump on)	L1-L2 ____ V.	L1-L2 ____ V.
	L2-L3 ____ V.	L2-L3 ____ V.
	L1-L3 ____ V.	L1-L3 ____ V.
Amp Draw (Pump on)	L1 ____ A.	L1 ____ A.
	L2 ____ A.	L2 ____ A.
	L3 ____ A.	L3 ____ A.

VI. FUNCTIONAL TEST

P1 98 GPM @ 15 'TDH
P2 98 GPM @ 15 'TDH

VII. SUMMARIZATION

COMMENTS:

I certify this start-up report to be accurate:

Justin Stenwick (Name) 8-10-17 (Date)

Others present during Start-Up:

- ☐ Engineer
- ☒ Contractor
- ☐ Operator
- ☐ Other

FILE COPY

© Copyright 2003 Zoeller Co. All rights reserved.