Schematic Key

Note that component names in schematic have been shortened for clarity; the 'CLA-' prefix and component type label ('-MAG-', '-DIA-', etc.) have been omitted. The full label format is as in this example: 'CLA-S01-MAG-DIP-01'.

Magnets

MAG-DIP
Rectangular Dipole Magnet

MAG-QUAD
Quadrupole Magnet

MAG-DIP
Sector Dipole Magnet

MAG-SEXT
Sextupole Magnet

MAG-SOL
Solenoid

MAG-HCOR/VCOR/HVCOR
Horizontal/Vertical/Horizontal and Vertical Corrector Magnet

Diagnostics

DIA-SCR
YAG Screen

DIA-ICT
Integrated Current Transformer

DIA-BPM
Beam Position Monitor

DIA-BAM
Beam Arrival Monitor

DIA-FCUP
Faraday Cup

DIA-WCM
Wall Current Monitor

Other Components

VAC-VALV
Vacuum Valve

DIA-COLL
Collimator

DIA-DCP
Dechirper

-CAV
RF Cavity


BEAM DIRECTION
GUN-BSOL-01
GUN-CAV-01
GUN-SOL-01
S01-HVCOR-01
S01-VALV-01
Light Box
S01-WCM-01
S01-BPM-01
S01-HVCOR-02
S01-SCR-01
L01-SOL-01
L01-CAV-01
L01-SOL-02
S02-HVCOR-01
S02-BPM-01
S02-QUAD-01
S02-VALV-01
S02-QUAD-02
S02-SCR-01
S02-HVCOR-02
S02-COLL-01
S02-HVCOR-03
S02-SCR-02
S02-QUAD-03
S02-QUAD-04
C2V-DIP-01
S02-BPM-02
S02-QUAD-05
S02-SCR-03
S02-HVCOR-04
L02-CAV
MODULE 1
MODULE 2
MODULE 3
Photoinjector Laser
C2V-BPM-01
C2V-HVCOR-01
C2V-QUAD-01
C2V-VALV-01
C2V-QUAD-02
C2V-QUAD-03
C2V-SCR-01
C2V-DIP-02
45°
SP1-BPM-01
SP1-HVCOR-01
SP1-QUAD-01
SP1-QUAD-02
SP1-SCR-01
SP1-FCUP-01
S01
S02
SP1


BEAM DIRECTION
L02-CAV
S03-BPM-01
S03-QUAD-01
S03-HVCOR-01
S03-SCR-01
L03-CAV
MODULE 5
MODULE 3
MODULE 4
S04-HVCOR-01
S04-QUAD-01
S04-ICT-01
S04-BPM-01
S04-QUAD-02
S04-VALV-01
S04-SCR-01
S04-QUAD-03
S04-BPM-02
S04-QUAD-04
S04-HVCOR-02
S04-SCR-02
S04-SCR-03
S04-BPM-03
S04-HVCOR-03
S04-BPM-04
S04-SCR-04
10m
S03
S04
20m


BEAM DIRECTION
L02-CAV
S03-BPM-01
S03-QUAD-01
S03-HVCOR-01
S03-SCR-01
L03-CAV
MODULE 5
MODULE 3
MODULE 4
S04-HVCOR-01
S04-QUAD-01
S04-ICT-01
S04-BPM-01
S04-QUAD-02
S04-VALV-01
S04-SCR-01
S04-QUAD-03
S04-BPM-02
S04-QUAD-04
S04-HVCOR-02
S04-SCR-02
S04-SCR-03
S04-BPM-03
S04-HVCOR-03
S04-BPM-04
S04-SCR-04
10m
S03
S04
20m


BEAM DIRECTION
S04-SCR-05
S04-QUAD-05
S04-HVCOR-04
S04-QUAD-06
S04-BPM-05
S04-QUAD-07
S04-HVCOR-05
S04-VALV-02
S04-QUAD-08
S04-BPM-06
L4H-CAV
VBC-DIP-01
VBC-HCOR-01
VBC-DIP-02
VBC-HCOR-02
VBC-BPM-01
VBC-VCOR-01
VBC-COLL-01
VBC-SCR-01
VBC-DIP-03
VBC-HCOR-03
VBC-DIP-04
VBC-HCOR-04
MODULE 8
MODULE 6
MODULE 7
S05-VALV-01
S05-QUAD-01
S05-ICT-01
S05-BPM-01
S05-HVCOR-01
S05-SCR-01
S05-BAM-01
S05-QUAD-02
S05-BPM-02
S06-BPM-01
S06-HVCOR-01
S06-QUAD-01
S06-BAM-01
S06-QUAD-02
S04
S05
VBC
30m
S06


BEAM DIRECTION
S04-SCR-05
S04-QUAD-05
S04-HVCOR-04
S04-QUAD-06
S04-BPM-05
S04-QUAD-07
S04-HVCOR-05
S04-VALV-02
S04-QUAD-08
S04-BPM-06
L4H-CAV
VBC-DIP-01
VBC-HCOR-01
VBC-DIP-02
VBC-HCOR-02
VBC-BPM-01
VBC-VCOR-01
VBC-COLL-01
VBC-SCR-01
VBC-DIP-03
VBC-HCOR-03
VBC-DIP-04
VBC-HCOR-04
MODULE 8
MODULE 6
MODULE 7
S05-VALV-01
S05-QUAD-01
S05-ICT-01
S05-BPM-01
S05-HVCOR-01
S05-SCR-01
S05-BAM-01
S05-QUAD-02
S05-BPM-02
S06-BPM-01
S06-HVCOR-01
S06-QUAD-01
S06-BAM-01
S06-QUAD-02
S04
S05
VBC
30m
S06


BEAM DIRECTION
S06-SCR-01
SP2-DIP-01
S06-VALV-01
S06-BPM-02
S06-HVCOR-02
S06-SCR-02
L04-CAV
S07-BPM-01
S07-HVCOR-01
S07-QUAD-01
S07-QUAD-02
S07-BPM-02
S07-HVCOR-02
S07-SCR-01
S07-TDC-01
S07-VALV-01
S07-BPM-03
S07-HVCOR-03
S07-QUAD-03
S07-QUAD-04
S07-BPM-04
S07-SCR-02
S07-QUAD-05
MODULE 9
MODULE 11
MODULE 8
MODULE 10
30°
SP2-HVCOR-01
SP2-BPM-01
SP2-SCR-01
SP2-QUAD-01
SP2-QUAD-02
SP2-HVCOR-02
SP2-BPM-02
SP2-SCR-02
SP2-FCUP-01
S07-HVCOR-04
S07-QUAD-06
S07-DCP-01
S07-BPM-05
SP2
S06
40m
S07


BEAM DIRECTION
S06-SCR-01
SP2-DIP-01
S06-VALV-01
S06-BPM-02
S06-HVCOR-02
S06-SCR-02
L04-CAV
S07-BPM-01
S07-HVCOR-01
S07-QUAD-01
S07-QUAD-02
S07-BPM-02
S07-HVCOR-02
S07-SCR-01
S07-TDC-01
S07-VALV-01
S07-BPM-03
S07-HVCOR-03
S07-QUAD-03
S07-QUAD-04
S07-BPM-04
S07-SCR-02
S07-QUAD-05
MODULE 9
MODULE 11
MODULE 8
MODULE 10
30°
SP2-HVCOR-01
SP2-BPM-01
SP2-SCR-01
SP2-QUAD-01
SP2-QUAD-02
SP2-HVCOR-02
SP2-BPM-02
SP2-SCR-02
SP2-FCUP-01
S07-HVCOR-04
S07-QUAD-06
S07-DCP-01
S07-BPM-05
SP2
S06
40m
S07

FEA


BEAM DIRECTION
S07-QUAD-07
S07-HVCOR-05
SP3-DIP-01
S07-HVCOR-06
S07-BPM-06
S07-SCR-03
S07-QUAD-08
S07-QUAD-09
S07-BPM-07
S07-HVCOR-07
S07-SCR-04
S07-QUAD-10
FEA-DIP-01
FEA-VALV-01
FEA-QUAD-01
FEA-QUAD-02
FEA-HVCOR-01
FEA-BPM-01
FEA-SCR-01
FEA-QUAD-03
FEA-SEXT-01
FEA-QUAD-04
FEA-BPM-02
FEA-DIP-02
FEA-QUAD-05
FEA-QUAD-06
FEA-HVCOR-02
FEA-BPM-03
FEA-SCR-02
FEA-QUAD-07
FEA-QUAD-08
FEA-BPM-04
MODULE 11
MODULE 12
MODULE F1
MODULE F2
MODULE F3
14°
14°
30°
SP3-VCOR-01
SP3-BPM-01
SP3-SCR-01
SP3-QUAD-01
SP3-QUAD-02
SP3-BPM-02
SP3-SCR-02
SP3-FCUP-01
SP3
S07-QUAD-11
S07-HVCOR-08
S07-BPM-08
S07-SCR-05
S07-FCUP-01
50m
S07

FEA


BEAM DIRECTION
S07-QUAD-07
S07-HVCOR-05
SP3-DIP-01
S07-HVCOR-06
S07-BPM-06
S07-SCR-03
S07-QUAD-08
S07-QUAD-09
S07-BPM-07
S07-HVCOR-07
S07-SCR-04
S07-QUAD-10
FEA-DIP-01
FEA-VALV-01
FEA-QUAD-01
FEA-QUAD-02
FEA-HVCOR-01
FEA-BPM-01
FEA-SCR-01
FEA-QUAD-03
FEA-SEXT-01
FEA-QUAD-04
FEA-BPM-02
FEA-DIP-02
FEA-QUAD-05
FEA-QUAD-06
FEA-HVCOR-02
FEA-BPM-03
FEA-SCR-02
FEA-QUAD-07
FEA-QUAD-08
FEA-BPM-04
MODULE 11
MODULE 12
MODULE F1
MODULE F2
MODULE F3
14°
14°
30°
SP3-VCOR-01
SP3-BPM-01
SP3-SCR-01
SP3-QUAD-01
SP3-QUAD-02
SP3-BPM-02
SP3-SCR-02
SP3-FCUP-01
SP3
S07-QUAD-11
S07-HVCOR-08
S07-BPM-08
S07-SCR-05
50m
S07
S07-FCUP-01


BEAM DIRECTION
FEA
MODULE F5
SHUTTER STAND
14°
MODULE F4
FEA-DIP-03
FEA-QUAD-09
FEA-QUAD-10
FEA-HVCOR-03
FEA-BPM-05
FEA-SCR-03-MASK
FEA-QUAD-11
FEA-SEXT-02
FEA-QUAD-12
FEA-BPM-06
FEA-DIP-04
FEA-BAM-01
FEA-QUAD-13
FEA-BPM-07
CTR Station
FEA-BPM-08
FEA-QUAD-16
FEA-HVCOR-05
FEA-VALV-02
FEA-HVCOR-06
FEA-BPM-09
FEA-SHTR-01
FEA-QUAD-14
FEA-ICT-01
FEA-SCR-04
FEA-HVCOR-04
FEA-QUAD-15
~3.7m

60m


BEAM DIRECTION
FEA
MODULE F5
SHUTTER STAND
14°
MODULE F4
FEA-DIP-03
FEA-QUAD-09
FEA-QUAD-10
FEA-HVCOR-03
FEA-BPM-05
FEA-SCR-03-MASK
FEA-QUAD-11
FEA-SEXT-02
FEA-QUAD-12
FEA-BPM-06
FEA-DIP-04
FEA-BAM-01
FEA-QUAD-13
FEA-BPM-07
CTR Station
FEA-BPM-08
FEA-QUAD-16
FEA-HVCOR-05
FEA-VALV-02
FEA-HVCOR-06
FEA-BPM-09
FEA-SHTR-01
FEA-QUAD-14
FEA-ICT-01
FEA-SCR-04
FEA-HVCOR-04
FEA-QUAD-15
~3.7m
60m

FEH


BEAM DIRECTION
FEH-BPM-01
FEH-QUAD-01
FEH-HVCOR-01
FEH-QUAD-02
FEH-HVCOR-02
FEH-SCR-01
FEH-VALV-01
Interaction Point (IP)
FEH-VALV-02
FEH-SCR-02
FEH-QUAD-03
FEH-HVCOR-03
FEH-QUAD-04
FEH-HVCOR-04
FEH-BPM-02
FEH-ICT-01
FEH-BPM-03
FEH-QUAD-05
FEH-HVCOR-05
FEH-QUAD-06
FEH-HVCOR-06
FEH-SCR-03
FEH-VALV-03
FEH-VALV-04
FEH-SCR-04
FEH-QUAD-07
FEH-HVCOR-07
FEH-QUAD-08
FEH-HVCOR-08
FEH-BPM-04
FMBOX1
MODULE F6A
FEC1
MODULE F6B
Laser Dump
FMBOX2
MODULE F6C
FEC2
MODULE F6D
~1.5m

70m

FEH


BEAM DIRECTION
FEH-BPM-01
FEH-QUAD-01
FEH-HVCOR-01
FEH-QUAD-02
FEH-HVCOR-02
FEH-SCR-01
FEH-VALV-01
Interaction Point (IP)
FEH-VALV-02
FEH-SCR-02
FEH-QUAD-03
FEH-HVCOR-03
FEH-QUAD-04
FEH-HVCOR-04
FEH-BPM-02
FEH-ICT-01
FEH-BPM-03
FEH-QUAD-05
FEH-HVCOR-05
FEH-QUAD-06
FEH-HVCOR-06
FEH-SCR-03
FEH-VALV-03
FEH-VALV-04
FEH-SCR-04
FEH-QUAD-07
FEH-HVCOR-07
FEH-QUAD-08
FEH-HVCOR-08
FEH-BPM-04
FMBOX1
MODULE F6A
FEC1
MODULE F6B
Laser Dump
FMBOX2
MODULE F6C
FEC2
MODULE F6D
~1.5m

70m


BEAM DIRECTION
MODULE F7
MODULE F8
FED
OTR
Station
FED-QUAD-01
FED-SHTR-01
FED-QUAD-02
FED-HVCOR-01
FED-BPM-01
FED-SCR-01
FED-DIP-01
FED-BPM-02
FED-QUAD-03
FED-SCR-02
FED-FCUP-01
80m


BEAM DIRECTION
MODULE F7
MODULE F8
FED
OTR
Station
FED-QUAD-01
FED-SHTR-01
FED-QUAD-02
FED-HVCOR-01
FED-BPM-01
FED-SCR-01
FED-DIP-01
FED-BPM-02
FED-QUAD-03
FED-SCR-02
FED-FCUP-01
80m