Clamp user guide

Clamp is an FFGL effect for Resolume Arena and Avenue that puts your picture through a video amplifier whose DC restoration has failed, so black wanders with the picture, a bright moment darkens the next one, and lines and fields tilt.

None of that is painted on. Your picture goes inside a real 625/50 or 525/59.94 television field (sync, back porch, the picture, front porch, the blank lines), the whole field runs through one coupling capacitor in real time, and you get the clamp that's supposed to put black back on every line, with a control for how badly it's doing its job. Every bit of the look falls out of that one circuit.



The repo's test card through the plugin at its defaults, rendered by the offline harness rather than captured from Resolume: 625/50, a coupling of 6.3 ms, a clamp that's all but given up, a little supply sag. The bright bars at the top charge the capacitor and push black down; the dark end of the ramp is crushed, and the dark ground lightens toward the bottom of the field as the charge bleeds away.

> **Before you rely on this:** it's **v0.1.0**, and still early days. The amplifier is measured rather than asserted, by a harness that drives the real plugin class and reads each claim back out of the picture it made. After a burst of white, black falls back on the RC's exponential with every blanking interval counted, with fitted time constants of 63.998 µs, 20.000 ms and 0.99999 s against 64 µs, 20 ms and 1 s stated. A flat field tilts 0.555906 across each line at a coupling of one line, the same as stated. Black moves 0.7481 per unit of average picture level at a one-second coupling, against the closed form. The clamp leaves 0.980199, 0.818731 and 0.135335 of the error behind each porch at 0.02, 0.2 and 2 time constants, e^{-n} to six places. Every pixel matches a serial double-precision run of the same timeline to within 2.3 float ULPs; host frame rates from 23.976 to 144 fps all land on one continuous trajectory; the supply's attack and recovery fit 0.040 s and 0.200 s against 0.04 and 0.2; and sixteen faults, put in on purpose, are shown to make those checks fail. All 13 controls are shown to change the picture. It's **never been loaded into Resolume on macOS**, where the one host it's run in is the fleet's own test host, `oxbow`, for 120 frames. On Windows, a build of v0.1.0 loads, registers and renders in Resolume Arena 7.27.1, with every control matching what the plugin declares, but on software rendering, so that says nothing about a GPU. Sag Attack and Sag Recovery couldn't be shown moving there, because the gate's picture is a still whose level never changes, so the supply never sags or recovers; the harness measures both. Try it on a spare layer before you put it in a show.
>
> This codebase was created with AI assistance, directed and reviewed by a human author.

Installing

Each download has one effect in it, **SW Clamp**. Drop it into Resolume's effects folder and restart Resolume:

```
macOS    ~/Documents/Resolume Arena/Extra Effects/
Windows  %USERPROFILE%\Documents\Resolume Arena\Extra Effects\
```

Avenue uses the same layout under its own folder name. The effect then shows up in the effects browser as **SW Clamp**.

The macOS download is a universal build (Apple silicon and Intel), as a `.dmg` or a `.zip`. It's **Developer ID-signed and notarised**, so the bundle just loads. The Windows download is an x64 installer or a `.zip`. It isn't code-signed, so the installer trips SmartScreen once: **More info** → **Run anyway**.

A capacitor does not pass DC

Analogue video amplifiers were joined to each other by capacitors. A capacitor passes change and blocks anything steady, and the steadiest thing in a video signal is its **black level**. So every stage lost it, and every stage had to put it back. The part that did that was the **clamp**: a switch that closed for a few microseconds at the start of every line, in the **back porch** just after sync, when the signal is known to be at black, and pulled it back to a reference. Black got restored fifteen thousand times a second, and nobody watching ever knew.

When the clamp gets weak, or dies, nothing puts black back. The capacitor settles instead to the **average** of whatever's passed through it recently, and everything is measured from that average. That's the whole effect:

- **Black wanders with the picture.** A bright scene raises the average, so black is pushed down and the shadows crush. A dark scene lowers it, and black lifts to grey.
- **A bright moment darkens the next one.** The capacitor charged up during the flash and takes time to let go, so what follows is darker until it has, and recovers on the capacitor's own curve.
- **Lines and fields tilt.** When the capacitor's time constant is near the length of a line, a flat area sags from left to right across each line. Near the length of a field, it sags from top to bottom down the picture.
- **A healthy clamp takes all of it out**, line by line, apart from the little its own switch can't finish in the time the porch gives it.

"Recently" is set by one control, **Coupling**, and it's real time: the capacitor runs through every line and every blanking interval of the field, fifty or sixty fields a second, in order. The blanking counts. For about a quarter of every field the signal is at blanking level, not picture, and the capacitor averages that too. That's why, with a dead clamp, black moves by about three quarters of the picture's average level rather than all of it.

Two separate things sit on top, as they did in the old kit. The **power supply sags** when the picture is bright and recovers when it isn't, so the whole picture breathes with the content, and an optional **triode stage** clips one side hard and the other softly.

Start here

Put SW Clamp **on a layer** (not on a clip), with footage that cuts between bright and dark. The defaults are a coupling of 6.3 ms (about a third of a field) and a clamp that's all but given up, so out of the box black already wanders and every field tilts: a bright top half darkens the bottom half below it. A still picture settles and stays settled. **The effect shows on changing footage**, because most of what it does is what the picture was doing a moment ago.

Why the layer? An effect on a clip belongs to that clip, so the next clip you trigger arrives with its own copy of the effect, already settled to its own picture. On the layer, the capacitor sees the cut,

and the bright clip before it.

Then:

1. **Coupling → about 0.9, Clamp Health → 0.** A coupling of about 0.6 s and no clamp at all. Cut from something bright to something dark: the dark clip arrives crushed and climbs back over the next second or so. Cut the other way and it arrives washed out and sinks. A white flash leaves a dark hole behind it.
2. **Coupling → about 0.1.** A coupling of about one line. Now each line forgets its own start before it reaches the end: flat areas sag toward the reference from left to right, and a bright shape leaves a dark trail to its right.
3. **Clamp Health → 1, Clamp Reference → 0.25, Sag Depth → 0.** A working amplifier: black is back at black, and the picture is very nearly the clip again. Now bring Clamp Health down slowly. That's a failing clamp as a performance control.
4. **Per Channel on**, with the clamp weak. Red, green and blue each get their own capacitor, so a strongly coloured scene pushes its own colour down and black takes the opposite tint.
5. **Sag Depth up, Sag Recovery long.** The whole picture dims when it gets bright and takes its time to come back: a pump on every cut to white.

Clamp Reference at 0.25, not 0. The slider's default, halfway, is a reference of **+0.25**, not black. That's on purpose: it's where a failed clamp's picture sits in view, with dark scenes lifting and bright ones pushing black down, which is the look everyone remembers from a set without DC restoration. But it also means a *healthy* clamp puts black at a quarter grey. For black at black when the clamp is working, set Clamp Reference to **0.25 on the slider**, a quarter of the way along, which is a reference of 0.

Every slider is declared to the host as 0 to 1, so the host only knows its position. The value each position stands for is given with each control below.

Time is real time, not frames

The raster runs on the host's clock, in seconds. A 625/50 field lasts 1/50 s and a 525/59.94 field 1001/60000 s whatever your composition's frame rate is, and every time constant here is in seconds. So the same settings give the same look at 30 fps and at 60, and the harness checks that directly: host rates from 23.976 to 144 fps all follow one continuous run to within 1.3e-7.

When the composition runs slower than the field rate, several fields pass between two frames. They all run, on the one picture there is; the capacitor doesn't skip them. When it runs faster, some frames fall inside a field that's already on show, and that field is shown again with the new picture. Rendering the same moment twice doesn't move the capacitor on.

A backwards step in the host's clock, or a gap of more than half a second (a scrub, a loop, a stall), isn't believed: the raster steps on by one sixtieth of a second and carries on from there, so it never jumps. If the host's clock stops, the raster stops with it.

The first frame after the effect loads starts from the picture's own steady state, as if it had been running on that picture for ever, so loading it doesn't open with a settle that belongs to nothing. A change of resolution changes nothing the capacitor holds.

The Coupling group

The capacitor itself, and the television system it sits in.

Coupling: the capacitor's time constant, τ, from **20 µs to 2 s**, on a logarithmic slider where every fifth of the way is ten times longer. Default **0.5, which is 6.3 ms**. This is how far back the capacitor remembers, and it decides which of the looks you get:

Slider	τ	What it looks like with the clamp dead
0	20 µs, a third of a line	each line keeps only its changes: flat areas sag to the reference within a fraction of the line, and a bright shape's right-hand edge dips dark
about 0.1	about 63 µs, a line	lines tilt: a flat white line sags by more than half from left to right
0.5	6.3 ms, a third of a field	the default: the top of the picture sets the level for the bottom
0.6	20 ms, a 625/50 field	fields tilt top to bottom, but only gently: 1–7% on Resolume's demo clips; the field before still counts. The clearest field tilt is nearer the default
about 0.94	1 s	black breathes with the content over a second; a flash darkens what follows
1	2 s	slow drift, a hundred fields long

After a bright moment, the charge it left decays as e^(−t/τ): about a third is left after one τ, about a seventh after two.

Standard: 625/50 (PAL) or **525/59.94 (NTSC)**; 625/50 by default. The television field your picture is placed in, with its real line timing: 64 µs lines, 288 picture lines and 50 fields a second for 625/50; 63.56 µs lines, 240 picture lines and 59.94 fields a second for 525/59.94. It changes where the blanking falls and how often the clamp gets a chance, and it changes how many lines the capacitor runs on: 288 or 240, whatever the height of your picture. Your picture's own detail is kept either way; only the capacitor's state is at the field's line count. Switching Standard starts the new system's fields from that moment and keeps the capacitor's charge.

Per Channel: off by default. Off, the amplifier works on brightness: the capacitor follows the picture's luma (Rec. 601) and the same offset is taken from red, green and blue, so black wanders but colours keep their differences. On, red, green and blue are three separate amplifiers with three capacitors, and each wanders on its own: a mostly red scene pushes red down and the shadows

go cyan. All three are always running underneath, so switching Per Channel never makes the picture jump.

The Clamp group

Clamp Health: how strongly the clamp pulls the signal back in each back porch, as time constants of the clamp's own switch per porch. **0 is dead**: the switch never closes. Above that, every fifth of the slider is ten times stronger, up to **20 time constants a porch at 1**, which leaves e^{-20} of the error behind: a perfect clamp. Default **0.2, which is 0.002 time constants a porch**, a clamp that's all but given up.

Slider	per porch	error left after each porch
0	none	all of it: the clamp is dead
0.2	0.002	99.8%
0.4	0.02	98.0%
0.6	0.2	81.9%
0.8	2	13.5%
1	20	effectively none

Even a weak clamp gets a porch on every line, fifteen thousand or so a second, so it adds up: at the default it would put black back over about 32 ms on its own (by arithmetic, on 625/50), which is why the default coupling, at 6.3 ms, still wins. The strength is per porch, so a setting means the same clamp on either Standard. Between dead and healthy, the clamp and the coupling fight it out, the clamp pulling black back every line and the coupling pulling the average there, and this is the slider to ride live.

Clamp Reference: where black is put back, from **−0.25 to +0.75**: 0 is at a quarter of the slider, and the default, halfway, is **+0.25**. It does two jobs, because in the circuit the next stage's input returns to the same reference as the clamp:

- **With a healthy clamp** it's just the black level. At the default, black sits at a quarter grey; at 0.25 on the slider it's black. Below that, black is pushed under the floor and the shadows crush.
- **With a weak or dead clamp** it's the level the picture's **average** is forced to. Higher, and the whole picture rides up, with more room before bright scenes push black off the bottom; lower, and dark scenes stay dark and bright ones crush sooner.

See **Start here** for why the default is +0.25 and not 0.

The Supply group

A separate mechanism from the clamp: the power supply sagging under load. The supply follows the picture's **average brightness** (the luma of the incoming picture over its active area), and the amplifier's gain drops as it rises. The gain multiplies everything, black level included, so a bright picture comes out dimmer overall, not just brighter in the highlights.

Sag Depth: how far the gain falls at a fully white picture, from **0 to 0.5**: the gain is 1 − depth × the average. Default **0.3 on the slider, a depth of 0.15**: an all-white picture comes out at 85%. At 0 the supply is perfect and the other two controls do nothing.

Sag Attack: how quickly the supply follows a picture that gets **brighter**, as a time constant from **5 ms to 2 s** on a logarithmic slider; the middle is 0.1 s. Default **0.35, about 41 ms**: a cut to white dims within a couple of frames.

Sag Recovery: how quickly it comes back when the picture gets **darker**, on the same range. Default **0.6, about 0.18 s**. Make it long for a picture that stays dimmed after every bright moment and creeps back.

The supply moves once per field, so it runs at 50 or 59.94 steps a second whatever your frame rate. It follows the input, not what the amplifier puts out.

The Stage group

An optional valve stage after the amplifier. It's a look: its curve is the textbook shape of a triode, not a measured valve.

Triode On: off by default. Bias and Drive do nothing while it's off.

Bias: the valve's operating point, from **−0.6 (toward cutoff) to +0.6 (toward grid current)**; the middle, the default, is 0. The dark side of the signal runs into **cutoff**, a hard knee: below it the valve conducts nothing and the shadows flatten to a single level. The bright side runs into **grid current**, a soft knee: the highlights round off gradually. Bias moves the operating point toward one knee or the other.

Drive: how hard the signal is pushed into the valve, from **0.5 to 4**, logarithmic; **1 at a third of the way, the default**. The stage is normalised so that mid-grey stays mid-grey and small changes around it keep their size, so Drive decides how far the picture reaches into the two knees, not how bright it is. At the default the curve is gentle. Toward 4 the shadows flatten hard onto a floor that sits well above black, and the highlights and saturated colours compress.

Triode On lifts black; it doesn't crush it. The floor is where the stage's output lands when the valve is cut off and passes nothing, and it comes from that normalisation: mid-grey is pinned at mid-grey with the curve's slope there made 1, so zero current comes out at mid-grey less the current at the operating point divided by Drive times that slope, rather than at black. How far above black that is depends on Drive and Bias (by arithmetic from the stage's law, not measured):

Drive, Bias	a black input comes out at	the cutoff floor
1, 0 (the defaults)	about 7% grey	below black, never reached
2, 0	about 17% grey	about 17% grey: black is at cutoff
4, 0	about 33% grey	about 33% grey
4, −0.6 (toward cutoff)	about 43% grey	about 43% grey
4, +0.6 (toward grid current)	about 9% grey	about 9% grey

So even at the defaults, turning the triode on raises black slightly; at high Drive, or with Bias toward cutoff, the whole bottom of the picture sits on a flat grey. Bias toward grid current brings the floor back down, and at low Drive with Bias toward grid current it goes below black again, where the output's clip to black does the crushing instead.


The Output group

Mix: the amplified picture against the untouched clip, 0 to 1; **1 by default**. Zero is the clip as it arrived. The capacitor keeps running underneath whatever Mix says. The output always carries the clip's own alpha.

Show Blanking: off by default. Instead of your picture, it draws **the whole field** as the capacitor saw it, stretched to fill the output: each line from left to right starting at sync, then the back porch where the clamp closes, the picture, and the front porch; every line of the field from top to bottom, with the blank lines and the final half line below the picture. Sync is drawn at its tip, in black, so you can see it.

It isn't a faithful picture of the signal. It's scaled and lifted so you can see what happens below black: the view shows a quarter grey plus three quarters of the signal (after the supply's gain), so blanking level is drawn at a quarter grey and full white still reaches white, with the range between squeezed into the top three quarters. With Per Channel off (the default) it's also **luma only**: the whole raster, picture included, is drawn in monochrome, because with Per Channel off the amplifier only has one channel. With Per Channel on it's drawn in colour, one channel per capacitor.

It's a way to watch the circuit working (the porch pulling back toward the reference, the charge sagging across the blanking), and it's a look in its own right. It's a diagnostic, though, and behaves like one: the Stage group and Mix don't apply to it, and its output is opaque.



The same frame as the hero with Show Blanking on: sync at the left edge, the porch where the clamp closes, the active line, the front porch, and the vertical blanking below, with the half line along the bottom, stopping halfway. Rendered by the offline harness.

How it works

Once a frame:

1. **Sum.** The GPU reads your picture along the field's picture lines (288 or 240, each taking the row of your picture under its centre) and for every run of 16 samples works out how much those samples would add to the capacitor's charge. Your picture's width is the sample rate across the line. These sums are read back to the CPU.
2. **Walk.** The CPU runs the field in time order, in double precision: sync, back porch (where the clamp pulls at the Clamp Health rate), the picture 16 samples at a time, front porch, then the blank lines and the half line. Every step is the capacitor's exact response to what it was given, not an approximation of it.
3. **Schedule.** From the host's clock it works out which field is under way. Every field that began since the last frame is run on this picture; the last one is the one shown. The supply steps once per field.
4. **Fill.** The GPU works out the capacitor's charge at every sample of the field on show, from the charge at the start of each run of 16.
5. **Display.** Each pixel of your picture, minus the charge on its line at its position, plus the Clamp Reference, times the supply's gain; then the triode if it's on, then clipped to black and white, then Mix. Or, with Show Blanking, the whole field instead.

The only thing carried from one frame to the next is the capacitor's charge in each channel and the supply's state, which is a handful of numbers on the CPU. Nothing on the GPU outlives a frame.

Performance

Measured by the offline harness on an M4 Max at the defaults, best of three runs of 60 frames after a warm-up, on a GPU shared with other work (single runs moved by up to 2×):

	ms/frame	% of a 60 fps frame	Per Channel + Triode
1280×720	0.36	2.2%	0.43
1920×1080	0.41	2.4%	0.41
3840×2160	0.82	4.9%	0.77

It's cheap, and the settings barely change it. Most of the cost is the one read back from the GPU every frame, which makes the CPU wait for the sums. That's on purpose, because the walk needs them. The capacitor runs on 288 or 240 lines whatever the height of the picture. GPU memory, by arithmetic rather than measurement, is about 10 MB at 1080p and 20 MB at 4K on 625/50. I haven't timed it inside Resolume, or on Windows.

If it looks wrong

Nothing seems to happen, or it's just a bit darker. A still picture settles and holds. Give it footage that changes, cut between bright and dark, and turn Clamp Health down to 0. Check Mix.

Black is grey, even with the clamp healthy. That's the default Clamp Reference of +0.25. Set it to 0.25 on the slider for black at black.

The shadows crush after anything bright. That's the effect: the bright picture pushed black down. Raise Clamp Health, raise Clamp Reference, or shorten Coupling so the capacitor forgets sooner.

The whole picture dims on bright scenes and comes back slowly. Sag Depth, and a long Sag Recovery.

Black has a colour cast. Per Channel is on.

Bias and Drive do nothing. Triode On is off.

Black is lifted to grey as soon as Triode On is on. That's the stage's floor: it's normalised about mid-grey, so a signal at black comes out above black (slightly at the defaults, a third grey at Drive 4). See the Stage group.

Black is a flat grey and the shadows have no detail. Triode On with Drive high, or Bias toward cutoff: the dark side is at cutoff, on the floor. Lower Drive, or move Bias toward grid current.

Show Blanking is black and white, washed out, and Mix does nothing to it. That's all intended. With Per Channel off the view is luma only; turn Per Channel on to see it in colour. It's always lifted by a quarter so blanking and anything below black show, so its levels aren't your picture's. The Stage group and Mix don't apply to it. See Show Blanking.

Fine horizontal steps at a very short Coupling. The capacitor runs on 288 lines (240 on 525/59.94), so on a 1080-row picture each of its lines covers three or four rows. At a coupling near a line, where every line differs, that can show.

The picture jumped when I scrubbed or looped. It shouldn't: a jump in the host's clock steps the raster on by one sixtieth of a second. If the clock stops, the raster stops, and the picture holds its level.

SW Clamp isn't in the effects browser. Check the folder under Installing, and that Resolume was restarted.

The effect does nothing at all. A shader that won't compile looks just like that, and the actual message is in the log:

```
macOS    ~/Library/Logs/clamp/clamp.YYYY-MM-DD.log
Windows  %LOCALAPPDATA%\clamp\logs\clamp.YYYY-MM-DD.log
```

It records the build that was loaded, the GL vendor, renderer and version at load, which shader failed if one did, a buffer that couldn't be allocated, and at frame 60 the host's clock and the unit the plugin decided it's in.

Known limits

- **Never loaded into Resolume on macOS**, and nothing has driven the controls in a host there. How the thirteen controls read in the inspector, and what Resolume's clock does to the raster over a long session, are untested.
- **Never seen on camera footage.** Apart from the harness's synthetic cards, it's only been run on Resolume's bundled demo loops, through the harness, for the release video.
- **The triode stage and Show Blanking are looks**, checked only for being alive, not measured.
- **The fields aren't interlaced.** Each field covers the whole picture on 288 or 240 lines, top to bottom, with the real field period. It only matters at a coupling of about a line.
- **Sync sits at blanking level** in the circuit, not at its tip, so it doesn't pull the average down the little a real sync pulse would. It's only drawn at its tip in Show Blanking.
- **The capacitor is driven by 288 or 240 rows of your picture**, not all of them. Your picture's detail is kept; the charge is at the field's line count.

- **Below the field rate, the fields no frame shows run on the picture of the frame after them**, up to a frame early.
- **The supply follows the input's average**, not what the amplifier draws.
- **Checked at up to 1920×1080**, and only timed at 4K.
- **On a Mac I've only run it on Apple silicon** (an M4 Max, and CI's macOS runner), although the macOS build contains an Intel slice. On Windows, see the note at the top of this guide.
- **No presets, no audio input** and no OpenFX version.
- **There's a browser demo** at clamp-demo.stoatworks-labs.com. It's a port to a web page rather than the plugin: the shaders run in WebGL2 and any CPU half is rewritten in JavaScript. The page lists what it doesn't reproduce.

About

The last group, **About**, has the plugin's name, version, licence and maker, and buttons that open this user guide (stoatworks-labs.com/software/clamp/guide/), the project page, the source on GitHub and the support page in your browser.

Reporting something

Open an issue at github.com/stoatworks-labs/clamp/issues. A screenshot, the Coupling, Clamp Health, Clamp Reference and Standard settings, and the composition's resolution and frame rate are usually enough to go on. If the effect did nothing, attach the log.
