Cora Controls

A dramatically simplified end user's guide.




Button 6: Shoot Ball

Button 8: Start/Stope ball intake rollers



Button 5: Set Arm Angle. Toggles 0 or 60 Degree arm position

> Button 7: Eject Ball using Rollers



Space Bar: Emergency stop (Robot will require power cycle to restart)