

HPE 1820 24p

HPE 1820 8p



HPE 1820 24p



Reset כפתור

נורות חיווי

מספר+נורה קבועה = מהירות **1000 מגה**
מספר + נורה מהבהבת = **מהירות 100 מגה**
מספר ללא נורה = **10 מגה**

PORT 10\100\1000

HPE 1820 8p



Reset כפתור

PORT 10\100\1000

נורות חיווי

מספר+נורה קבועה = מהירות **1000 מגה**
מספר + נורה מהבהבת = מהירות **100 מגה**
מספר ללא נורה = **10 מגה**

ניתן לחבר את המתג עם
POE וללא ספק כח

ממשק כניסה

HPE OfficeConnect Switch
1820 24G
J9980A

Username

Password

Log In

[Support](#)

Copyright © 2010-2016 Hewlett Packard Enterprise
Development LP.

USER – admin
ללא - Pass

שינוי סיסמא

- Dashboard
- Setup Network
- Switching
- VLAN
- Trunks
- LLDP
- LLDP-MED
- Security
- Green Features
- Diagnostics
- Maintenance
 - Password Manager
 - Backup and Update Manager
 - Dual Image Configuration

Password Manager

Help

Username	admin	(1 to 64 characters)
Current Password		(8 to 64)
New Password		(8 to 64)
Confirm New Password		(8 to 64)

Apply

Refresh


Cancel

שינוי סיסמא

הגדרות ראשוניות

Hewlett Packard
Enterprise

> Dashboard



Save Configuration

Log Out

Dashboard

- Setup Network
- Switching
- VLAN
- Trunks
- LLDP
- LLDP-MED
- Security
- Green Features
- Diagnostics
- Maintenance

Dashboard

Help

System Information

System Description	HPE OfficeConnect Switch 1820 24G J9980A, PT.02.06, Linux 3.6.5, U-Boot 2012.10-00119 (Aug 31 2018 - 10:12:27)		
System Name		(0 to 64 characters)	
System Location		(0 to 255 characters)	
System Contact		(0 to 255 characters)	
System Object ID	1.3.6.1.4.1.11.2.3.7.11.168		
System Up Time	0 days, 6 hours, 36 mins, 26 secs		
Current Time	06:36:26		
Date	January 01, 1970		

שינוי שם אתר (אנגלית)

שינוי שם אתר (אנגלית)

Device Information

Software Version	PT.02.06
Operating System	Linux 3.6.5
Serial Number	CN95GMW6BG

System Resource Usage



הגדרות ראשוניות – שינוי כתובת IP

Dashboard

Setup Network

Get Connected

System Time

Switching

VLAN

Trunks

LLDP

LLDP-MED

Security

Green Features

Diagnostics

Maintenance

Get Connected

Network Details

Protocol Type	☒ Static ☐ DHCP 🔗
IP Address	10.0.0.249 (x.x.x.x)
Subnet Mask	255.255.255.0 (x.x.x.x)
Gateway Address	10.0.0.138 (x.x.x.x)
MAC Address	38:21:C7:94:D4:60

Web Parameters

Session Timeout (Minutes)	5 (1 to 60)
---------------------------	--

Management Access

Management VLAN ID	1
Management Port	None

SNMP

SNMP	☒ Enabled ☐ Disabled
Community Name	public (1 to 20 characters)

V2860_20200109_....cfg

שינוי כתובת IP
הגדרה - STATIC

לאחר שינוי כתובת יש להתחבר בכתובת החדשה.
יש לחוץ על SAVE CONFIGURATION בצד ימין למעלה
יש לעשות זאת מעת לעת בזמן הגדרות המכשיר

הגדרות ראשוניות – הגדרת LOOP PROTECTION

לחיצה על CONFIGRETION

שינוי ל-25

Switching > Loop Protection > Status

Save Configuration Log Out

Status Configuration

Loop Protection Status

Display 25 rows Showing 1 to 25 of 34 entries Filter:

Interface	Loop Protection	Configured Action Taken	Tx Mode	Loop Count	Status	Loop	Time of Last Loop
1	Disabled	Shutdown Port	Enabled	0	Link Down		01/01/1970 00:00:00
2	Disabled	Shutdown Port	Enabled	0	Link Down		01/01/1970 00:00:00
3	Disabled	Shutdown Port	Enabled	0	Link Down		01/01/1970 00:00:00
4	Disabled	Shutdown Port	Enabled	0	Link Up		01/01/1970 00:00:00
5	Disabled	Shutdown Port	Enabled	0	Link Down		01/01/1970 00:00:00
6	Disabled	Shutdown Port	Enabled	0	Link Down		01/01/1970 00:00:00
7	Disabled	Shutdown Port	Enabled	0	Link Down		01/01/1970 00:00:00
8	Disabled	Shutdown Port	Enabled	0	Link Up		01/01/1970 00:00:00
9	Disabled	Shutdown Port	Enabled	0	Link Up		01/01/1970 00:00:00
10	Disabled	Shutdown Port	Enabled	0	Link Up		01/01/1970 00:00:00
11	Disabled	Shutdown Port	Enabled	0	Link Down		01/01/1970 00:00:00
12	Disabled	Shutdown Port	Enabled	0	Link Down		01/01/1970 00:00:00
13	Disabled	Shutdown Port	Enabled	0	Link Down		01/01/1970 00:00:00
14	Disabled	Shutdown Port	Enabled	0	Link Up		01/01/1970 00:00:00
15	Disabled	Shutdown Port	Enabled	0	Link Down		01/01/1970 00:00:00
16	Disabled	Shutdown Port	Enabled	0	Link Down		01/01/1970 00:00:00
17	Disabled	Shutdown Port	Enabled	0	Link Down		01/01/1970 00:00:00
18	Disabled	Shutdown Port	Enabled	0	Link Down		01/01/1970 00:00:00
19	Disabled	Shutdown Port	Enabled	0	Link Up		01/01/1970 00:00:00
20	Disabled	Shutdown Port	Enabled	0	Link Down		01/01/1970 00:00:00
21	Disabled	Shutdown Port	Enabled	0	Link Up		01/01/1970 00:00:00
22	Disabled	Shutdown Port	Enabled	0	Link Up		01/01/1970 00:00:00
23	Disabled	Shutdown Port	Enabled	0	Link Up		01/01/1970 00:00:00
24	Disabled	Shutdown Port	Enabled	0	Link Up		01/01/1970 00:00:00
25	Disabled	Shutdown Port	Enabled	0	Link Down		01/01/1970 00:00:00

First Previous 1 2 Next Last

Refresh

הגדרות ראשוניות – הגדרת LOOP PROTECTION

סימון All

enable

Status

Configuration

Loop Protection Configuration

Help

Loop Protection

☒ Enabled ☐ Disabled

Transmission Time (Seconds)

5 (1 to 10)

Shutdown Time (Seconds)

180 (0 to 604800)

Display 25 rows

Showing 1 to 25 of 34 entries

Filter:

	Loop Protection	Action	Tx Mode	Status	Loop	Time of Last Loop
1	Disabled	Shutdown Port	Enabled	Link Down		01/01/1970 00:00:00
2	Disabled	Shutdown Port	Enabled	Link Down		01/01/1970 00:00:00
3	Disabled	Shutdown Port	Enabled	Link Down		01/01/1970 00:00:00
4	Disabled	Shutdown Port	Enabled	Link Up		01/01/1970 00:00:00
5	Disabled	Shutdown Port	Enabled	Link Down		01/01/1970 00:00:00
6	Disabled	Shutdown Port	Enabled	Link Down		01/01/1970 00:00:00
7	Disabled	Shutdown Port	Enabled	Link Down		01/01/1970 00:00:00
8	Disabled	Shutdown Port	Enabled	Link Up		01/01/1970 00:00:00
9	Disabled	Shutdown Port	Enabled	Link Up		01/01/1970 00:00:00
10	Disabled	Shutdown Port	Enabled	Link Up		01/01/1970 00:00:00
11	Disabled	Shutdown Port	Enabled	Link Down		01/01/1970 00:00:00
12	Disabled	Shutdown Port	Enabled	Link Down		01/01/1970 00:00:00
13	Disabled	Shutdown Port	Enabled	Link Down		01/01/1970 00:00:00
14	Disabled	Shutdown Port	Enabled	Link Up		01/01/1970 00:00:00
15	Disabled	Shutdown Port	Enabled	Link Down		01/01/1970 00:00:00
16	Disabled	Shutdown Port	Enabled	Link Down		01/01/1970 00:00:00
17	Disabled	Shutdown Port	Enabled	Link Down		01/01/1970 00:00:00
18	Disabled	Shutdown Port	Enabled	Link Down		01/01/1970 00:00:00
19	Disabled	Shutdown Port	Enabled	Link Up		01/01/1970 00:00:00
20	Disabled	Shutdown Port	Enabled	Link Down		01/01/1970 00:00:00
21	Disabled	Shutdown Port	Enabled	Link Up		01/01/1970 00:00:00
22	Disabled	Shutdown Port	Enabled	Link Up		01/01/1970 00:00:00
23	Disabled	Shutdown Port	Enabled	Link Up		01/01/1970 00:00:00
24	Disabled	Shutdown Port	Enabled	Link Up		01/01/1970 00:00:00
25	Disabled	Shutdown Port	Enabled	Link Down		01/01/1970 00:00:00

First

Previous

1

2

Next

Last

Apply

Refresh

Edit

Edit All

Edit all

הגדרות ראשוניות – הגדרת LOOP PROTECTION

הפעלה

לחודא !!!

Edit Loop Protection Port Configuration

NOTE: Configuration will be applied to all interfaces.

Loop Protection ☒ Enabled ☐ Disabled

Action Shutdown Port ▼

Tx Mode ☒ Enabled ☐ Disabled

Apply Cancel

הגדרת VLAN

VLAN Configuration

Display **All** rows

Showing 1 to 3 of 3 entries

Filter:

☐	↕ VLAN ID	↕ Name	↕ Type
☐	1	default	Default
☐	20	beecomm	Static
☐	30	guest	Static

First Previous 1 Next Last

Refresh

Add

Edit

Remove

Copyright © 2010-2016 Hewlett Packard Enterprise Development LP.

בחירת ה-VLAN ולחיצה על
עדיית לשינוי שם ממספר ה
VLAN לתפקיד ה-VLAN

2

Edit VLAN Configuration

VLAN ID 20
Name (1 to 32 characters)

Apply

Cancel

1

מס ה-VLAN TAG שהוגדר
בראשית

Add VLAN

VLAN ID or Range

Enter VLAN ID in the range 2 to 4093.
Use '-' to specify a range and ',' to separate VLAN IDs or
VLAN ranges in the list.

Apply

Cancel

הגדרת VLAN

Dashboard

Setup Network

Switching

VLAN

- Configuration
- Port Membership
- Port Configuration

Trunks

LLDP

LLDP-MED

Security

Green Features

Diagnostics

Maintenance

VLAN Port Membership

VLAN ID

Display 25 rows

Showing 1 to 25 of 34 entries

☐	Interface	Participation/Tagging
☐	1	Excluded
☐	2	Excluded
☐	3	Excluded
☐	4	Excluded
☐	5	Excluded
☐	6	Excluded
☐	7	Excluded
☐	8	Excluded
☐	9	Excluded
☐	10	Excluded
☐	11	Excluded
☐	12	Excluded
☐	13	Untagged
☐	14	Untagged
☐	15	Untagged
☐	16	Untagged
☐	17	Untagged
☐	18	Untagged
☐	19	Untagged
☐	20	Untagged
☐	21	Untagged
☒	22	Untagged
☒	23	Untagged
☒	24	Untagged
☐	25	Untagged

First Previous 1 2 Next Last

Refresh Edit Edit All

בחירת ה-VLAN הרלוונטי

1

בחירת הפורטים אותם
נרצה לשנות

2

הגדרת VLAN

Tagged = פורטים מתוויגים , מחייבים שהמכשיר שמחובר אליהם ידע לזהות את התיוג , מתאים למתג מנוהל שמחובר למתג ראשי או ל-AP

Untagged = כל פורט אותו נרצה לחבר למכשירים אשר אינם יודעים לזהות תיוג , מתאים למדפסות בונים , NVR , מכשירי מוזיקה וכו'

Excluded = כל פורט שאינו משויך לאותו VLAN

VLAN 1 = default vlan – כל הפורטים מפורט 12 ומעלה מסומנים ב Untagged

VLAN 20 = BeeComm \ Tabit – פורטים 22,23,24 מסומנים ב Tagged

פורטים 13-21 מסומנים ב Untagged

VLAN 20 =Guest – פורטים 22,23,24 מסומנים ב Tagged

הגדרת מתג

יש לחוץ על SAVE CONFIGURATION בצד ימין למעלה