









讴歌						
MDX [YD]	MDX 3.7	09.06-08.13	12V, 80Ah, 680A		0 986 A02 613	
奥迪						
A4 [8E2, B6]	A4 1.8 T A4 2.0 T	11.03-01.09 09.05-02.09	12V, 77Ah, 790A 12V, 77Ah, 790A			0 092 S57 060 0 092 S57 060
	A4 2.4 i	04.03-02.07	12V, 70Ah, 570A	0 092 S37 399	0.000.400.040	0 032 337 000
		04.03→	12V, 70Ah, 650A 12V, 70Ah, 570A	0 092 S37 399	0 986 A02 618	
A4 [8EC, B7]	A4 2.0 TFSI	09.05-06.08	12V, 70Ah, 650A 12V, 48Ah, 450A	0 092 S37 402	0 986 A02 618	
			12V, 55Ah, 450A 12V, 55Ah, 500A	0 092 S37 393	0 986 A02 818	
			12V, 60Ah, 400A 12V, 72Ah, 700A	0 986 A02 789	0 986 A02 822	
A41	AAL 1 O.T.	00.00	12V, 74Ah, 680A			0 986 A02 334
A4L	A4L 1.8 T	06.09→	12V, 72Ah, 700A 12V, 80Ah, 720A		0 986 A02 822 0 986 A02 341	
	A4L 2.0 i	11.08-07.14	12V, 72Ah, 700A		0 986 A02 822	
	A4L 2.0 T	11.08→	12V, 72Ah, 700A		0 986 A02 822	
		01.14→	12V, 110Ah, 850A		0 986 A02 340	
A5 [8F7] 敞篷轿车	A5 3.2 FSI 敞篷轿车	03.09-03.12	12V, 74Ah, 680A			0 986 A02 334
A5 [8T3] 轿跑	A5 2.0 TFSI 轿跑 A5 3.2 FSI 轿跑	06.08-05.13 06.07-03.12	12V, 74Ah, 680A 12V, 110Ah, 850A			0 986 A02 334 0 986 A02 340
A5 [8TA] 运动掀背车	A5 3.0 TDI	05.09-05.10	12V, 110Ah, 830A			0 092 S50 130
AG [GIA] 250 MA F	运动掀背四驱车	00.00 00.10	124, 100/11, 000/1			0 002 000 100
A6 [4B, C5]	A6 1.8 T	01.01-07.08	12V, 70Ah, 570A	0 092 S37 399		
			12V, 70Ah, 650A		0 986 A02 618	
		01.01.00.10	12V, 100Ah, 830A		0.000.400.000	0 092 S50 130
		01.01-06.12	12V, 72Ah, 700A 12V, 100Ah, 760A		0 986 A02 822	0 986 A02 337
	A6 2.4 i	09.99-09.05	12V, 70Ah, 570A	0 092 S37 399		0 300 AUZ 331
	7.0 2.41	00.00 00.00	12V, 70Ah, 650A	0 002 001 000	0 986 A02 618	
			12V, 72Ah, 700A		0 986 A02 822	
			12V, 74Ah, 680A			0 986 A02 334
	AC 2 0 :	11.07-11.08	12V, 72Ah, 700A	0.000.007.000	0 986 A02 822	
	A6 2.8 i	01.98-09.05	12V, 70Ah, 570A 12V, 70Ah, 650A	0 092 S37 399	0 986 A02 618	
			12V, 72Ah, 700A		0 986 A02 822	
			12V, 100Ah, 760A			0 986 A02 337
			12V, 100Ah, 830A			0 092 S50 130
A6 [4F2, C6]	A6 1.8 T	01.01-06.10	12V, 72Ah, 700A		0 986 A02 822	
	A6 2.4	03.05-10.08	12V, 72Ah, 700A 12V, 77Ah, 790A		0 986 A02 822	0 092 S57 060
			12V, 80Ah, 640A	0 092 S37 401		0 032 337 000
			12V, 80Ah, 720A			0 986 A02 341
			12V, 88Ah, 600A		0 986 A02 823	
			12V, 100Ah, 760A			0 986 A02 337
	A6 2.4 i	01.01-06.03	12V, 100Ah, 830A 12V, 85Ah, 760A			0 092 S50 130 0 986 A02 336
	A0 2.41	01.01 00.05	12V, 88Ah, 600A		0 986 A02 823	0 300 A02 330
	A6 2.5 D	01.01-06.02	12V, 100Ah, 760A			0 986 A02 337
	A6 2.8 i	02.01→	12V, 100Ah, 760A			0 986 A02 337
A6L	A6L 2.0 T	01.01-08.12	12V, 85Ah, 760A		0.000.400.000	0 986 A02 336
		02.12→	12V, 88Ah, 600A 12V, 72Ah, 700A		0 986 A02 823 0 986 A02 822	
	A6L 2.5 i	12.11→	12V, 72Ah, 700A		0 986 A02 822	
	A6L 2.7 TDI	01.01-01.14	12V, 100Ah, 760A			0 986 A02 337
	A6L 2.8 i	09.08-08.12	12V, 80Ah, 720A		0 986 A02 341	
	A61.2.0	12.11	12V, 72Ah, 700A		0 986 A02 822	
	A6L 3.0 A6L 3.0 i	09.08-06.14 03.05-12.07	12V, 72Ah, 700A 12V, 85Ah, 760A		0 986 A02 822	0 986 A02 336
	AUE 0.0 I	00.00-12.07	12V, 88Ah, 600A		0 986 A02 823	3 300 A02 330
	A6L 3.1 i	08.06-09.09	12V, 85Ah, 760A			0 986 A02 336
			12V, 88Ah, 600A		0 986 A02 823	


















4	<u>_</u>	R	参数	S3	S4	S5
•		4411	少奴	动能	动力神	银侠
A6L	A6L 4.2 i	08.05-08.06	12V, 85Ah, 760A			0 986 A02 336
10[15 00]	100050	00 07 07 10	12V, 88Ah, 600A		0 986 A02 823	
A8 [4E, D3]	A8 2.8 FSI A8 3.0	09.07-07.10 07.03-05.06	12V, 110Ah, 850A		0 986 A02 824	0 986 A02 340
	A0 3.0	07.03-05.06	12V, 100Ah, 800A 12V, 110Ah, 850A		U 900 AUZ 024	0 986 A02 340
	A8 3.2 FSI	06.05-07.10	12V, 100Ah, 760A			0 986 A02 337
			12V, 100Ah, 800A		0 986 A02 824	
			12V, 110Ah, 850A			0 986 A02 340
	A8 3.2 FSI 四驱	06.05-07.10	12V, 100Ah, 760A			0 986 A02 337
	AO 4 O MI III	44.00.05.00	12V, 110Ah, 850A	0.000.007.000		0 986 A02 340
	A8 4.2 四驱	11.02-05.06	12V, 70Ah, 570A 12V, 100Ah, 760A	0 092 S37 399		0 986 A02 337
			12V, 100Ah, 700A		0 986 A02 824	0 900 A02 331
			12V, 110Ah, 850A		0 000 702 024	0 986 A02 340
	A8 6.0 四驱	02.04-07.10	12V, 100Ah, 800A		0 986 A02 824	
			12V, 110Ah, 850A			0 986 A02 340
Q3 [8U]	Q3 2.0 i	11.12→	12V, 72Ah, 700A		0 986 A02 822	
Q5 [83B]	Q5 2.0 TFSI quattro	11.09→	12V, 72Ah, 700A		0 986 A02 822	
Q7 [4LB]	Q7 3.0 TDI	09.07-05.10	12V, 100Ah, 800A		0 986 A02 824	0.006.402.240
	Q7 3.0 TFSI	05.10-08.15	12V, 110Ah, 850A 12V, 110Ah, 850A			0 986 A02 340 0 986 A02 340
	Q7 3.6 FSI	03.07-05.10	12V, 110Ah, 800A		0 986 A02 824	0 300 A02 340
	Q7 0.01 0.	00.07 00.10	12V, 110Ah, 850A		0 0007102 02 1	0 986 A02 340
	Q7 4.2 FSI	03.06-05.10	12V, 100Ah, 760A			0 986 A02 337
			12V, 100Ah, 800A		0 986 A02 824	
			12V, 110Ah, 850A			0 986 A02 340
R8 [423]	R8 4.2 FSI 四轮驱动	04.07-09.10	12V, 110Ah, 850A			0 986 A02 340
DO [400]	R8 5.2 FSI 四轮驱动	09.12→ 07.12→	12V, 110Ah, 850A 12V, 110Ah, 850A			0 986 A02 340 0 986 A02 340
R8 [429]	R8 5.2 FSI Spyder quattro		, , , , , , , , , , , , , , , , , , , ,			
S5 [8F7] 敞篷轿车	S5 3.0 TFSI 敞篷四驱车	05.09-03.12	12V, 74Ah, 680A			0 986 A02 334
TT [8J3] Coupe	TT 2.0 TFSI Coupe	07.06-06.10	12V, 80Ah, 640A	0 092 S37 401		
			12V, 80Ah, 720A			0 986 A02 341
			12V, 88Ah, 600A		0 986 A02 823	
TT [8N3] 双门	TT 3.2 Coupe quattro	07.03-06.06	12V, 60Ah, 400A	0 986 A02 789		
宝骏						
630	630 1.5 i	03.11→	12V, 55Ah, 610A		0 986 A02 826	
030	030 1.31	03.11	12V, 63Ah, 610A		0 092 S47 192	
	630 1.8 i	05.12→	12V, 55Ah, 610A		0 986 A02 826	
			12V, 63Ah, 610A		0 092 S47 192	
730	730 1.5 i	04.14→	12V, 55Ah, 610A		0 986 A02 826	
			12V, 63Ah, 610A		0 092 S47 192	
乐驰	乐驰 0.8 i	10.03-03.09	12V, 36Ah, 180A	0 092 \$37 381		
	乐驰 1.0 i	06.04-01.09	12V, 36Ah, 180A	0 092 S37 381	0.000 400 704	
			12V, 36Ah, 310A 12V, 40Ah, 340A		0 986 A02 781	
		01.10→	12V, 40AH, 340A 12V, 55Ah, 610A		0 092 S47 181 0 986 A02 826	
		01.10	12V, 63Ah, 610A		0 092 S47 192	
	乐驰 1.2 i	06.08→	12V, 36Ah, 180A	0 092 S37 381		
			12V, 36Ah, 310A		0 986 A02 781	
			12V, 40Ah, 340A		0 092 S47 181	
宝龙						
菱麒	菱麒 2.4 i	12.03-04.05	12V, 80Ah, 680A		0 986 A02 612	
				V	V	•
				BOSCH	BOSCH	BOSCH

讴歌 · 奥迪 · 宝骏 · 宝龙



















参数

S3 动能 S4 动力神 S5 银侠

北京汽车						
E130	E130 1.3 i	01.12→	12V, 60Ah, 520A		0 092 S37 380	
E150	E150 1.5 i	01.12→	12V, 60Ah, 520A		0 092 S37 380	
幻速 S3	幻速 S3 1.5 i	01.14→	12V, 60Ah, 520A		0 092 S37 406	
陆霸	陆霸 2.2 i 2032	01.01-06.02	12V, 45Ah, 225A	0 092 S37 385		
	陆霸 2.4 i 2032	01.01-06.08	12V, 60Ah, 400A		0 986 A02 789	
			12V, 60Ah, 450A	0.000.007.000	0 092 S47 101	
	陆霸 2.7 i 2400	01.01.05.00	12V, 60Ah, 520A 12V, 45Ah, 225A	0 092 \$37 380		
	陆霸 2.7 1 2 4 0 0 一	01.01-05.08	12V, 45Ah, 225A	0 092 S37 385 0 092 S37 385		
	陆霸 3.4 i 2032	01.01-06.02	12V, 45Ah, 225A 12V, 65Ah, 465A	0 092 331 303	0 092 S47 102	
	FM 400 0.41 2002	01.01 00.02	12V, 65Ah, 550A		0 986 A02 604	
威旺	威旺 1.3 i	12.10→	12V, 45Ah, 350A	0 092 S37 384		
	威旺 1.5 i MPV	05.13→	12V, 55Ah, 550A		0 092 S37 396	
			12V, 55Ah, 610A		0 986 A02 826	
			12V, 63Ah, 610A		0 092 S47 192	
威旺 205	威旺 205 1.0 i	09.12→	12V, 45Ah, 350A		0 092 \$37 383	
威旺 306	威旺 306 1.2 i	08.12→	12V, 55Ah, 550A		0 092 S37 396	
战旗	战旗 2.2 i	01.01-07.11	12V, 60Ah, 290A	0.000.007.400	0 092 S47 103	
			12V, 60Ah, 450A 12V, 60Ah, 475A	0 092 S37 433	0 986 A02 793	
			12V, 60Ah, 520A		0 986 A02 607	
			12V, 60Ah, 550A		0 092 S47 189	
	战旗 2.8 D	01.01→	12V, 60Ah, 290A		0 092 S47 103	
			12V, 60Ah, 475A		0 986 A02 793	
			12V, 60Ah, 520A		0 986 A02 607	
骑士	骑士 2.0 i	02.07-05.14	12V, 80Ah, 680A		0 986 A02 612	
	骑士 2.2 i	01.01-11.12	12V, 80Ah, 680A		0 986 A02 612	
宾利						
大陆 GT	大陆 GT 6.0	06.03-10.10	12V, 93Ah, 680A			0 092 S57 027
飞驰	飞驰 4.0 V8	02.14→	12V, 100Ah, 830A			0 092 S50 130
	飞驰 6.0 W12	03.13-05.15	12V, 100Ah, 830A			0 092 S50 130
欧陆 GT	欧陆 GT 4.0 V8		12V, 100Ah, 830A			0 092 S50 130
雅致	雅致 6.8 V8 T	04.02-08.08	12V, 93Ah, 680A			0 092 S57 027
慕尚	慕尚 6.8	09.09-05.15	12V, 100Ah, 830A			0 092 S50 130
奔腾						
B50	B50 1.6 i	09.08→	12V, 65Ah, 490A		0 986 A02 791	
			12V, 65Ah, 520A	0 092 S37 418		
B70	B70 2.0 i	04.06-06.14			0 986 A02 791	
	D70.0.0.	04.00.44.44	12V, 65Ah, 520A	0 092 S37 418	0.000 1.00 701	
	B70 2.3 i	04.06-11.11	12V, 65Ah, 490A 12V, 65Ah, 520A	0 092 S37 418	0 986 A02 791	
X80	X80 2.0 i	12.12→	12V, 70Ah, 550A	0 032 337 410	0 092 S37 420	
宝马						
1[E87]	120 i	06.08-06.11	12V, 72Ah, 700A		0 986 A02 822	
3 [E 46]	318 i	09.01-03.04	12V, 55Ah, 500A	0 092 S37 393		
			12V, 74Ah, 680A			0 986 A02 334
			12V, 88Ah, 600A		0 986 A02 823	
	325 i	11.03-08.05	12V, 85Ah, 760A			0 986 A02 336
	0.10.007	10.05.55	12V, 88Ah, 600A		0 986 A02 823	
3 [E 90]	318 2.0 i	12.09-07.11	12V, 88Ah, 600A		0 986 A02 823	0.006.600.004
	318 i 320 i	10.08-12.09 03.05-12.11	12V, 62Ah, 480A 12V, 85Ah, 760A			0 986 A02 331 0 986 A02 336
	3201	03.05-03.14	12V, 88Ah, 600A		0 986 A02 823	0 300 AUZ 330
	325 i	09.06-01.13	12V, 62Ah, 480A		3 300 A02 023	0 986 A02 331
	328 Li 2.0	08.07-07.08	12V, 88Ah, 600A		0 986 A02 823	
	M 3	11.07-10.11	12V, 85Ah, 760A			0 986 A02 336
3 [E 92] 轿跑	325 i 轿跑	09.06-06.13	12V, 77Ah, 790A			0 092 S57 060
	M3轿跑	05.07-06.13	12V, 74Ah, 680A			0 986 A02 334
a Fee a a S (N) See Let a L	0.05 (1) (2) (3)		12V, 77Ah, 790A			0 092 S57 060
3 [E 93] 敞篷轿跑	325 i 敞篷轿跑	03.07-09.13	12V, 74Ah, 680A			0 986 A02 334
			12V, 77Ah, 790A			0 092 S57 060














	_			00	0.4	0.5
			参数	S3	S4	S5
		411	2 22	动能	动力神	银侠
3 [F 30]	316 1.6 i	06.13→	12V, 88Ah, 600A		0 986 A02 823	
3 [F 35]	320 2.0 i 320 Li 2.0 i	11.12→ 03.12→	12V, 88Ah, 600A 12V, 80Ah, 720A		0 986 A02 823 0 986 A02 341	
3 [F 33]	328 Li 2.0 i	03.12→	12V, 88Ah, 600A		0 986 A02 823	
	335 Li 3.0 T	03.12→	12V, 88Ah, 600A		0 986 A02 823	
5 [E 60]	520 i	01.04-11.05	12V, 85Ah, 760A		0 300 A02 023	0 986 A02 336
0[200]	0201	01.0111.00	12V, 88Ah, 600A		0 986 A02 823	0 0007102 000
	520 Li	02.09-10.10	12V, 110Ah, 850A			0 986 A02 340
		01.10-06.13	12V, 88Ah, 600A		0 986 A02 823	
	523 Li	03.06-08.10	12V, 85Ah, 760A			0 986 A02 336
			12V, 88Ah, 600A		0 986 A02 823	
	525 i	01.04-06.06	12V, 85Ah, 760A			0 986 A02 336
	F0F1:	00.05.05.40	12V, 88Ah, 600A		0 986 A02 823	0.000.400.000
	525 Li	08.05-05.10	12V, 85Ah, 760A 12V, 88Ah, 600A		0 986 A02 823	0 986 A02 336
	530 i	10.04-11.05	12V, 85Ah, 760A		U 900 AUZ 023	0 986 A02 336
	5501	10.04-11.05	12V, 88Ah, 600A		0 986 A02 823	0 900 A02 330
		03 05-02 10	12V, 80Ah, 720A		0 300 A02 023	0 986 A02 341
		00.00 02.10	12V, 100Ah, 760A			0 986 A02 337
			12V, 110Ah, 850A			0 986 A02 340
	530 Li	08.05-05.14	12V, 85Ah, 760A			0 986 A02 336
			12V, 88Ah, 600A		0 986 A02 823	
	550 i	09.05-02.10	12V, 80Ah, 640A	0 092 S37 401		
			12V, 80Ah, 720A			0 986 A02 341
			12V, 88Ah, 600A		0 986 A02 823	
			12V, 100Ah, 760A			0 986 A02 337
5 [5 64] 按尔斯	ME按信用	02.07.00.10	12V, 110Ah, 850A			0 986 A02 340
5 [E 61] 旅行版 5 [F 10]	M 5 旅行版	03.07-08.10 01.12→	12V, 110Ah, 850A		0 986 A02 823	0 986 A02 340
2 [t 10]	520 Li 2.0 i 523 i	03.10-08.11	12V, 88Ah, 600A 12V, 88Ah, 600A		0 986 A02 823	
	525 Li 2.0 i	07.12→	12V, 88Ah, 600A		0 986 A02 823	
5 [F 18]	520 Li 2.0	03.12-03.14	12V, 88Ah, 600A		0 986 A02 823	
	528 Li 3.0 i	04.10-12.12	12V, 80Ah, 800A		0 092 S67 053	
	535 Li	04.10→	12V, 88Ah, 600A		0 986 A02 823	
6 [E 63]	630 i	09.04-07.10	12V, 85Ah, 760A			0 986 A02 336
			12V, 110Ah, 850A			0 986 A02 340
	M 6	03.05-07.10	12V, 85Ah, 760A			0 986 A02 336
7.[5.00]	705.11	04.00.40.00	12V, 110Ah, 850A			0 986 A02 340
7 [E 38]	725 tds	01.96-12.00	12V, 100Ah, 830A			0 092 \$50 130
	730 d 735 i,iL	08.98-12.01 09.94-10.01	12V, 100Ah, 830A 12V, 85Ah, 760A			0 092 S50 130 0 986 A02 336
	7 33 I,IL	09.94-10.01	12V, 100Ah, 760A			0 986 A02 337
			12V, 100Ah, 830A			0 092 S50 130
7 [E 66]	730 Li	04.05-10.08	12V, 100Ah, 800A		0 986 A02 824	0 002 000 200
			12V, 110Ah, 850A			0 986 A02 340
	745 Li	03.02-03.05	12V, 85Ah, 760A			0 986 A02 336
			12V, 100Ah, 760A			0 986 A02 337
			12V, 100Ah, 830A			0 092 S50 130
			12V, 110Ah, 850A			0 986 A02 340
	7501:	03.02-10.08	12V, 100Ah, 800A		0 986 A02 824	0.000.000.000
	750 Li 760 Li	04.05-10.08	12V, 85Ah, 760A			0 986 A02 336
	/ OU LI	12.02-10.08	12V, 85Ah, 760A 12V, 100Ah, 760A			0 986 A02 336 0 986 A02 337
			12V, 100Ah, 760A 12V, 100Ah, 800A		0 986 A02 824	0 300 AUZ 337
			12V, 100Ah, 830A		0 000 H02 024	0 092 S50 130
			12V, 110Ah, 850A			0 986 A02 340
X 1 [E 84]	X 1 sDrive 2.0	10.11-08.14	12V, 85Ah, 760A			0 986 A02 336
	X 1 xDrive 2.0	10.11-10.12	12V, 85Ah, 760A			0 986 A02 336
	X 1 xDrive 2.0 4X4	06.12→	12V, 85Ah, 760A			0 986 A02 336
X 3 [E 83]	X 3 2.5 si	09.06-08.08	12V, 80Ah, 640A	0 092 S37 401		
	VO D : 05:	00.00.00.15	12V, 100Ah, 830A		0.000 / 00.00	0 092 S50 130
	X 3 xDrive 25 i	09.08-08.10	12V, 100Ah, 800A		0 986 A02 824	0.000 050 420
			12V, 100Ah, 830A			0 092 S50 130
				+	+	+
					O BOICH	E BOSCH
				0	(a) BOSCH	(BOSCH
				⊜ BOSCH	S4 Preceptor	S5 Mega Power Silver

宝马 ・ 别克 ・ 比亚迪 ▶

北京汽车 ・ 宾利 ・ 奔腾 ・ 宝马 ・ 别克 ・ 比亚迪







S3








S5

		31	参数	- 33 动能	34 动力神	银侠
	1-4	سا		4JI HE	多りが	抵1大
宝马(接上页)						
X5[E 53]	X 5 3.0 i	10.99-09.06	12V, 85Ah, 760A			0 986 A02 336
			12V, 100Ah, 760A 12V, 100Ah, 800A		0 986 A02 824	0 986 A02 337
	X 5 4.4 i	10.03-10.06	12V, 100Ah, 830A 12V, 85Ah, 760A			0 092 S50 130 0 986 A02 336
	X 5 4.4 I	10.03-10.06	12V, 100Ah, 760A			0 986 A02 337
			12V, 100Ah, 830A			0 092 S50 130
X 5 [E 70]	X 5 4.8 i	11.06-09.08	12V, 85Ah, 760A 12V, 100Ah, 830A			0 986 A02 336 0 092 S50 130
X 6 [E 71]	X 6 xDrive 35 i	03.08-03.10	12V, 100Ah, 830A			0 092 S50 130
Z 3 [E 36/7]	Z 3 3.0 i	05.00-06.02	12V, 74Ah, 680A			0 986 A02 334
Z 4 [E 89]	Z 4 sDrive 23 i	04.09-08.11	12V, 60Ah, 580A		0 986 A02 827	
别克						
GL 8	GL8 2.4 i	09.12→	12V, 66Ah, 550A	0 092 S37 395		
	GL 8 2.4 i	08.10-09.13	12V, 66Ah, 550A	0 092 S37 395		
	GL 8 2.5 i	01.01-11.10	12V, 60Ah, 550A	0 000 007 005	0 986 A02 825	
	GL 8 3.0 i	01.01-10.10	12V, 66Ah, 550A 12V, 60Ah, 550A	0 092 S37 395	0 986 A02 825	
	GE 0 0.01	01.01→	12V, 66Ah, 550A	0 092 S37 395	0 0007102 020	
君威	君威 1.6 T	08.09→	12V, 60Ah, 550A		0 986 A02 825	
		11.02-05.08	12V, 66Ah, 550A 12V, 60Ah, 550A	0 092 S37 395	0 986 A02 825	
	石 灰 2.01	11.02-03.08	12V, 66Ah, 550A	0 092 S37 395	0 900 A02 623	
		09.08→	12V, 60Ah, 550A		0 986 A02 825	
		05.00	12V, 66Ah, 550A	0 092 S37 395	0.000 400 005	
	君威 2.0 T	05.09→	12V, 60Ah, 550A 12V, 66Ah, 550A	0 092 S37 395	0 986 A02 825	
	君威 2.4 i	09.08-01.11	12V, 60Ah, 550A	0 032 331 333	0 986 A02 825	
			12V, 66Ah, 550A	0 092 S37 395		
	君威 2.5 i	11.02-02.08	12V, 60Ah, 550A 12V, 66Ah, 550A	0 092 S37 395	0 986 A02 825	
		12.02-03.06	12V, 60Ah, 550A	0 092 537 595	0 986 A02 825	
	777		12V, 66Ah, 550A	0 092 S37 395		
	新君威 2.4 i	08.10-08.14	12V, 72Ah, 700A		0 986 A02 822	
君越	君越 2.4 i	12.05-01.11	12V, 45Ah, 310A 12V, 55Ah, 550A	0 092 S37 396	0 092 S47 130	
			12V, 55Ah, 610A	0 032 331 330	0 986 A02 826	
			12V, 63Ah, 610A		0 092 S47 192	
	君越 3.0 i	12.05-04.14	12V, 60Ah, 550A 12V, 66Ah, 550A	0 092 S37 395	0 986 A02 825	
	新君越 2.0 T	09.09→	12V, 45Ah, 310A	0 032 331 333	0 092 S47 130	
	新君越 2.4 i	08.10→	12V, 60Ah, 580A		0 092 S47 193	
바미 ±#	₩П ±#\ 4 C :	10.10	101/ 5545 0104		0 986 A02 827	
凯越	凯越 1.5 i	10.12→	12V, 55Ah, 610A 12V, 63Ah, 610A		0 986 A02 826 0 092 S47 192	
	凯越 1.6 i	01.03-06.09	12V, 55Ah, 550A	0 092 S37 396		
			12V, 55Ah, 610A		0 986 A02 826	
		08.03-03.13	12V, 63Ah, 610A 12V, 55Ah, 550A	0 092 S37 396	0 092 S47 192	
		00.00 00.10	12V, 55Ah, 610A	0 002 001 000	0 986 A02 826	
	un ela . · ·	01.00.00	12V, 63Ah, 610A		0 092 S47 192	
	凯越 1.8 i	01.03-12.09	12V, 55Ah, 550A 12V, 55Ah, 610A	0 092 S37 396	0 986 A02 826	
			12V, 63Ah, 610A		0 092 S47 192	
凯越旅行版	凯越旅行版 1.8 i	05.05-09.09	12V, 55Ah, 550A	0 092 S37 396		
			12V, 55Ah, 610A		0 986 A02 826	
昂科拉	昂科拉 1.4 T	07.12→	12V, 63Ah, 610A 12V, 60Ah, 580A		0 092 S47 192 0 092 S47 193	
					0 986 A02 827	
林荫大道	林荫大道2.8i	01.07-09.09	12V, 48Ah, 450A	0 092 \$37 402		
			12V, 55Ah, 450A 12V, 72Ah, 700A	0 092 S37 392	0 986 A02 822	
	林荫大道3.0i	08.09-12.12	12V, 48Ah, 450A	0 092 S37 402	3 555 1102 022	
			12V, 55Ah, 450A	0 092 S37 392		
	林荫大道 3.6 i	01.07-08.09	12V, 72Ah, 700A 12V, 48Ah, 450A	0 092 S37 402	0 986 A02 822	
	170月八起 3.01	01.07-00.09	12V, 48AH, 45UA 12V, 55Ah, 45OA	0 092 537 402		
			12V, 72Ah, 700A		0 986 A02 822	
英朗 GT	英朗 GT 1.6 i	03.10→	12V, 60Ah, 580A		0 092 \$47 193	
	英朗 GT 1.8 i	03.10→	12V, 60Ah, 580A		0 986 A02 827 0 092 S47 193	
	MM OI TOI	00.10 /	121, OUAII, JOUA		0 986 A02 827	
















北京汽车・ 宾利・ 奔腾・ 宝马・ 别克・ 比亚迪

















S3 动能 S4 动力神 S5 银侠

凯迪拉克						
CTS	CTS 2.8 i	07 04-06 12	12V, 74Ah, 680A			0 986 A02 334
SRX	SRX 3.0 i	01.13→	12V, 72Ah, 700A		0 986 A02 822	0 000 702 004
XTS	XTS 2.0	09.12→	12V, 72Ah, 700A		0 986 A02 822	
赛威	赛威 2.0 i		12V, 72Ah, 700A		0 986 A02 822	
	赛威 2.8 i	11.06-10.09	12V, 72Ah, 700A		0 986 A02 822	
	赛威 3.0 i	11.09-09.12	12V, 72Ah, 700A		0 986 A02 822	
长安						
СМ8	CM8 1.3 i	07 04-07 08	12V, 36Ah, 180A	0 092 S37 381		
CIVIO	CIVIO 1.31	07.04-07.00	12V, 36Ah, 310A	0 032 337 301	0 986 A02 781	
		06.05-11.06	12V, 45Ah, 325A		0 986 A02 786	
CS35	CS35 1.6 i	03.12→	12V, 60Ah, 580A		0 092 S47 193	
	0000 1.01	00.12	121,007,0007.		0 986 A02 827	
CS75	CS75 2.0 i	10.13→	12V, 60Ah, 580A		0 986 A02 617	
CX20	CX20 1.3 i	06.10-08.14	12V, 45Ah, 325A		0 986 A02 786	
			12V, 48Ah, 450A		0 092 S47 184	
	CX20 1.4 i	02.13→	12V, 45Ah, 325A		0 986 A02 786	
			12V, 48Ah, 450A		0 092 S47 184	
CX30	CX30 1.6 i	03.10-06.14	12V, 60Ah, 580A		0 986 A02 827	
		01.11-06.14			0 092 S47 193	
长安	长安 0.8 i	06.01-11.11	12V, 45Ah, 325A		0 986 A02 786	
			12V, 48Ah, 450A		0 092 S47 184	
		01.08→	12V, 45Ah, 350A	0 092 S37 384		
	长安 1.0 i	05.02→	12V, 45Ah, 325A		0 986 A02 786	
	1		12V, 45Ah, 350A	0 092 S37 384		
	长安 1.2 i	06.12→	12V, 45Ah, 350A	0 092 S37 384		
	长安 1.3 i	05.10→	12V, 60Ah, 580A		0 986 A02 617	
	V #1 4 0 D	01.11→	12V, 45Ah, 350A	0 092 S37 384	0.000 100 700	
	长安 1.8 D	11.01-04.05	12V, 45Ah, 325A		0 986 A02 786	
	长安 2.2 D	12.05-12.11 06.01-06.11	12V, 45Ah, 325A		0 986 A02 786	
	长女 2.20	09.03-04.09	12V, 45Ah, 325A 12V, 36Ah, 180A	0 092 S37 381	0 986 A02 786	
		09.03-04.09	12V, 36Ah, 310A	0 032 337 361	0 986 A02 781	
	长安 2.3 D	11.04-04.09	12V, 36Ah, 180A	0 092 S37 381	0 300 A02 101	
	N X 2.00	11.0101.00	12V, 36Ah, 310A	0 002 00. 002	0 986 A02 781	
	长安 2.4 i	11.03→	12V, 45Ah, 325A		0 986 A02 786	
		08.06-05.10	12V, 70Ah, 640A	0 986 A02 332		
	长安 2.5 D	03.01-06.09	12V, 36Ah, 180A	0 092 S37 381		
			12V, 36Ah, 310A		0 986 A02 781	
		12.03→	12V, 45Ah, 325A		0 986 A02 786	
	长安 2.5 i	07.04-09.10	12V, 70Ah, 640A	0 986 A02 332		
	长安 2.7 D	07.02-06.09	12V, 45Ah, 325A		0 986 A02 786	
		11.06→	12V, 70Ah, 640A	0 986 A02 332		
	V # 0 0 D	05.10→	12V, 45Ah, 325A	0.000.100.000	0 986 A02 786	
	长安 2.8 D 长安 3.2 D	03.06→	12V, 70Ah, 640A	0 986 A02 332		
	太女 3.20	$08.05-12.08$ $06.07 \rightarrow$	12V, 70Ah, 640A 12V, 45Ah, 325A	0 986 A02 332	0 986 A02 786	
	长安 3.3 D	10.02→	12V, 45Ah, 325A		0 986 A02 786	
	长安 3.4 D	07.03-09.08	, , , , , ,	0 986 A02 332	0 300 MUZ 100	
	N. J.	11.03→	12V, 75Ah, 325A	0 300 A02 332	0 986 A02 786	
		04.02-09.08	12V, 45Ah, 325A		0 986 A02 786	
	长安 3.7 D		12V, 70Ah, 640A	0 986 A02 332		
		06.07→	12V, 45Ah, 325A		0 986 A02 786	
	长安 3.7 i	02.07-01.10	12V, 45Ah, 325A		0 986 A02 786	
	长安 3.8	02.07-11.10	12V, 70Ah, 640A	0 986 A02 332		
	长安 3.9 D	07.03→	12V, 45Ah, 325A		0 986 A02 786	
		08.03-07.08	12V, 70Ah, 640A	0 986 A02 332		
	长安 4.1 D	12.02-04.05	12V, 45Ah, 325A		0 986 A02 786	
1	长安 4.3 D	09.03-11.05	12V, 45Ah, 325A		0 986 A02 786	
长安之星	长安之星 0.8 i	04.07-06.08	12V, 45Ah, 325A		0 986 A02 786	
	长安之星1.0i	01.98-04.11	12V, 45Ah, 350A	0 092 S37 384	0.000 100 701	
		08.03-12.10	12V, 45Ah, 325A	0.000.007.004	0 986 A02 786	
		08.03-09.13	12V, 36Ah, 180A	0 092 S37 381	0.000 400 704	
			12V, 36Ah, 310A		0 986 A02 781	
		06.05.10.10	12V, 40Ah, 340A		0 092 \$47 181	
		06.05-12.10 10.10-03.14	12V, 48Ah, 450A 12V, 45Ah, 325A		0 092 S47 184 0 986 A02 786	
	长安之星 1.2 i	06.12→	12V, 45Ah, 325A		0 986 A02 786	
	以外汇至 1.21	00.12	12V, 48Ah, 450A		0 092 S47 184	
			12 V, HUAII, HUUA		3 032 347 104	















		A	参数	S3 动能	S4 动力神	S5 银侠
	7-4	سا		初肥	多りが	抵沃
长安之星	长安之星 1.3 i	08.03-09.08	12V, 36Ah, 180A	0 092 S37 381		
以女 之生	以父之生1.31	06.03-09.06	12V, 36Ah, 310A	0 092 337 361	0 986 A02 781	
			12V, 45Ah, 350A	0 092 S37 384	0 000 702 702	
			12V, 45Ah, 325A		0 986 A02 786	
			12V, 48Ah, 450A		0 092 S47 184	
		02.09-03.11		0 092 S37 384	0.000 100 700	
		07.11→	12V, 45Ah, 325A 12V, 48Ah, 450A		0 986 A02 786 0 092 S47 184	
	长安之星Ⅱ1.0i	12 06-06 14	12V, 45Ah, 350A	0 092 S37 384	0 092 547 104	
	NX2211101	01.08-10.09	12V, 45Ah, 325A	0 002 001 001	0 986 A02 786	
		10.08→	12V, 45Ah, 350A	0 092 S37 384		
	长安之星Ⅱ1.3i	12.06-10.09	12V, 48Ah, 450A		0 092 S47 184	
	レウカ目 C4C0 1 0:	12.06-03.10	12V, 45Ah, 325A		0 986 A02 786	
	长安之星 S460 1.0 i	10.08-08.11	12V, 45Ah, 325A 12V, 48Ah, 450A		0 986 A02 786 0 092 S47 184	
	长安之星 S460 1.3 i	02.09→	12V, 45Ah, 325A		0 986 A02 786	
	VX2101001101	02.00	12V, 48Ah, 450A		0 092 S47 184	
运通	运通 0.8 i	09.03-10.08	12V, 36Ah, 180A	0 092 S37 381		
	\ - \ - \	00.00.10.	12V, 36Ah, 310A		0 986 A02 781	
	运通 1.0 i	09.03-10.08	12V, 36Ah, 180A	0 092 \$37 381	0 986 A02 781	
奔奔	奔奔 1.0 i CV6	07.07-09.09	12V, 36Ah, 310A 12V, 36Ah, 180A	0 092 S37 381	U 300 AU2 781	
>F>F	373T 1.010VU	01.01 00.00	12V, 36Ah, 310A	0 002 001 001	0 986 A02 781	
			12V, 45Ah, 325A		0 986 A02 788	
		11.09→	12V, 45Ah, 350A	0 092 S37 384		
		11.11→	12V, 45Ah, 325A		0 986 A02 786	
	本本 1 2:0//0	05 00 04 10	12V, 48Ah, 450A	0.000.007.004	0 092 S47 184	
	奔奔 1.3 i CV6	05.06-04.10	12V, 36Ah, 180A 12V, 36Ah, 310A	0 092 \$37 381	0 986 A02 781	
			12V, 35Ah, 315A		0 986 A02 788	
		09.09-06.11	12V, 45Ah, 325A		0 986 A02 786	
杰勋	杰勋 2.0 i	11.06-06.09	12V, 45Ah, 325A		0 986 A02 786	
欧力威	欧力威 1.2 i	09.12→	12V, 45Ah, 325A		0 986 A02 786	
Rh \₩	∇b ₩ 4 Ω :	00.11	12V, 48Ah, 450A		0 092 S47 184	
欧诺	欧诺 1.3 i	08.11→	12V, 60Ah, 580A		0 092 S47 193 0 986 A02 827	
	欧诺 1.5 i	06.12→	12V, 60Ah, 580A		0 092 S47 193	
	77.774 = 10 1				0 986 A02 827	
金牛星	金牛星 1.2 i	05.12→	12V, 45Ah, 325A		0 986 A02 786	
	A # E 4 0 :	10.10	12V, 48Ah, 450A	0.000.007.004	0 092 S47 184	
星光	金牛星 1.3 i 星光 0.8 i	10.10→ 03.05-05.12	12V, 45Ah, 350A 12V, 45Ah, 350A	0 092 S37 384 0 092 S37 384		
至几	星光 0.81 星光 0.9i	03.03-03.12	12V, 45Ah, 325A	0 092 331 364	0 986 A02 786	
	22,00.01	02.00	12V, 48Ah, 450A		0 092 S47 184	
	星光 1.0 i		12V, 45Ah, 350A	0 092 S37 424		
		06.04-03.11	12V, 45Ah, 350A	0 092 S37 384		
			12V, 45Ah, 325A 12V, 48Ah, 450A		0 986 A02 786	
	星光 1.3 i		12V, 48Ah, 450A 12V, 45Ah, 325A		0 092 S47 184 0 986 A02 786	
	至/01.01	02.09-03.12		0 092 S37 384	3 300 A02 100	
星韵	星韵 1.0 i	01.03-06.04			0 986 A02 786	
To J. Man	IM NE	06.05-07.06	12V, 45Ah, 325A		0 986 A02 786	
悦翔	悦翔 1.3 i V3	01.12→	12V, 60Ah, 580A		0 092 \$47 193	
	悦翔 1.5 i	08.08-01.13	12V, 55Ah, 500A		0 986 A02 827 0 092 S37 393	
	DC#11.31	$08.08 \rightarrow 01.13$	12V, 55AH, 500A 12V, 60Ah, 580A		0 092 S47 193	
		30.00			0 986 A02 827	
		06.09-05.11	12V, 60Ah, 580A		0 986 A02 617	
		11.11-07.14	12V, 60Ah, 580A		0 092 S47 193	
	<u>悦翔 1.5 i V5</u>	02.12	101/ 6045 5004		0 986 A02 827	
	Dτ.#1 1.31V5	02.12→	12V, 60Ah, 580A		0 092 S47 193 0 986 A02 827	
彩虹	彩虹 1.0 i	06.04-07.08	12V, 36Ah, 180A	0 092 S37 381	0 300 MUZ 021	
	.,,		12V, 36Ah, 310A		0 986 A02 781	
		12.05-12.07	12V, 45Ah, 325A		0 986 A02 786	
	11/4T + 0 :	05.06-03.09	12V, 45Ah, 350A	0 092 S37 384	0.002.125	
海	彩虹 1.3 i 海	06.05-03.09	12V, 45Ah, 325A		0 986 A02 786	
逸动 XT	逸动 XT 1.6 i	01.13→	12V, 55Ah, 610A 12V, 63Ah, 610A		0 986 A02 826 0 092 S47 192	
			IZY, OOMII, OTOM		3 002 041 102	








长安▶

凯迪拉克 • 长安






























		面	参数	S3 动能	S4 动力神	S5 银侠
A3 掀背车	A3 1.6 i 掀背车	06.10→	12V, 60Ah, 580A		0 092 \$47 193	
A5	A5 1.3 i	03.08-05.11	12V, 45Ah, 325A		0 986 A02 827 0 986 A02 787	
AJ	A3 1.31	03.00 03.11	12V, 45Ah, 350A	0 092 S37 383	0 300 A02 101	
			12V, 58Ah, 510A			0 092 S57 024
						0 986 A02 233
	A5 1.6 i	01.05-10.09	12V, 45Ah, 325A		0 986 A02 787	
			12V, 45Ah, 350A	0 092 S37 383		0.000.057.004
			12V, 58Ah, 510A			0 092 S57 024 0 986 A02 233
		01.05-07.12	12V, 60Ah, 580A		0 092 S47 193	0 900 AU2 233
		01.00 07.112	121,007111,00071		0 986 A02 827	
	A5 2.0 i	01.05-01.11	12V, 60Ah, 580A		0 986 A02 827	
E3	E3 1.5 i	09.12→	12V, 60Ah, 580A		0 092 S47 193	
FF [404FL 0]	FF 1 F:	00.10	101/ 0045 5004		0 986 A02 827	
E5 [A21FL-C]	E5 1.5 i	06.10→	12V, 60Ah, 580A		0 092 S47 193 0 986 A02 827	
QQ3	QQ3 0.8 i	12.03-04.14	12V, 45Ah, 325A		0 986 A02 787	
440	4400.01	12.00 04.14	12V, 45Ah, 350A	0 092 S37 383	0 000 702 101	
			12V, 48Ah, 450A		0 092 S47 183	
			12V, 58Ah, 510A			0 092 S57 024
						0 986 A02 233
	00040	08.10→	12V, 45Ah, 325A		0 986 A02 785	
	QQ3 1.0 i	12.08-03.14	12V, 60Ah, 580A		0 092 \$47 193	
		06.10→	12V, 45Ah, 325A		0 986 A02 827 0 986 A02 785	
		00.10	12V, 48Ah, 450A		0 092 S47 185	
	QQ3 1.1 i	09.03-11.07	12V, 45Ah, 325A		0 986 A02 787	
			12V, 45Ah, 350A	0 092 S37 383		
			12V, 58Ah, 510A			0 092 S57 024
						0 986 A02 233
		12.05-01.13	12V, 45Ah, 325A	0 092 S37 384	0 986 A02 788	
			12V, 45Ah, 350A 12V, 58Ah, 510A	0 092 537 384		0 092 S57 002
QQ5	QQ5 1.0 i	02.12→	12V, 45Ah, 325A		0 986 A02 785	0 032 337 002
			12V, 48Ah, 450A		0 092 S47 185	
QQ6	QQ6 1.3 i	06.07-09.12	12V, 45Ah, 325A		0 986 A02 787	
			12V, 45Ah, 350A	0 092 S37 383		
			12V, 58Ah, 510A			0 092 S57 024
风云 2	风云 2 1.5 i	04.09→	12V, 60Ah, 580A		0 986 A02 617	0 986 A02 233
MAZ	MA 21.51	$06.09 \rightarrow$	12V, 60Ah, 580A		0 092 S47 193	
		00.00	121, 00/11, 000/1		0 986 A02 827	
风云 [A11]	风云 1.6 i	01.02-07.08	12V, 60Ah, 580A		0 986 A02 617	
		03.03-07.08	12V, 60Ah, 580A		0 092 S47 193	
	+++ ====		1011 0011 5001		0 986 A02 827	
东方之子 [B11]	东方之子2.0i	$06.03-08.09$ $06.03 \rightarrow$	12V, 60Ah, 580A		0 986 A02 617	
	东方之子 2.4 i		12V, 60Ah, 580A 12V, 60Ah, 580A		0 986 A02 827 0 986 A02 617	
东方之子 [B14]	东方之子 1.9 D	01.02-04.14	12V, 60Ah, 580A		0 986 A02 617	
东方之子 [B16]	东方之子1.8 i	07.06-05.14	12V, 60Ah, 580A		0 092 S47 193	
					0 986 A02 827	
艾瑞泽 7	艾瑞泽 7 1.6 i	12.12→	12V, 60Ah, 580A		0 986 A02 617	
瑞虎	瑞虎 1.6	08.10→	12V, 70Ah, 500A		0 986 A02 796	
	瑞虎 3 1.6 i 瑞虎 5 2.0 i	04.09-05.13 06.13→	12V, 70Ah, 500A 12V, 70Ah, 570A		0 986 A02 796 0 092 S37 399	
瑞虎 [T11]	瑞虎 1.6 i	10.05-12.13	12V, 70AH, 570A 12V, 60Ah, 580A		0 092 547 193	
[]	-10%0 T.O.I	10.00 12.10	, John, Jooh		0 986 A02 827	
	瑞虎 1.8 i	08.06-11.12	12V, 60Ah, 290A		0 092 S47 103	
			12V, 60Ah, 450A	0 092 S37 433		
			12V, 60Ah, 475A		0 986 A02 793	
			12V, 60Ah, 520A		0 986 A02 607	
	瑞虎 2.0 i	07.04-06.09	12V, 60Ah, 550A 12V, 60Ah, 580A		0 092 S47 189 0 092 S47 193	
	州のル ひ と.U I	07.04-00.09	12 V, OUAII, DOUA		0 986 A02 827	
		04.07→	12V, 60Ah, 290A		0 092 S47 103	
			12V, 60Ah, 475A		0 986 A02 793	
			12V, 60Ah, 520A		0 986 A02 607	
	世春~4:	10.00.10.00	12V, 60Ah, 550A		0 092 \$47 189	
	瑞虎 2.4 i 4x4	12.03-10.08	12V, 60Ah, 580A		0 986 A02 827	
				\	\	\
				•		d b
					Man o Bosch	BOSCH
				37	(→ BOSCH	(BOSCH

奇瑞▶

长丰 • 昌河 • 奇瑞




















12V, 88Ah, 600A

0 986 A02 823


















		面	参数	S3 动能	S4 动力神	S5 银侠
300C [LE]	300C 5.7	10.04-08.10	12V, 80Ah, 640A	0 092 S37 401		0.000 100 011
			12V, 80Ah, 720A 12V, 88Ah, 600A		0 986 A02 823	0 986 A02 341
大捷龙	大捷龙 3.3 i	07.07-05.10	12V, 55Ah, 450A		0 986 A02 818	
雪铁龙						
C2 [A6]	C2 1.4 i	07.06-10.13	12V, 60Ah, 580A		0 092 S47 193	
	C2 1.6 i	07.06-10.13	12V, 60Ah, 580A		0 986 A02 827 0 092 S47 193	
C4L	041.1.6:	00.10	107 6045 5004		0 986 A02 827	
C4L	C4L 1.6 i C4L 1.6 T	08.12→ 08.12→	12V, 60Ah, 580A 12V, 60Ah, 580A		0 986 A02 827 0 092 S47 193	
					0 986 A02 827	
	C4L 1.8 i	12.12→	12V, 60Ah, 580A		0 092 S47 193 0 986 A02 827	
C5 [X4]	C5 2.0 i 16V	03.01-09.04	12V, 70Ah, 570A	0 092 S37 399	0 900 AUZ 621	
C5 [X7]	C5 2.0 i	11.09→	12V, 72Ah, 700A		0 986 A02 822	
	C5 2.3 i	11.09→	12V, 60Ah, 580A		0 986 A02 617	
世嘉	C5 3.0 i 世嘉 1.6 i	11.09→ 10.12→	12V, 60Ah, 580A 12V, 60Ah, 580A		0 986 A02 827 0 986 A02 617	
<u>⊏ ⊅⊓</u>	世嘉 1.6 i 16V	04.09→	12V, 60Ah, 580A		0 986 A02 617	
		12.12→	12V, 60Ah, 580A		0 986 A02 827	
	世嘉 2.0 i	04.09→	12V, 60Ah, 580A		0 092 S47 193	
世嘉掀背车	世嘉 1.6 i 掀背车 16V	06.08→	12V, 60Ah, 580A		0 986 A02 827 0 986 A02 617	
产频派日十	世嘉 2.0 i 掀背车 10V	06.08→	12V, 60Ah, 580A		0 986 A02 827	
毕加索	毕加索 1.6 i	06.02-02.07	12V, 60Ah, 580A		0 986 A02 617	
	毕加索 2.0 i	12.03-10.09	12V, 60Ah, 580A		0 092 S47 193	
					0 986 A02 617 0 986 A02 827	
凯旋	凯旋 2.0 i	10.04-03.08	12V, 70Ah, 570A	0 092 S37 399	0 300 A02 021	
			12V, 60Ah, 580A		0 986 A02 827	
₩ =4	□ □△ 4 4:	01.06-04.12			0 092 S47 193	
爱丽舍	爱丽舍 1.4 i 爱丽舍 1.6 i	08.06-07.08	12V, 60Ah, 580A 12V, 60Ah, 580A		0 986 A02 617 0 092 S47 193	
	交加員 1.01	01.01 10.00	124, 00/11, 000/1		0 986 A02 827	
		05.09-06.11	12V, 60Ah, 580A		0 986 A02 617	
		05.13→	12V, 60Ah, 580A		0 092 S47 193	
	爱丽舍 1.6 i 16V	01.01→	12V, 60Ah, 580A		0 986 A02 827 0 986 A02 617	
富康	富康 1.4 i	01.01-10.08			0 986 A02 617	
		01.01-04.09	12V, 60Ah, 580A		0 092 S47 193	
	富康 1.6 i	10.02-12.08	12V, 60Ah, 580A		0 986 A02 827 0 092 S47 193	
	田/永 1.01	10.02-12.00	12V, 00AH, 300A		0 986 A02 827	
		12.03-06.08	12V, 62Ah, 480A			0 986 A02 331
	富康 1.6 i 8V	06.03-06.09	12V, 60Ah, 580A		0 092 S47 193	
					0 986 A02 617 0 986 A02 827	
赛纳	赛纳 2.0 i	01.02-06.03	12V, 60Ah, 580A		0 986 A02 617	
大迪						
±0 + → ±	### A A :	00.04.00.00	101/ 0041 0001		0.000 400 040	
都市威菱 都市骏马	都市威菱 2.2 i 都市骏马 2.2 i	06.04-03.08 01.03-11.09	12V, 80Ah, 680A 12V, 60Ah, 400A		0 986 A02 612 0 986 A02 789	
用户门 极一	即中级一2.21	01.05-11.05	12V, 60Ah, 450A		0 092 S47 101	
			12V, 60Ah, 520A	0 092 S37 380		
	都市骏马 2.8 D	08.03-10.08	12V, 80Ah, 680A		0 986 A02 612	
大宇						
马蒂兹 [M100]	马蒂兹 0.8 i	04.98-01.05	12V, 38Ah, 340A		0 092 \$47 021	
大发						
	4+10/		1011 0 2 11 2 2 2 2			
特锐	特锐 1.3 i	05.00-12.05	12V, 36Ah, 280A	0 092 S37 382	0.086.402.702	
			12V, 36Ah, 310A 12V, 40Ah, 340A		0 986 A02 782 0 092 S47 180	
森雅	森雅 1.3 i	12.02-07.14	12V, 36Ah, 280A	0 092 S37 382		
		01.05-06.08	12V, 45Ah, 225A		0 092 S37 385	
				\	+	+
					The second	BOSCH

大发 • 东风 • 帝豪 • 英伦 • 理念 ▶

雪佛兰 ・ 克莱斯勒 ・ 雪铁龙 ・ 大迪 ・ 大宇 ・ 大发 ・ 东风 ・ 帝豪 ・ 英伦 ・ 理念



















	_			90 BE	93 73 IT	IK IX
大发(接上页)						
森雅	森雅 1.3 i	01.05-06.08	12V, 45Ah, 325A		0 986 A02 786	
			12V, 45Ah, 350A	0 092 S37 386		
	本 114 4 5 :	44.00	12V, 58Ah, 510A	0.000.007.000		0 092 S57 024
本114.000	森雅 1.5 i	11.06→	12V, 36Ah, 280A	0 092 S37 382	0.000.007.000	
森雅 S80	森雅 S80 1.5 i	08.10→	12V, 45Ah, 350A		0 092 S37 383	
东风						
73 17 14						
H30 Cross	H30 Cross 1.6 i	10.10→	12V, 55Ah, 450A		0 092 S37 392	
S30	S30 1.6 i	12.08→	12V, 60Ah, 580A		0 092 S47 193	
			,,		0 986 A02 827	
小王子	小王子 1.0 i	06.03-06.08	12V, 100Ah, 512A	0 986 A02 732		
			12V, 100Ah, 680A		0 986 A02 805	
			12V, 100Ah, 700A	0 092 S37 407		
小康	小康 0.8 i	08.07-06.08	12V, 100Ah, 512A	0 986 A02 732		
			12V, 100Ah, 680A		0 986 A02 805	
			12V, 100Ah, 700A	0 092 S37 407		
	小康 0.9 i	08.07-08.14	12V, 100Ah, 512A	0 986 A02 732		
			12V, 100Ah, 680A		0 986 A02 805	
			12V, 100Ah, 700A	0 092 S37 407		
	小康 1.0 i	01.06→	12V, 100Ah, 512A	0 986 A02 732		
			12V, 100Ah, 680A		0 986 A02 805	
		11.00.11.11	12V, 100Ah, 700A	0 092 S37 407		
		11.06-11.11	12V, 45Ah, 325A		0 986 A02 788	
		06.08→	12V, 48Ah, 450A		0 092 S47 182	
		06.08→	12V, 45Ah, 325A		0 986 A02 786	
		10.10→	12V, 48Ah, 450A	0.002.527.424	0 092 S47 184	
	小康 1.1 i	01.03→	12V, 45Ah, 350A 12V, 100Ah, 512A	0 092 S37 424 0 986 A02 732		
	小泉 1.11	01.03	12V, 100Ah, 680A	U 900 AUZ 732	0 986 A02 805	
			12V, 100Ah, 700A	0 092 S37 407	0 900 AU2 003	
		10.05-06.10	12V, 45Ah, 325A	0 032 331 401	0 986 A02 786	
		10.05-00.10	12V, 48Ah, 450A		0 092 S47 184	
	小康 1.2 i	10.10→	12V, 45Ah, 325A		0 986 A02 786	
	J 14 1.21	10.10	12V, 48Ah, 450A		0 092 S47 184	
	小康 1.3 i	12.04→	12V, 100Ah, 512A	0 986 A02 732	0 0 0 0 0 0 1 1 0 1	
	3 /4 1.0	12.0	12V, 100Ah, 680A		0 986 A02 805	
			12V, 100Ah, 700A	0 092 S37 407		
		06.08→	12V, 45Ah, 325A		0 986 A02 786	
			12V, 48Ah, 450A		0 092 S47 184	
	小康 1.4 i	10.10→	12V, 45Ah, 325A		0 986 A02 786	
			12V, 48Ah, 450A		0 092 S47 184	
	小康 2.0 i	09.03-06.11	12V, 70Ah, 640A	0 986 A02 332		
小霸王	小霸王 2.2 D	04.02-11.09	12V, 70Ah, 640A	0 986 A02 332		
		03.08→	12V, 135Ah, 790A		0 092 S37 425	
		06.08→	12V, 70Ah, 570A		0 092 S37 399	
	小霸王 2.4 D	09.06-05.08	12V, 70Ah, 640A	0 986 A02 332		
	小霸王 2.5 D	03.01-10.07	12V, 150Ah, 754A	0 986 A02 735		
	小霸王 3.2 D	07.04.07.00	12V, 150Ah, 800A	0 092 S37 413	0.000.400.000	
			12V, 60Ah, 490A	0.000 400 000	0 986 A02 603	
	小霸王 3.3 D	03.01-07.11 03.02-03.06	12V, 70Ah, 640A 12V, 150Ah, 754A	0 986 A02 332 0 986 A02 735		
		03.02-03.06	12V, 150Ah, 754A 12V, 150Ah, 800A	0 092 S37 413		
	小霸王 3.7 D	09.01-04.11	12V, 60Ah, 490A	0 052 551 415	0 986 A02 603	
	小霸王 3.7 D	03.08→	12V, 60Ah, 490A		0 986 A02 603	
风光	风光 1.5 i	01.13→	12V, 45Ah, 350A		0 092 S37 384	
风行景逸	风行景逸 1.5 i	06.08→	12V, 68Ah, 650A		0 986 A02 611	
	风行景逸 1.6 i	11.07→	12V, 45Ah, 350A		0 092 S37 384	
	风行景逸 1.8 i	01.07-05.11	12V, 65Ah, 370A		0 092 S47 105	
			12V, 65Ah, 580A		0 986 A02 609	
			12V, 70Ah, 500A		0 986 A02 796	
		03.11→	12V, 100Ah, 512A	0 986 A02 732		
			12V, 100Ah, 680A		0 986 A02 805	
			12V, 100Ah, 700A	0 092 S37 407		
风神	风神 1.6 i A60	07.12→	12V, 45Ah, 350A		0 092 S37 384	
	风神 1.6 i H30	12.09-08.14	12V, 60Ah, 580A		0 986 A02 617	
东风	东风 0.9 i	09.07-11.08	12V, 70Ah, 640A	0 986 A02 332		
	东风 1.0 i	07.07→	12V, 45Ah, 350A	0 092 S37 384		
		11.07→	12V, 70Ah, 640A	0 986 A02 332		
	东风 1.1 i	05.02-06.11	12V, 70Ah, 640A	0 986 A02 332		
		04.09→	12V, 45Ah, 350A	0 092 S37 384		
	+	12.10→	12V, 45Ah, 350A	0.000	0 092 S37 384	
	东风 2.0 D	11.06-07.11	12V, 70Ah, 640A	0 986 A02 332		
	东风 2.2 D	04.01-07.11	12V, 70Ah, 640A	0 986 A02 332		
	东风 2.2 i	06.09→	12V, 70Ah, 640A	0 986 A02 332		
	东风 2.4 D	11.06-07.11	12V, 70Ah, 640A	0 986 A02 332		
	东风 2.5 D 东风 2.7 D	01.06→	12V, 70Ah, 640A	0 986 A02 332		
	东风 2.7 D 东风 2.8 D	01.06→ 07.02-04.07	12V, 70Ah, 640A 12V, 70Ah, 640A	0 986 A02 332		
	东风 2.8 D 东风 3.2 D	07.02-04.07	12V, 70An, 640A 12V, 70Ah, 640A	0 986 A02 332 0 986 A02 332		
	东风 3.2 D 东风 3.3 D	10.01→	12V, 70An, 640A 12V, 70Ah, 640A	0 986 A02 332 0 986 A02 332		
	东风 3.7 D	01.01-07.11	12V, 70Ah, 640A	0 986 A02 332		
	东风 3.7 D 东风 3.9 D	03.03→	12V, 70Ah, 640A	0 986 A02 332		
	77 / O.U D	00.00 /	121, 10AII, 040A	0 300 A02 332		
















雪佛兰 ・ 克莱斯勒 ・ 雪铁龙 ・ 大迪 ・ 大宇 ・ 大发 ・ 东风 ・ 帝豪 ・ 英伦 ・ 理念





















参数

S3 动能

S4 动力神

S5 银侠

天津一汽						
天津一汽	天津一汽1.0	06.08→ 01.07-04.08	12V, 45Ah, 350A	0 092 \$37 383		
太湖	太湖 2.7 D	01.07-04.08	12V, 100Ah, 512A 12V, 100Ah, 680A	0 986 A02 732	0 986 A02 805	
			12V, 100Ah, 700A	0 092 S37 407	0 000 A02 000	
	太湖 2.8 D	06.09→	12V, 100Ah, 512A	0 986 A02 732		
			12V, 100Ah, 680A	0.000.007.407	0 986 A02 805	
	太湖 3.0 D	10.05-05.08	12V, 100Ah, 700A 12V, 100Ah, 512A	0 092 S37 407 0 986 A02 732		
)(()()() () ()	10.00 00.00	12V, 100Ah, 680A	0 300 A02 102	0 986 A02 805	
			12V, 100Ah, 700A	0 092 S37 407		
	太湖 3.2 D	10.05-05.08	12V, 100Ah, 512A	0 986 A02 732	0.000 400 005	
			12V, 100Ah, 680A 12V, 100Ah, 700A	0 092 S37 407	0 986 A02 805	
	太湖 3.4 D	05.05→	12V, 70Ah, 640A	0 986 A02 332		
	太湖 3.7 D	05.05-06.08	12V, 70Ah, 640A	0 986 A02 332		
	太湖 3.9 D	05.07-05.08	12V, 100Ah, 512A	0 986 A02 732		
			12V, 100Ah, 680A 12V, 100Ah, 700A	0 092 S37 407	0 986 A02 805	
华西	华西 3.9 T	08.03-03.08	12V, 70Ah, 640A	0 986 A02 332		
自由风	自由风 1.9 D	01.09-06.13	12V, 100Ah, 512A	0 986 A02 732		
			12V, 100Ah, 680A		0 986 A02 805	
	自由风 2.0 i	10.04→	12V, 100Ah, 700A 12V, 70Ah, 640A	0 092 S37 407 0 986 A02 332		
	自由从 2.01	01.07-06.13	12V, 70AH, 040A 12V, 100Ah, 512A	0 986 A02 732		
		01.07 00.10	12V, 100Ah, 680A	00007102	0 986 A02 805	
			12V, 100Ah, 700A	0 092 S37 407		
	自由风 2.2 i	08.03-06.08	12V, 100Ah, 512A	0 986 A02 732	0.000 100 005	
			12V, 100Ah, 680A 12V, 100Ah, 700A	0 092 S37 407	0 986 A02 805	
	自由风 2.4 i	12.04-11.10	12V, 70Ah, 640A	0 986 A02 332		
佳宝	佳宝 0.9 i	01.98-07.08	12V, 45Ah, 400A		0 986 A02 600	
	佳宝 1.0 i	01.99→	12V, 45Ah, 325A		0 986 A02 786	
			12V, 45Ah, 350A	0 092 S37 386	0.000 047 404	
			12V, 48Ah, 450A 12V, 58Ah, 510A		0 092 S47 184	0 092 S57 024
		01.00→	12V, 45Ah, 325A		0 986 A02 787	0 002 007 027
			12V, 48Ah, 450A		0 092 S47 183	
	/+ 中 4 4 :	08.03→	12V, 45Ah, 400A		0 986 A02 600	
	佳宝 1.1 i	01.03-04.13	12V, 45Ah, 325A 12V, 45Ah, 350A	0 092 S37 386	0 986 A02 786	
			12V, 48Ah, 450A	0 032 331 300	0 092 S47 184	
			12V, 58Ah, 510A			0 092 S57 024
	74.5	05.03→	12V, 45Ah, 400A		0 986 A02 600	
	佳宝 1.3 i	08.06-11.08 08.09-04.14	12V, 45Ah, 400A 12V, 45Ah, 400A		0 986 A02 600 0 986 A02 600	
		10.12→	12V, 70Ah, 640A	0 986 A02 332	0 300 A02 000	
幸福使者	幸福使者 1.0 i	01.97-05.08	12V, 45Ah, 350A	0 092 S37 383		
	+ = + +		12V, 55Ah, 500A	0 092 S37 393		
	幸福使者 1.1 i	09.03-11.17	12V, 45Ah, 350A 12V, 55Ah, 500A	0 092 S37 383 0 092 S37 393		
威乐	威乐 1.3 i	01.04-03.06	12V, 45Ah, 325A	0 0 3 2 3 3 1 3 3 3	0 986 A02 786	
			12V, 45Ah, 350A	0 092 S37 386		
	-		12V, 58Ah, 510A			0 092 S57 024
	威乐 1.5 i	01.04-04.09	12V, 45Ah, 325A 12V, 45Ah, 325A		0 986 A02 788 0 986 A02 786	
		12.05-10.11	12V, 45Ah, 350A	0 092 S37 386	0 300 A02 700	
			12V, 58Ah, 510A			0 092 S57 024
	威乐 1.6 i	03.05-09.06	12V, 45Ah, 325A		0 986 A02 786	
			12V, 45Ah, 350A 12V, 58Ah, 510A	0 092 S37 386		0 092 S57 024
威志		07.03-08.07	12V, 45Ah, 400A		0 986 A02 601	0 092 557 024
,,,,,,,	威志 1.3 i	07.03-02.10	12V, 45Ah, 400A		0 986 A02 601	
	威志 1.5 i	07.06-10.11	12V, 45Ah, 325A		0 986 A02 788	
	威志 1.5 i V5	09.08-06.10	12V, 45Ah, 400A		0 986 A02 601	
威志 [V2]		08.11→ 04.09-08.13	12V, 45Ah, 325A 12V, 45Ah, 350A		0 986 A02 788 0 092 S37 384	
	277-W1 TE 2101	11.11-11.12	12V, 45Ah, 325A		0 986 A02 788	
柯斯达	柯斯达 2.7		12V, 70Ah, 600A		0 986 A02 797	
解放	解放 2.1 D 解放 2.2 D	12.03-04.11 04.01-07.11	12V, 70Ah, 640A 12V, 70Ah, 640A	0 986 A02 332		
	解放 2.2 D 解放 2.3 D	12.02-07.11	12V, 70Ah, 640A	0 986 A02 332 0 986 A02 332		
	解放 2.5 D	10.03-07.09	12V, 70Ah, 640A	0 986 A02 332		
	解放 2.7 D	08.03-06.09	12V, 70Ah, 640A	0 986 A02 332		
	解放 3.0 D	12.03-11.08	12V, 70Ah, 640A	0 986 A02 332		
	解放 3.2 D 解放 3.4 D	11.01→ 12.03-07.08	12V, 70Ah, 640A 12V, 70Ah, 640A	0 986 A02 332 0 986 A02 332		
	解放 3.8 D	05.03-05.08	12V, 70Ah, 640A	0 986 A02 332		
	解放 3.9 D	09.03-07.08	12V, 70Ah, 640A	0 986 A02 332		
	解放 4.8 D	03.04-04.05	12V, 70Ah, 640A	0 986 A02 332		
	解放 5.2 D 解放 5.7	11.03-11.05 01.03-01.06	12V, 70Ah, 640A 12V, 70Ah, 640A	0 986 A02 332 0 986 A02 332		
	解放 6.6 D	03.06→	12V, 70Ah, 640A	0 986 A02 332		
			,			


















		面	参数	S3 动能	S4 动力神	S5 银侠
解放 LT	解放 LT 3.9 D	04.07→	12V, 165Ah, 600A	0 092 \$37 414		
		06.08→	12V, 180Ah, 630A	0 092 S37 415		
一汽解放						
各宝	路宝 1.3 i	04.03-05.05	12V, 55Ah, 500A	0 092 S37 393		
法拉利						
	450 11 11	00.40	101/ 7441 0004			0.000.400.00
58 [F 142]	458 Italia 458 Spider	03.10→ 09.11→	12V, 74Ah, 680A 12V, 74Ah, 680A			0 986 A02 334 0 986 A02 334
430	F 430 Scuderia	10.07-12.09	12V, 74Ah, 680A			0 986 A02 334
菲亚特						
西耶那 [172]	西耶那 1.2 MPI 8V	01.02-02.07			0 986 A02 617	
	西耶那 1.2 MPI 16V 西耶那 1.5 MPI	01.03→ 12.03-04.08	12V, 60Ah, 580A 12V, 60Ah, 580A		0 986 A02 617 0 986 A02 617	
周末风	周末风 1.2 MPI 16V	07.03-03.04	12V, 60Ah, 580A		0 986 A02 617	
成力奥 [178]	周末风 1.5 MPI 派力奥 1.2 MPI 8V	07.03-11.06 01.02-02.07	12V, 60Ah, 580A 12V, 60Ah, 580A		0 986 A02 617 0 986 A02 617	
\\\> [110]	<u>派力奥 1.2 MPI 6V</u> 派力奥 1.2 MPI 16V	08.03-04.08	12V, 60Ah, 580A		0 986 A02 617	
	派力奥 1.5 MPI	01.02-11.06	12V, 60Ah, 580A		0 986 A02 617	
成朗 [172] 5年 [245]	派朗 1.7 MPI	05.06-04.08	12V, 55Ah, 500A	0 092 S37 393		0.000.400.00
έ跃 [345] έ翔	菲跃 3.6 4x4 菲翔 1.4	08.11→ 06.12→	12V, 74Ah, 680A 12V, 60Ah, 580A		0 092 S47 193	0 986 A02 334
-711	9F711 1.4	00.12	12 V, OOAH, 300A		0 986 A02 827	
福迪						
	探险者 2.8 DⅡ	12.08-01.12	12V, 60Ah, 400A		0 986 A02 790	
			12V, 60Ah, 450A	0 092 S37 431		
			12V, 60Ah, 520A 12V, 60Ah, 530A	0 092 S37 406	0 092 S47 187	
畐迪	福迪 2.2 i	08.02-04.05		0 092 S37 390	0 092 547 167	
福特						
-MAX '06	S-MAX 2.3 i	02.07-05.14	12V, 66Ah, 550A		0 986 A02 819	
È顺	全顺 2.3 i	12.07→	12V, 70Ah, 640A	0 986 A02 332		
	全顺 2.4 D	02.07→	12V, 75Ah, 700A 12V, 70Ah, 640A	0 986 A02 332	0 092 S47 191	
	至,例 2.4 0	02.07	12V, 75Ah, 700A	0 300 A02 332	0 092 S47 191	
	全顺 2.4 i	12.05→	12V, 70Ah, 640A	0 986 A02 332		
	全顺 2.8 D	02.01.07.00	12V, 75Ah, 700A		0 092 S47 191 0 986 A02 732	
	主順 2.8 U	03.01-07.09	12V, 100Ah, 512A 12V, 100Ah, 680A		0 986 A02 732 0 986 A02 805	
			12V, 100Ah, 700A	0 092 S37 407	0 000 7102 000	
		03.01→	12V, 75Ah, 700A		0 092 S47 191	
· · · · · · · · · · · · · · · · · · ·	福克斯 1.6 i	05.01→ 12.11→	12V, 70Ah, 640A 12V, 66Ah, 550A	0 986 A02 332	0 986 A02 819	
电 无别	福克斯 1.8 i	08.05→	12V, 45Ah, 225A	0 092 S37 385	0 500 AU2 015	
			12V, 55Ah, 450A	0 092 S37 392		
			12V, 58Ah, 510A		0.000.100.010	0 092 S57 024
			12V, 66Ah, 550A 12V, 70Ah, 640A		0 986 A02 819	0 986 A02 332
	福克斯 2.0 i	08.05→	12V, 45Ah, 225A	0 092 S37 385		0 300 A02 332
			12V, 58Ah, 510A			0 092 S57 024
			12V, 66Ah, 550A	0.000.007.400	0 986 A02 819	
			12V, 72Ah, 580A 12V, 72Ah, 700A	0 092 S37 400	0 986 A02 822	
長迪欧	蒙迪欧 1.5 i	04.13→	12V, 66Ah, 550A		0 986 A02 819	
	蒙迪欧 2.0 i	03.04-07.08	12V, 65Ah, 490A		0 986 A02 791	
		$03.04 \rightarrow 07.07-04.13$	12V, 66Ah, 550A 12V, 45Ah, 225A	0 092 S37 385	0 986 A02 819	
		01.01-04.13	12V, 58Ah, 510A	0 032 331 303		0 092 S57 024
			12V, 72Ah, 580A	0 092 S37 400		
	营油屋 2.2 :	07.07	12V, 72Ah, 700A		0 986 A02 822	
	蒙迪欧 2.3 i 蒙迪欧 2.5 i	07.07→ 03.04-01.08	12V, 66Ah, 550A 12V, 45Ah, 225A	0 092 S37 385	0 986 A02 819	
	男へ/世 F/\ ∠.J I	00.04-01.00	12V, 58Ah, 510A	0 032 331 303		0 092 S57 024
			12V, 66Ah, 550A		0 986 A02 819	
			12V, 72Ah, 580A	0 092 S37 400	0.006.400.006	
			12V, 72Ah, 700A		0 986 A02 822	
				•	*	*
				MODELL MODELL	The same of the sa	E CO BOSCH
				BOSCH	⊜ BOSCH	(A) BOSCH
				W BUSCH	No.	00000

福特▶

天津一汽 • 一汽解放 • 法拉利 • 菲亚特 • 福迪 • 福特





























奥铃					动力神	银侠
६ इर	奥铃 2.2 D	04.08→	12V, 60Ah, 475A		0 986 A02 793	
	关节 2.20	04.00	12V, 60Ah, 550A		0 092 S47 189	
		06.08→	12V, 80Ah, 680A		0 986 A02 612	
	奥铃 2.2 i	11.01-10.11	12V, 70Ah, 640A	0 986 A02 332		
	奥铃 2.3 D	03.02-03.09 12.05-06.11	12V, 80Ah, 680A 12V, 70Ah, 640A	0 986 A02 332	0 986 A02 612	
	₹ ₩ 2.5 D	$07.12 \rightarrow$	12V, 70Ah, 600A	0 300 A02 332	0 986 A02 798	
	奥铃 2.5 D	12.05-06.09	12V, 65Ah, 370		0 092 S47 106	
			12V, 70Ah, 500A		0 986 A02 795	
		03.06-06.09 08.06-06.09	12V, 80Ah, 680A 12V, 70Ah, 640A	0 986 A02 332	0 986 A02 612	
	<u>奥铃 2.7 D</u> 奥铃 2.8 D	03.01-11.09	12V, 70AH, 640A	U 900 AUZ 332	0 986 A02 612	
	241, 211 2	03.01-03.11	12V, 68Ah, 650A		0 986 A02 611	
		03.01→	12V, 70Ah, 640A	0 986 A02 332		
	奥铃 3.2 D	09.01→	12V, 70Ah, 640A	0 986 A02 332		
	奥铃 3.3 D	12.02-09.10 05.04-12.08	12V, 70Ah, 640A 12V, 80Ah, 680A	0 986 A02 332	0 986 A02 612	
	奥铃 3.4 D	07.04-05.08	12V, 70Ah, 640A	0 986 A02 332	0 900 A02 012	
	奥铃 3.7 D	12.02-06.09	12V, 70Ah, 640A	0 986 A02 332		
		11.07→	12V, 80Ah, 680A		0 986 A02 612	
	奥铃 3.8 D	09.07-05.08	12V, 70Ah, 640A	0 986 A02 332		
	奥铃 3.9 D	$08.03 \rightarrow 10.05-12.08$	12V, 70Ah, 640A 12V, 45Ah, 400A	0 986 A02 332	0 986 A02 600	
		$10.05^{-12.08}$ $11.07 \rightarrow$	12V, 45AH, 400A 12V, 80Ah, 680A		0 986 A02 612	
	奥铃 4.0 D	04.05-06.08	12V, 68Ah, 650A		0 986 A02 611	
		06.05-05.08	12V, 70Ah, 640A	0 986 A02 332		
	m b	12.08→	12V, 80Ah, 680A		0 986 A02 612	
	奥铃 4.1 D	02.03-06.08 10.05-12.08	12V, 70Ah, 640A	0 986 A02 332	0.006.400.611	
		10.05-12.08	12V, 68Ah, 650A 12V, 80Ah, 680A		0 986 A02 611 0 986 A02 612	
田	福田 1.1 i	03.08→	12V, 70Ah, 640A	0 986 A02 332	0 300 A02 012	
	福田 1.6 D	04.11→	12V, 70Ah, 640A	0 986 A02 332		
	福田 1.8 D	10.06→	12V, 70Ah, 640A	0 986 A02 332		
 表派克	蒙派克 2.0 i	01.07→	12V, 70Ah, 640A	0 986 A02 332		
	蒙派克 2.4 i 蒙派克 2.5 D	12.05→ 03.08→	12V, 70Ah, 640A 12V, 70Ah, 640A	0 986 A02 332 0 986 A02 332		
	蒙派克 2.8 D	02.07→	12V, 70Ah, 640A	0 986 A02 332		
福迪						
深索者	探索者Ⅱ2.2i	09.03-04.08	12V, 60Ah, 400A	0.000.007.400	0 986 A02 790	
			12V, 60Ah, 520A 12V, 60Ah, 530A	0 092 S37 406	0 092 S47 187	
	探索者Ⅱ2.8D	03.04-09.10	12V, 60Ah, 400A		0 986 A02 790	
),,,,, H	0010100120	12V, 60Ah, 450A	0 092 S37 431		
			12V, 60Ah, 520A	0 092 S37 406		
	極事者 2000:	10.04	12V, 60Ah, 530A		0 092 \$47 187	
	探索者 Ⅲ 2.2 i	12.04→	12V, 60Ah, 400A 12V, 60Ah, 450A		0 986 A02 789 0 092 S47 101	
			12V, 60Ah, 520A	0 092 S37 380	0 092 547 101	
	探索者Ⅲ2.8D	12.05-07.08	12V, 60Ah, 400A	0 002 001 000	0 986 A02 790	
	, , , , , , , , , , , , , , , , , , ,		12V, 60Ah, 450A	0 092 S37 431		
			12V, 60Ah, 520A	0 092 S37 406		
			12V, 60Ah, 530A		0 092 S47 187	
吉利						
	010 1 01	05.10	101/ 4511 555		0000000	
X2 X7	GX2 1.3 i GX7 1.8 i	05.10→ 10.11→	12V, 45Ah, 325A 12V, 70Ah, 600A		0 986 A02 785	0 986 A02 797
IA1	GX7 2.0 i	10.11→	12V, 70Ah, 600A			0 986 A02 797
忙利欧	优利欧 1.0 i	11.04-04.08	12V, 45Ah, 325A		0 986 A02 787	2 300 HVZ 131
			12V, 45Ah, 350A	0 092 S37 383		
			12V, 58Ah, 510A			0 092 S57 024
		11.04.00.00	101/ 4545 2504	0.002.527.204		0 986 A02 233
	优利欧 1.3 i	11.04-06.08 08.03-06.07	12V, 45Ah, 350A 12V, 45Ah, 350A	0 092 S37 384 0 092 S37 384		
	优利欧 1.6 i	03.05-09.06	12V, 45Ah, 350A	0 092 537 384		
	20-13M/ T/O I	22.00 30.00	12V, 36Ah, 310A		0 986 A02 781	
			12V, 45Ah, 350A	0 092 S37 384		
È球鹰 GC7	全球鹰 GC7 1.5 i	03.11→	12V, 70Ah, 600A		0 986 A02 797	
自由舰	全球鹰 GC7 1.8 i 自由舰 1.0 i	03.11→ 08.10→	12V, 70Ah, 600A 12V, 55Ah, 450A		0 986 A02 797 0 986 A02 818	
4 141 157	自由舰 1.3 i	11.04→	12V, 60Ah, 400A		0 986 A02 789	
	-1 -120 110 1		12V, 60Ah, 450A		0 092 S47 101	
			12V, 60Ah, 520A	0 092 S37 380		
	444.	44.64.6= : :	12V, 60Ah, 530A		0 092 S47 186	
	自由舰 1.5 i	11.04-07.14	12V, 45Ah, 400A		0 986 A02 600	
				—	+	+

吉利・金龙・吉奥・长城・哈飞▶


















		圍	参数	S3 动能	S4 动力神	S5 银侠
吉利(接上页) 自由舰	自由舰 1.6 i	11.04-12.08	12V, 60Ah, 400A		0 986 A02 789	
			12V, 60Ah, 450A 12V, 60Ah, 520A	0 092 S37 380	0 092 \$47 101	
远景	远景 1.5 i	01.08→	12V, 60Ah, 400A	0 032 331 300	0 986 A02 789	
			12V, 60Ah, 450A 12V, 60Ah, 520A	0 092 S37 380	0 092 S47 101	
			12V, 60Ah, 530A	0 002 001 000	0 092 S47 186	
	远景 1.8 i	12.05→	12V, 60Ah, 400A 12V, 60Ah, 450A		0 986 A02 789 0 092 S47 101	
			12V, 60Ah, 520A	0 092 S37 380		
金刚	金刚 1.5 i	12.05→	12V, 60Ah, 530A 12V, 60Ah, 400A		0 092 S47 186 0 986 A02 789	
	<u></u> [1] 1.01	12.00	12V, 60Ah, 450A		0 092 \$47 101	
			12V, 60Ah, 520A 12V, 60Ah, 530A	0 092 S37 380	0 092 S47 186	
	金刚 1.6 i	12.05-06.09	12V, 60Ah, 400A		0 986 A02 789	
			12V, 60Ah, 450A 12V, 60Ah, 520A	0 092 S37 380	0 092 S47 101	
	金刚 1.8 i	11.06-07.08		0 092 537 360	0 986 A02 789	
			12V, 60Ah, 450A	0.000.007.000	0 092 S47 101	
金鹰	金鹰 1.5 i	11.07→	12V, 60Ah, 520A 12V, 60Ah, 400A	0 092 S37 380	0 986 A02 789	
			12V, 60Ah, 530A		0 092 S47 186	
美人豹	美人豹 1.3 i 美人豹 1.5 i	12.03-03.08	12V, 45Ah, 400A 12V, 45Ah, 400A		0 986 A02 601 0 986 A02 601	
	美人豹 1.8 i	04.06-04.09	12V, 60Ah, 400A		0 986 A02 789	
			12V, 60Ah, 450A 12V, 60Ah, 520A	0 092 S37 380	0 092 S47 101	
美日	美日 1.3 i	08.03-07.08	12V, 60Ah, 400A	0 092 537 360	0 986 A02 789	
			12V, 60Ah, 450A	0.000.007.000	0 092 S47 101	
熊猫	熊猫 1.0 i	06.08→	12V, 60Ah, 520A 12V, 45Ah, 325A	0 092 S37 380	0 986 A02 785	
			12V, 48Ah, 450A		0 092 S47 185	
豪情	熊猫 1.3 i 豪情 1.0 i	06.08→ 02.03-05.09	12V, 45Ah, 225A 12V, 45Ah, 325A	0 092 S37 385	0 986 A02 786	
2011/06	30 H 1.01	02.00 00.00	12V, 48Ah, 450A		0 092 S47 184	
		08.03-12.08	12V, 70Ah, 640A 12V, 60Ah, 400A	0 986 A02 332	0 986 A02 789	
		00.03-12.00	12V, 60Ah, 450A		0 092 S47 101	
			12V, 60Ah, 520A	0 092 S37 380	0.000.047.400	
	豪情 1.3 i	08.03-01.09	12V, 60Ah, 530A 12V, 45Ah, 325A		0 092 S47 186 0 986 A02 787	
			12V, 45Ah, 350A	0 092 S37 383		
			12V, 58Ah, 510A			0 092 S57 024 0 986 A02 233
			12V, 45Ah, 350A	0 092 S37 384		0 000 /102 200
	豪情 1.5 i	01.01-10.08	12V, 45Ah, 400A		0 986 A02 600	
金龙						
金旅	金旅 2.2 i	01.06→	12V, 80Ah, 400A	0 092 S37 391		
吉奥						
伊美	伊美 1.1 i		12V, 45Ah, 350A	0 092 S37 383	0.000.007.004	
星旺	星旺 1.1 i	09.08-01.13	12V, 45Ah, 350A		0 092 S37 384	
长城						
C50	C50 1.5 i	05.11→	12V, 45Ah, 325A		0 986 A02 786	
			12V, 48Ah, 450A		0 092 S47 184	
风骏	风骏 2.0 D 风骏 2.2 i	02.12→ 12.12→	12V, 80Ah, 400A	0.086 403 333	0 092 S37 391	
	风骏 2.21 风骏 2.8 D	06.07-09.09	12V, 70Ah, 640A 12V, 70Ah, 640A	0 986 A02 332 0 986 A02 332		
\d. (2)) th (T 0 0 : 414)	04.13→	12V, 80Ah, 400A		0 092 S37 391	
迪尔	迪尔 2.2 i 4WD	03.02-07.08	12V, 70Ah, 640A 12V, 100Ah, 512A	0 986 A02 332	0 986 A02 732	
			12V, 100Ah, 680A		0 986 A02 805	
	<u>迪尔 2.2 i</u>	09.10→	12V, 100Ah, 700A 12V, 70Ah, 640A	0 092 S37 407 0 986 A02 332		
	CC1021/1022			0 300 A02 332		
	迪尔 2.4 i 迪尔 2.8 D	04.08→ 07.01-12.10	12V, 68Ah, 650A 12V, 68Ah, 650A		0 986 A02 611 0 986 A02 611	
	迪尔 2.8 D CC1021		12V, 80Ah, 680A		0 986 A02 611 0 986 A02 613	
哈弗	哈弗 2.4 i		12V, 70Ah, 600A		0 986 A02 798	
	哈弗 2.5 D 哈弗 · 派 2.8 T	06.08-11.12 02.07-11.08			0 986 A02 607 0 092 S47 103	
			12V, 60Ah, 475A		0 986 A02 793	
			12V, 60Ah, 520A 12V, 60Ah, 290A		0 986 A02 607 0 092 S47 103	
哈弗CUV	哈弗 (リル・) 4:	01 04-02 10			0 002 041 100	
哈弗 CUV	哈弗 CUV 2.4 i	01.04-02.10	12V, 60Ah, 450A	0 092 S37 433		
哈弗 CUV	哈弗 CUV 2.4 i	01.04-02.10	12V, 60Ah, 450A 12V, 60Ah, 475A	0 092 S37 433	0 986 A02 793	
哈弗 CUV	哈弗 CUV 2.4 i	01.04-02.10	12V, 60Ah, 450A	0 092 \$37 433	0 986 A02 793 0 986 A02 607 0 092 S47 189	
	哈弗 CUV 2.8 T	01.04-02.11	12V, 60Ah, 450A 12V, 60Ah, 475A 12V, 60Ah, 520A 12V, 60Ah, 550A 12V, 60Ah, 520A		0 986 A02 607	
哈弗 CUV 哈弗 H2			12V, 60Ah, 450A 12V, 60Ah, 475A 12V, 60Ah, 520A 12V, 60Ah, 550A 12V, 60Ah, 520A 12V, 60Ah, 450A	0 092 S37 433 0 092 S37 432	0 986 A02 607 0 092 S47 189 0 986 A02 607	
	哈弗 CUV 2.8 T	01.04-02.11	12V, 60Ah, 450A 12V, 60Ah, 475A 12V, 60Ah, 520A 12V, 60Ah, 550A 12V, 60Ah, 520A 12V, 60Ah, 450A 12V, 60Ah, 520A		0 986 A02 607 0 092 S47 189	
















		Ta Car	参数	S3 动能	S4 动力神	S5 银侠
計弗 H5	哈弗 H5 2.0 4x2	05.12→	12V, 70Ah, 600A		0 986 A02 798	
	哈弗 H5 2.0 D	06.10→	12V, 60Ah, 475A		0 986 A02 793	
	哈弗 H5 2.0 i	05.09→	12V, 60Ah, 550A 12V, 60Ah, 475A		0 092 S47 189 0 986 A02 793	
	响 师 □3 2.0 I	05.09→	12V, 60Ah, 550A		0 092 S47 189	
弗 H6	哈弗 H6 1.5 T	12.11→	12V, 60Ah, 400A		0 986 A02 789	
7F 110	*D 77 110 1.3 1	12.11	12V, 60Ah, 530A		0 092 S47 186	
	哈弗 H6 2.0 i	12.10→	12V, 60Ah, 475A		0 986 A02 794	
	*g 57 110 2.0 1	12.10	12V, 60Ah, 550A		0 092 S47 188	
	哈弗 H6 2.0 T	01.11→	12V, 60Ah, 475A		0 986 A02 793	
	*G 59 110 2.0 1	01.11	12V, 60Ah, 550A		0 092 S47 189	
	哈弗 H6 2.4 i	08.11→	12V, 70Ah, 600A		0 986 A02 798	
弗 M2	ー	09.09→	12V, 45Ah, 325A		0 986 A02 786	
177 1112	.дур M2 1.01	00.00	12V, 48Ah, 450A		0 092 S47 184	
弗 M4	哈弗 M4 1.5 i	12.11→	12V, 45Ah, 325A		0 986 A02 786	
	A21		12V, 48Ah, 450A		0 092 S47 184	
<u> </u>	炫丽 1.3 i	06.08-03.10	12V, 45Ah, 325A		0 986 A02 787	
	7-122	12.08→	12V, 45Ah, 350A	0 092 S37 424		
	炫丽 1.5 i	10.08→	12V, 45Ah, 325A		0 986 A02 787	
弗	赛弗 2.2 i 4WD	05.03-09.10	12V, 60Ah, 520A		0 986 A02 607	
翼	腾翼 1.5 i C20R	12.10→	12V, 45Ah, 325A		0 986 A02 786	
			12V, 48Ah, 450A		0 092 S47 184	
	腾翼 1.5 i C30	04.10→	12V, 55Ah, 450A		0 986 A02 818	
	腾翼 1.5 T V80	12.11-01.14	12V, 60Ah, 400A		0 986 A02 789	
			12V, 60Ah, 530A		0 092 S47 186	
	腾翼 2.0 i V80	08.07-01.14	12V, 60Ah, 400A		0 986 A02 789	
			12V, 60Ah, 530A		0 092 S47 186	
灵	精灵 1.3 i	01.08-12.10	12V, 36Ah, 180A	0 092 S37 381		
			12V, 36Ah, 310A		0 986 A02 781	
铃	赛铃 2.2 i CC1027	03.01-07.10	12V, 70Ah, 640A	0 986 A02 332		
	赛铃 3.2 D	12.05-06.11	12V, 55Ah, 550A	0 092 S37 396		
			12V, 55Ah, 610A		0 986 A02 826	
			12V, 63Ah, 610A		0 092 S47 192	
骏	赛骏 2.2 i	01.04-03.09	12V, 60Ah, 290A		0 092 S47 103	
			12V, 60Ah, 475A		0 986 A02 793	
			12V, 60Ah, 520A		0 986 A02 607	
酷	赛酷 2.2 i	10.03-04.08	12V, 70Ah, 640A	0 986 A02 332		
	赛酷 2.4 i	04.06-06.11	12V, 70Ah, 640A	0 986 A02 332		
	赛酷 2.8	05.09→	12V, 60Ah, 520A		0 092 S37 380	
	赛酷 2.8 D	09.06→	12V, 70Ah, 640A	0 986 A02 332		
影	赛影 2.2 i	10.03-02.10	12V, 60Ah, 290A		0 092 S47 103	
			12V, 60Ah, 450A	0 092 S37 433		
			12V, 60Ah, 475A		0 986 A02 793	
			12V, 60Ah, 520A		0 986 A02 607	
			12V, 60Ah, 550A		0 092 S47 189	
	赛影 2.8 D	06.08-03.10	12V, 60Ah, 290A		0 092 S47 103	
			12V, 60Ah, 475A		0 986 A02 793	
1.61-			12V, 60Ah, 520A		0 986 A02 607	
告熊	酷熊 1.5 i	10.08-01.13	12V, 45Ah, 325A		0 986 A02 786	
			12V, 48Ah, 450A		0 092 S47 184	
哈飞(松布	支江)			_		
H (1411	u <i>/</i> =					
意	中意 0.8 i	01.97-06.05	12V, 45Ah, 325A		0 986 A02 788	
			12V, 45Ah, 350A	0 092 S37 384		
			12V, 58Ah, 510A			0 092 S57 00
	中意 0.9 i	01.99-07.07	12V, 45Ah, 350A		0 092 S37 384	
	中意 1.0 i	01.99-05.11	12V, 45Ah, 325A		0 986 A02 788	
			12V, 45Ah, 350A	0 092 S37 384		
			12V, 48Ah, 450A		0 092 S47 182	
			12V, 58Ah, 510A			0 092 S57 00
	中意 1.1 i	01.00-03.11	12V, 45Ah, 325A		0 986 A02 788	
			12V, 45Ah, 350A	0 092 S37 384		
			12V, 58Ah, 510A			0 092 S57 00
意	民意 0.9 i	01.03-12.09	12V, 45Ah, 325A		0 986 A02 788	
			12V, 45Ah, 350A	0 092 S37 384		
	<u></u>	04.00.5	12V, 58Ah, 510A		0.002.121	0 092 S57 00
	民意 1.0 i	01.03-06.13	12V, 45Ah, 325A	0.000.00	0 986 A02 788	
			12V, 45Ah, 350A	0 092 S37 384	0.002.245.15	
			12V, 48Ah, 450A		0 092 S47 182	0.000.6==
		10.07	12V, 58Ah, 510A		0.000 100 701	0 092 S57 00
		12.07→	12V, 45Ah, 325A	0.000.00	0 986 A02 786	
			12V, 45Ah, 350A	0 092 S37 386	0.000.047.404	
			12V, 48Ah, 450A		0 092 S47 184	0.000.057.00
	日本 4.4 :	01.00.01.11	12V, 58Ah, 510A		0.000.047.400	0 092 S57 02
	民意 1.1 i	01.03-04.11	12V, 48Ah, 450A		0 092 \$47 182	
		01.03→	12V, 45Ah, 325A	0.000.007.004	0 986 A02 788	
			12V, 45Ah, 350A	0 092 S37 384		0.000.057.00
			12V, 58Ah, 510A			0 092 S57 00
					<u> </u>	Ţ
				▼	• • • • • • • • • • • • • • • • • • •	▼
				With a money	William Co Hongh	BOSCH
					(A) BOSCH	(A) BOSCH
				⊜ BOSCH	CA Preside	00000

哈飞▶









S3

S4








S5

		41	参数	动能	动力神	银侠
哈飞(接上页)						
民意	民意 1.3 i	09.05-09.11	12V, 45Ah, 325A		0 986 A02 788	
			12V, 45Ah, 350A	0 092 S37 384		0.000 057 000
		10 12-07 14	12V, 58Ah, 510A 12V, 45Ah, 325A		0 986 A02 788	0 092 S57 002
百利	百利 0.9 i	10.03-08.07	12V, 45Ah, 325A		0 986 A02 788	
- 1.2	H 13 - 10 -		12V, 45Ah, 350A	0 092 S37 384		
			12V, 58Ah, 510A			0 092 S57 002
松花江	松花江 1.0 i	10.02→	12V, 45Ah, 325A		0 986 A02 787	
		06.09→	12V, 48Ah, 450A		0 092 S47 183 0 092 S37 384	
黑豹	 黑豹 1.8 D	08.09-08.11	12V, 45Ah, 350A 12V, 100Ah, 700A		0 092 537 407	
路宝	路宝 1.0 i		12V, 45Ah, 350A	0 092 S37 384	0002007.101	
			12V, 45Ah, 325A		0 986 A02 788	
	路宝 1.1 i	12.03-05.13	12V, 36Ah, 310A		0 986 A02 782	
			12V, 40Ah, 340A		0 092 S47 180	
			12V, 45Ah, 325A 12V, 45Ah, 350A	0 092 S37 384	0 986 A02 788	
			12V, 45AH, 550A 12V, 58Ah, 510A	0 092 331 304		0 092 S57 002
	路宝 1.3 i	09.04-05.11	12V, 45Ah, 350A	0 092 S37 384		000200.002
路 尊	路尊 1.0 i	08.08→	12V, 45Ah, 325A		0 986 A02 787	
		12.08→	12V, 45Ah, 325A		0 986 A02 788	
	路尊 1.3 i	04.07-03.11	12V, 45Ah, 325A		0 986 A02 787	
÷ =	路尊 1.5 i	04.07-12.11	12V, 45Ah, 325A		0 986 A02 787	
赛马	赛马 1.3 i	07.03-06.09	12V, 45Ah, 325A	0.000.007.004	0 986 A02 788	
			12V, 45Ah, 350A 12V, 58Ah, 510A	0 092 S37 384		0 092 S57 002
	赛马 1.5 i	12.08→	12V, 35Ah, 316A		0 986 A02 788	0 0 3 2 3 3 7 0 0 2
	22 3 2101		12V, 45Ah, 350A	0 092 S37 384	7777777	
			12V, 58Ah, 510A			0 092 S57 002
	赛马 1.6 i	07.03-02.09	12V, 65Ah, 490A		0 986 A02 791	
			12V, 65Ah, 520A	0 092 S37 418		
赛豹	赛豹 1.6 i	10.04-06.12	12V, 65Ah, 490A	0.000.007.440	0 986 A02 791	
	赛豹 1.8 i	12.05-06.08	12V, 65Ah, 520A	0 092 S37 418	0.006 402 701	
	焚 初 1.01	12.05-06.08	12V, 65Ah, 490A 12V, 65Ah, 520A	0 092 S37 418	0 986 A02 791	
			12V, 03AII, 320A	0 0 3 2 3 3 7 4 1 0		
海马						
M5	M5 1.6 i	11.13→	12V, 65Ah, 520A		0 092 S37 418	
S5	S5 1.6 i	10.13→	12V, 60Ah, 520A		0 092 S37 380	
S7	S7 2.0 i	02.13→	12V, 65Ah, 520A		0 092 S37 418	
				0 092 S37 418		
V30	V30 1.5 i	09.12→	12V, 65Ah, 520A	0 092 S37 418		
王子 丘比特	王子 1.1 i 丘比特 1.3 i	12.09→	12V, 65Ah, 490A		0 986 A02 791	
<u> </u>		02.09→ 02.09-08.14	12V, 65Ah, 490A 12V, 55Ah, 500A	0 092 S37 393	0 986 A02 791	
海马 3	海马 3 1.6 i	04.09-12.10	12V, 55Ah, 500A	0 092 \$37 393		
	海马 3 1.8 i		12V, 55Ah, 500A	0 092 S37 393		
海马 7	海马 7 2.0 i	09.09→	12V, 80Ah, 680A		0 986 A02 612	
海福星	海福星 1.5 i	10.10-04.14	12V, 65Ah, 490A		0 986 A02 791	
	海福星 1.6	02.09-02.10	12V, 65Ah, 490A		0 986 A02 791	
	海福星 1.6 i 海福星 1.8 i	12.03-12.10	12V, 65Ah, 490A		0 986 A02 791	
奥路卡		08.02-06.08 06.12→	12V, 65Ah, 490A 12V, 45Ah, 350A		0 986 A02 791 0 092 S37 384	
英呵下 普力马	<u> </u>	04.09→	12V, 45Ah, 490A		0 986 A02 791	
H 73 -3	普力马 1.8 i	05.02-07.08	12V, 65Ah, 490A		0 986 A02 791	
		11.03→	12V, 65Ah, 490A		0 986 A02 791	
福美来	福美来 1.6 i	05.02-11.10	12V, 65Ah, 490A		0 986 A02 791	
			12V, 65Ah, 520A	0 092 S37 418		
		04.09→	12V, 65Ah, 465A		0 092 \$47 102	
			12V, 65Ah, 550A		0 986 A02 604	
华泰						
圣达菲	圣达菲 1.8 T	12.06→	12V, 70Ah, 600A		0 986 A02 797	
	圣达菲 2.0 D	04.06-10.13	12V, 70Ah, 600A		0 986 A02 797	
	圣达菲 2.0 i 圣达菲 2.5 D	08.10→	12V, 70Ah, 600A		0 986 A02 797	
	至达非 2.5 D 圣达菲 2.7 i	01.01-06.02 01.06→	12V, 70Ah, 600A 12V, 70Ah, 600A		0 986 A02 797 0 986 A02 797	
吉田	吉田 3.0 i	01.01-01.09	12V, 70Ah, 600A	0 092 \$37 391	0 000 NOZ 101	
			12V, 80Ah, 622A		0 986 A02 815	
特拉卡	特拉卡 2.4 i	06.08→	12V, 93Ah, 680A			0 092 S57 027
	特拉卡 2.9 D	08.03-02.09	12V, 80Ah, 622A		0 986 A02 815	
	特拉卡 3.5 i	01.02-11.09	12V, 70Ah, 550A 12V, 70Ah, 600A	0 092 S37 420	0 986 A02 797	
黑豹						
	N73 44. 4 4 7 7	00.00	101/ 051/		0.000 / 000	
黑豹	黑豹 1.6 D	03.06-06.09 12.11-06.14	12V, 65Ah, 490A 12V, 65Ah, 490A		0 986 A02 791 0 986 A02 791	
	黑豹 1.8 D	07.03-06.09	12V, 65Ah, 490A		0 986 A02 791	
	M 44 0 0 :	12.11→	12V, 65Ah, 490A	0.000.100	0 986 A02 791	
	黑豹 2.2 i	01.04-08.07	12V, 70Ah, 640A	0 986 A02 332		




















参数

S3 动能

S4 动力神

S5 银侠

本田						
CR-V	CR-V III 2.0 i	12.06-06.14	12V, 45Ah, 325A 12V, 48Ah, 450A		0 986 A02 786 0 092 S47 184	
	CR-V IV 2.0 i	11.11→	12V, 45Ah, 325A		0 986 A02 786	
	CR-V IV 2.4 i 4X4	11.11→	12V, 48Ah, 450A 12V, 65Ah, 490A		0 092 S47 184 0 986 A02 791	
CR-V [RD]	CR-V Vtec 2.0 i	05.02-09.13	12V, 45Ah, 350A	0 092 S37 424	0 000 702 702	
			12V, 70Ah, 550A	0 092 S37 420		
CR-V [RD7]	CR-V 2.4 i 4x4	10.04-09.09	12V, 70Ah, 600A 12V, 45Ah, 325A		0 986 A02 797 0 986 A02 786	
Ch-v [hb/]	GIT V 2.414X4	10.04-03.03	12V, 48Ah, 450A		0 092 S47 184	
			12V, 60Ah, 490A		0 986 A02 603	
CR-V [RE]	CR-V 2.4 i	01.06-06.14	12V, 45Ah, 325A 12V, 48Ah, 450A		0 986 A02 786 0 092 S47 184	
			12V, 40Ah, 490A		0 986 A02 603	
飞度	飞度 1.3 i	04.08→	12V, 36Ah, 310A		0 986 A02 782	
	飞度 1.5 i	03.14→	12V, 40Ah, 340A 12V, 36Ah, 310A		0 092 S47 180 0 986 A02 782	
	0反1.51	05.14	12V, 40Ah, 340A		0 092 S47 180	
	飞度 1.5 i 掀背车	04.08→	12V, 45Ah, 325A		0 986 A02 786	
			12V, 45Ah, 350A 12V, 48Ah, 450A	0 092 S37 386	0 092 S47 184	
			12V, 58Ah, 510A		0 092 547 164	0 092 S57 024
飞度 [GD]	飞度 1.3 i	04.03-12.09	12V, 45Ah, 325A		0 986 A02 786	
			12V, 45Ah, 350A	0 092 S37 386	0.000 647 404	
			12V, 48Ah, 450A 12V, 58Ah, 510A		0 092 S47 184	0 092 S57 024
	飞度 1.5 i	03.04-06.14	12V, 36Ah, 310A		0 986 A02 782	0 002 001 021
			12V, 40Ah, 340A		0 092 S47 180	
			12V, 45Ah, 325A 12V, 45Ah, 350A	0 092 S37 386	0 986 A02 786	
			12V, 48Ah, 450A	0 032 331 300	0 092 S47 184	
艾力绅	艾力绅 2.4 i	03.12→	12V, 45Ah, 400A		0 986 A02 600	
时韵 [RN] 思迪		12.03-07.06 12.05-07.10	12V, 45Ah, 325A 12V, 45Ah, 325A		0 986 A02 786 0 986 A02 786	
心坦	心區 1.51	12.05-07.10	12V, 48Ah, 450A		0 092 S47 184	
	思迪 1.5 i	03.04-06.14	12V, 36Ah, 310A		0 986 A02 782	
思铂睿	思铂睿 2.4 i	06.09-06.14	12V, 40Ah, 340A		0 092 S47 180 0 986 A02 788	
<u> </u>	芯珀音 2.41 思域 1.8 i	03.11→	12V, 45Ah, 325A 12V, 45Ah, 325A		0 986 A02 786	
			12V, 48Ah, 450A		0 092 S47 184	
m ++ real	思域 2.0 i	03.11-07.13	12V, 45Ah, 325A		0 986 A02 786	
思域 [FA]	思域 1.8 i	12.05-08.12	12V, 45Ah, 325A 12V, 45Ah, 350A	0 092 S37 386	0 986 A02 786	
			12V, 48Ah, 450A		0 092 S47 184	
思铭	思铭 1.8 i	10.11→ 05.13→	12V, 45Ah, 350A	0 092 S37 384	0.000 400 700	
凌派	凌派 1.8 i	05.13→	12V, 60Ah, 400A 12V, 60Ah, 530A		0 986 A02 789 0 092 S47 186	
奥德赛	奥德赛 2.4 i	11.04-02.10	12V, 65Ah, 490A		0 986 A02 791	
南海客[110]	南徳宝 2 2 :	01.01.06.02	12V, 65Ah, 520A	0 092 S37 418	0.000.647.400	
奥德赛 [HG]	奥德赛 2.3 i	01.01-06.03	12V, 65Ah, 465A 12V, 65Ah, 550A		0 092 S47 102 0 986 A02 604	
奥德赛 [RB1]	奥德赛 2.4 i	10.03-10.08	12V, 65Ah, 465A		0 092 S47 102	
<i>₩</i> ##	<i>₩</i> ## 4 <i>Γ</i> :	00.00	12V, 65Ah, 550A	0.000.007.000	0 986 A02 604	
锋范 雅阁	锋范 1.5 i 雅阁 2.0 i	09.08→ 12.07-09.13	12V, 36Ah, 280A 12V, 65Ah, 465A	0 092 S37 382	0 092 S47 102	
3210	3210 2.01	12.07 00.10	12V, 65Ah, 550A		0 986 A02 604	
	T#\\T 0 0 1 0 1	10.07	12V, 70Ah, 550A	0 092 S37 420		
	雅阁 3.0 i Sedan 雅阁 IX 2.0 i	12.97→ 06.13→	12V, 93Ah, 680A 12V, 65Ah, 490A		0 986 A02 791	0 092 S57 027
	雅阁 IX 2.4 i	06.13→	12V, 60Ah, 490A		0 986 A02 602	
	雅阁 VI 2.3 i	01.98-12.02	12V, 65Ah, 465A		0 092 S47 102	
雅阁 [CL7]	雅阁 2.0 i	01.01-12.08	12V, 65Ah, 550A 12V, 52Ah, 480A		0 986 A02 604 0 092 S47 025	
NEIRO [OL/]	/µш:пп Z.UI	01.01-12.08	12V, 52AH, 480A 12V, 60Ah, 290A		0 092 \$47 025	
			12V, 60Ah, 490A		0 986 A02 602	
雅阁 [CM]	雅阁 3.0 i	09.02-02.06	12V, 65Ah, 550A 12V, 65Ah, 490A		0 986 A02 604 0 986 A02 791	
arter fow]	/µш (р. О. I	00.02-02.00	12V, 65Ah, 520A	0 092 S37 418	0 300 MUZ 131	
	WH 255		12V, 93Ah, 680A			0 092 S57 027
	雅阁 VII 2.4 i 雅阁 V-Tec VII 2.4 i	10.05-08.07 01.01-11.09	12V, 65Ah, 465A 12V, 65Ah, 465A		0 092 S47 102 0 092 S47 102	
	/μ⊏րեց V⁻IEC VII∠.41	01.01-11.09	12V, 65Ah, 465A 12V, 65Ah, 550A		0 986 A02 604	
雅阁 [CP]	雅阁 VIII 2.4 i	09.07-08.15	12V, 65Ah, 465A		0 092 S47 102	
新爾德 賽	雅阁 VIII 3.5 i	09.07→	12V, 65Ah, 465A		0 092 \$47 102	
新奥德赛	新奥德赛 2.4 i	08.09→	12V, 65Ah, 490A 12V, 65Ah, 520A	0 092 S37 418	0 986 A02 791	
歌诗图	歌诗图 2.4 i	01.12→	12V, 70Ah, 600A		0 986 A02 797	
	歌诗图 3.5 i	08.10→	12V, 70Ah, 600A		0 986 A02 797	



汇众 · 现代 · 英菲尼迪 ▶

海马 ・ 华泰 ・ 黑豹 ・ 本田 ・ 红旗 ・ 红星 ・ 黄海 ・ 幻灵 ・ 华普 ・ 华西 ・ 汇众 ・ 现代 ・ 英菲尼迪













S3

S4







S5



###			4	参数	动能	动力神	银侠
HO3 名	红旗						
日の34.31		1100 0 0 :	10.05.00.00	401/ 7041 5504	0.000.007.400		
世紀章 世紀章 1.81	HQ3	HQ3 3.01	12.05-03.09		0 092 537 420	0 986 A02 797	
#記章 2.0		HQ3 4.3 i	12.05-02.09		0 092 S37 420	0.096 402 707	
世元星 2-01 6-6-04-1.06 12V, 63Ab, 550A 1 できままり 12V, 63Ab, 550A 1 できままり 12V, 63Ab, 550A 0 8986 A02 210 1 できままり 12V, 63Ab, 550A 0 8986 A02 210 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1	世纪星	世纪星 1.8 i	01.06-06.09		0 092 S37 398	0 900 AUZ 191	
世紀 2 2 0 1 12 0 2 0 5 0 1 2 0 5 0 5 0 0 9 8 6 A 0 2 10		世纪星20D	06 04-01 06		0.092 \$37 398	0 986 A02 810	
順世				12V, 63Ah, 550A	0 002 001 000		
明社 明社 181 1102-06.09 12V, 63Ab, 550A							
*		明仕 1.8 i	11.02-06.09	12V, 63Ah, 550A		0 986 A02 810	
小貴族	浜 舰	旗舰 4.61	03.05-08.07	12V, 63AN, 550A		0 986 A02 810	
大	红星						
大柴神 大柴神2.21 08.05→ 12V, 60Ah, 580A 0986 A02 827 幻灵	小贵族	小贵族 1.1 i	02.07→	12V, 45Ah, 350A	0 092 S37 383		
大楽神 大楽神 2.21 08.05 → 12V, 60Ah, 580A 0925 37 402 37 30 986 A02 827 37 30 986 A02 828 38 30 986 A02 805 30 986	44.35						
公司	黄海						
# 音	大柴神	大柴神 2.2 i	08.05→	12V, 60Ah, 580A			
# 音							
#祖	幻灵						
海斑 海斑 1.3 i 11.03-01.09 127.55AA, 450A 127.55AA, 450A 12.05-08.10 127.05AA, 450A 0.986 A02.218 12.05-08.10 127.05AA, 450A 0.992 \$47.193 0.986 A02.227 127.05AA, 450A 0.992 \$47.193 0.986 A02.227 127.05AA, 450A 0.992 \$47.193 0.986 A02.287 127.05AA, 450A 0.992 \$47.193 0.986 A02.287 127.05AA, 450A 0.992 \$47.186 0.99	幻灵	幻灵 3.7 D	03.05-09.05	12V, 70Ah, 640A	0 986 A02 332		
海域 海域 1.31 11.03-01.09 12V, 55Ah, 450A 0 996 A022 818 11.03-01.09 12V, 55Ah, 450A 0 996 A022 818 12V, 55Ah, 450A 0 996 A022 819 12V, 55Ah, 450A 0 996 A022 827 12V, 55Ah, 450A 0 996 A022 828 18 12V, 55Ah, 450A 0 996 A022 805 12V, 150Ah, 150A 0 996	华普						
海域 海域 1.31 11.03-01.09 12V, 55Ah, 450A 0 996 A022 818 11.03-01.09 12V, 55Ah, 450A 0 996 A022 818 12V, 55Ah, 450A 0 996 A022 819 12V, 55Ah, 450A 0 996 A022 827 12V, 55Ah, 450A 0 996 A022 828 18 12V, 55Ah, 450A 0 996 A022 805 12V, 150Ah, 150A 0 996	海讯	海讯 1.8 i AB	01.06-11.08	12V. 48Ah. 450A	0 092 S37 402		
12.05-08.10 12V, 60Ah, 580A 0986 A02 817 12.05-08.11 12V, 60Ah, 580A 0986 A02 817 12.05-08.11 12V, 60Ah, 450A 0992 \$47 193 0986 A02 827 12V, 60Ah, 450A 12V, 56Ah, 450A 0992 \$47 186 12V, 60Ah, 530A 12V, 60Ah, 530A 12V, 60Ah, 530A 0998 \$402 805 12V, 60Ah, 530A 12V, 60Ah, 680A 12V, 60Ah, 490A 12V,				12V, 55Ah, 450A	0 002 001 102		
海域 1.5 i 12.05-05.11 12V,60Ah,580A 9086A02 #133 9086A02 #133 9086A02 #133 9086A02 #133 9086A02 #133 9086A02 #134 9086A02 #135 9086A02	海域	海域 1.3 i					
無減 1.8 i 12.04-99 07 12V, 48Ah, 450A 12V, 58Ah, 450A 12V, 58Ah, 450A 0986 A02 818		海域 1.5 i				0 092 S47 193	
海景 1.5 i 09.09 1 22 (60A) 400A 09.86 A02 789 129 (60A) 530A 09.86 A02 805 129 (60A) 530A 09.86 A02 80		海域 1.8 i	12.04-09.07	12V, 48Ah, 450A	0 092 S37 402	0 986 A02 827	
海景 1.8 i 12.08 → 12.4 (80Ah, 400A	海景	海景 1.5 i	09.09→				
12½, 60Ah, 530A				12V, 60Ah, 530A		0 092 S47 186	
学西 (17.0 - 17.		冲京 1.8 1					
年西 2.4i	海锋	海锋 1.5 i	04.04-06.11				
年西 2.4i	华西						
本西 2.5							
#西 2.5	华西	华西 2.4 i	07.04-01.05	, , .	0 986 A02 732	0 986 A02 805	
12½, 100Ah, 580A 12½, 100Ah, 512A 12½, 100Ah, 50AA 12½, 10AAh, 40AA 12½, 10AAh, 40AA 12½, 10AAh, 40AA 12½, 10AAh, 40AA 12½, 10AA		the second		12V, 100Ah, 700A			
年西 2.5 i 03.03-12.10 12V, 100Ah, 512A 12V, 100Ah, 50AD 12V, 100Ah, 70OA 12V, 10OAh, 512A 12V, 50Ah, 49OA 12V, 50		华西 2.5	08.07-07.10		0 986 A02 732	0 986 A02 805	
#西 2.8 D		₩. 2.5:	02 02 12 10				
年西 2.8 D		平四 2.51	03.03-12.10		U 966 AUZ 732	0 986 A02 805	
12V, 100Ah, 680A 12V, 100Ah, 700A 0 936 A02 805 12V, 100Ah, 680A 12V, 100Ah, 680A 12V, 100Ah, 680A 12V, 100Ah, 680A 12V, 100Ah, 700A 0 936 A02 805 12V, 100Ah, 700A 12V, 100Ah, 700A 0 936 A02 805 12V, 100Ah, 680A 12V, 100Ah, 700A 0 936 A02 805 12V, 100Ah, 700A 0 936 A02 805 12V, 100Ah, 700A 12V, 100Ah, 700A 0 936 A02 805 12V, 100Ah, 700A 12V, 100Ah, 700A 0 936 A02 805 12V, 100Ah, 700A 12V, 100Ah, 700A 0 936 A02 805 12V, 100Ah, 700A 12V, 100Ah, 700A 0 936 A02 805 12V, 100Ah, 700A 12V, 100Ah, 70A		<u> </u>	03 03-06 07				
年西 3.4 D 03.03-05.08 12V, 100Ah, 512A 12V, 100Ah, 680A 12V, 100Ah, 680A 12V, 100Ah, 680A 12V, 100Ah, 700A 092\$37 407		구럽 2.00	03.00 00.07	12V, 100Ah, 680A		0 986 A02 805	
接西 3.7 D		<u>华西 3.4 D</u>	03.03-05.08	, ,			
単西 3.7 D				12V, 100Ah, 680A		0 986 A02 805	
日本		华西 3.7 D	03.03-05.08				
#西 3.9 D 01.04→ 12V, 100Ah, 512A 12V, 100Ah, 512A 12V, 100Ah, 500A 12V, 100Ah, 700A 092 \$37 407					0.092 \$37 407	0 986 A02 805	
12V, 100Ah, 700A 0.092 \$37 407 12V, 100Ah, 512A 12V, 100Ah, 512A 12V, 100Ah, 512A 12V, 100Ah, 700A 12V, 100Ah, 512A 12V, 100Ah, 512A 12V, 100Ah, 512A 12V, 100Ah, 512A 12V, 100Ah, 580A 12V, 100Ah, 680A 12V, 100Ah, 680A 12V, 100Ah, 700A 0.092 \$37 407 12V, 100Ah, 680A 12V, 100Ah, 680A 12V, 100Ah, 700A 0.092 \$37 407 12V, 100Ah, 680A 12V, 100Ah, 700A 0.092 \$37 407 12V, 100Ah, 640A 12V, 100Ah, 640A 12V, 100Ah, 640A 0.092 \$37 407 12V, 100Ah, 640A 12V, 100Ah, 640		华西 3.9 D	01.04→	12V, 100Ah, 512A			
#西 3.9 i 03.03-04.07 12V, 100Ah, 512A 12V, 100Ah, 680A 12V, 100Ah, 700A 092 \$37 407					0.092 \$37 407	0 986 A02 805	
#西 4.1 D		华西 3.9 i	03.03-04.07	12V, 100Ah, 512A		0.000.100.005	
12V, 100Ah, 680A 12V, 100Ah, 700A 0 092 \$37 407					0 092 S37 407	U 986 AU2 805	
		华西 4.1 D	03.03-06.07		0 986 A02 732	0 986 402 805	
伊思坦纳					0 092 S37 407	0 000 AUE 000	
现代 i30 [GD] i30 1.6 i 08.09-09.14 12V, 60Ah, 490A 0986 A02 602 ix35 [LM, EL] ix35 2.0 01.10-08.13 12V, 60Ah, 490A 0986 A02 602 12V, 75Ah, 630A 0998 A02 602 00992 \$58 384	汇众						
i30 [GD] i30 1.6 i 08.09-09.14 12V, 60Ah, 490A 0 986 A02 602 ix35 [LM, EL] ix35 2.0 01.10-08.13 12V, 60Ah, 490A 0 986 A02 602 12V, 75Ah, 630A 0 092 \$58 384	伊思坦纳	伊思坦纳 2.3 i	08.04→	12V, 70Ah, 640A	0 986 A02 332		
i30 [GD] i30 1.6 i 08.09-09.14 12V, 60Ah, 490A 0 986 A02 602 ix35 [LM, EL] ix35 2.0 01.10-08.13 12V, 60Ah, 490A 0 986 A02 602 12V, 75Ah, 630A 0 092 \$58 384	现代						
ix35 [LM, EL] ix35 2.0 01.10-08.13 12V, 60Ah, 490A 0986 A02 602 12V, 75Ah, 630A 0092 \$58 384				1011 05:11			
12V, 75Ah, 630A 0 092 S58 384							
111197 578 183	- / 4						



ix35 2.0 i 4x4

ix35 2.4 i

11.10→

12V, 60Ah, 580A

01.10→ 12V, 70Ah, 600A








0 092 S58 384 0 092 S58 385

0 092 S47 193 0 986 A02 827 0 986 A02 797









海马 ・ 华泰 ・ 黑豹 ・ 本田 ・ 红旗 ・ 红星 ・ 黄海 ・ 幻灵 ・ 华普 ・ 华西 ・ 汇众 ・ 现代 ・ 英菲尼迪





















S3 动能 S4 动力神



工 於						
五十铃						
N系列	N系列 2.8 D		12V, 70Ah, 640A	0 986 A02 332		
T 系列 五十铃	T 系列 2.8 D 五十铃 2.6 i	09.09→ 04.07→	12V, 80Ah, 400A 12V, 70Ah, 640A	0 092 S37 391 0 986 A02 332		
	五十铃 2.8 D	03.02-07.09	12V, 70Ah, 640A	0 986 A02 332		
竞技者	五十铃 3.0 D 竞技者 2.5 i	03.10→ 05.07-06.11	12V, 70Ah, 640A 12V, 70Ah, 550A	0 986 A02 332 0 092 S37 421		
	*************************************	00.00.10.00	12V, 70Ah, 600A		0 986 A02 798	
	竞技者 2.6 i	09.03-10.08	12V, 70Ah, 550A 12V, 70Ah, 600A	0 092 S37 421	0 986 A02 798	
	竞技者 2.8 D	09.03-06.09	12V, 70Ah, 550A	0 092 S37 421		
		06.08→	12V, 70Ah, 600A 12V, 70Ah, 550A	0 092 S37 421	0 986 A02 798	
			12V, 70Ah, 600A		0 986 A02 798	
	竞技者 3.2 i 4WD	01.00→	12V, 70Ah, 550A 12V, 70Ah, 600A	0 092 S37 421	0 986 A02 798	
			12V, 70AII, 000A		0 300 A02 130	
依维柯						
依维柯	依维柯 2.5 D	11.06→	12V, 120Ah, 740A		0 092 S37 410	
120	依维柯 2.8 D	03.02-07.09	12V, 120Ah, 740A		0 092 S37 410	
		10.03-06.08 09.08→	12V, 80Ah, 640A 12V, 70Ah, 640A	0 092 S37 401 0 986 A02 332		
		03.00 /	12V, 80Ah, 640A	0 092 S37 401		
中油	依维柯 2.8 D 4x4	11.06→	12V, 80Ah, 640A		0 092 \$37 401	
宝迪	宝迪 2.2 i 宝迪 2.8 D	01.04-03.09 02.03-03.09	12V, 65Ah, 550A 12V, 65Ah, 550A		0 986 A02 605 0 986 A02 605	
	宝迪 3.0 D	09.08→	12V, 65Ah, 550A		0 986 A02 605	
畅达 都灵	畅达 2.8 D 都灵 2.8 D	02.02→ 08.04-06.08	12V, 80Ah, 640A 12V, 65Ah, 465A	0 092 S37 401	0 092 S47 102	
神火	〒火 2.0 ∪	00.04-00.08	12V, 65Ah, 550A		0 092 547 102 0 986 A02 604	
		05.06→	12V, 70Ah, 640A	0 986 A02 332		
JAC(江淮	海车 \					
	,	44.61.5	401/ 10011 5111			
HFC 系列	HFC1061K2 3.9 D HFC 系列 2.4 i		12V, 100Ah, 700A 12V, 70Ah, 500A	0 092 S37 407	0 986 A02 796	
帅铃	帅铃 1.8 D	11.04-04.07	12V, 70Ah, 640A	0 986 A02 332	0 300 A02 130	
	14 th 0 0 D	06.07→	12V, 70Ah, 640A	0 986 A02 332		
	帅铃 2.2 D	$01.01-06.07$ $01.09 \rightarrow$	12V, 70Ah, 640A 12V, 70Ah, 640A	0 986 A02 332 0 986 A02 332		
	帅铃 2.5 D	07.08→	12V, 70Ah, 640A	0 986 A02 332		
	帅铃 2.8 D	05.05→	12V, 70Ah, 640A 12V, 65Ah, 520A	0 986 A02 332	0.000.007.440	
		01.11→ 07.06→	12V, 70Ah, 640A	0 986 A02 332	0 092 S37 418	
	帅铃 3.3 D	12.06→	12V, 70Ah, 640A	0 986 A02 332		
	帅铃 3.7 D 帅铃 4.1 D	08.03-05.07 03.02-04.07	12V, 70Ah, 640A 12V, 70Ah, 640A	0 986 A02 332 0 986 A02 332		
	<u>帅铃 4.6 D</u>		12V, 70Ah, 640A	0 986 A02 332		
同悦	同悦 1.3 i	06.08-08.14			0 986 A02 826	
	同悦 RS 1.3 i	08.08-06.14	12V, 63Ah, 610A 12V, 70Ah, 500A		0 092 S47 192 0 986 A02 796	
和悦	和悦 1.5 i	09.09→	12V, 45Ah, 325A		0 986 A02 787	
和悦 RS	和悦 RS 1.5 i	12.10→	12V, 65Ah, 580A 12V, 60Ah, 520A		0 986 A02 609 0 092 S37 380	
	和悦 RS 1.8 i	02.09→	12V, 45Ah, 325A		0 986 A02 787	
悦悦	悦悦 1.0 i	12.09→	12V, 48Ah, 450A 12V, 45Ah, 325A		0 092 S47 183 0 986 A02 787	
骏铃	骏铃 2.0 D	05.07→	12V, 70Ah, 640A	0 986 A02 332		
	骏铃 2.2 D 骏铃 2.5 D	01.09→	12V, 70Ah, 640A	0 986 A02 332		
	%	11.01→ 05.01→	12V, 70Ah, 640A 12V, 70Ah, 640A	0 986 A02 332 0 986 A02 332		
	骏铃 2.8 D	12.03→	12V, 70Ah, 640A	0 986 A02 332		
	骏铃 3.2 D 骏铃 3.3 D	03.03→ 05.02-05.07	12V, 70Ah, 640A 12V, 70Ah, 640A	0 986 A02 332 0 986 A02 332		
		11.07→	12V, 70Ah, 640A	0 986 A02 332		
	骏铃 3.7 D	07.02-10.06	12V, 70Ah, 640A	0 986 A02 332		
	骏铃 3.9 D	07.08→ 05.02→	12V, 70Ah, 640A 12V, 70Ah, 640A	0 986 A02 332 0 986 A02 332		
	骏铃 4.1 D	05.02-05.07	12V, 70Ah, 640A	0 986 A02 332		
康铃	康玲 3.7 D 康铃 1.8 D	03.02-07.11 10.01-06.11	12V, 140Ah, 540A 12V, 70Ah, 640A	0 092 S37 412 0 986 A02 332		
	康铃 2.0 D	06.01→	12V, 70Ah, 640A 12V, 70Ah, 640A	0 986 A02 332 0 986 A02 332		
	康铃 2.1 D	09.03-04.07	12V, 70Ah, 640A	0 986 A02 332		
	康铃 2.2 D	06.09→ 05.01-07.11	12V, 70Ah, 640A 12V, 70Ah, 640A	0 986 A02 332 0 986 A02 332		
	康铃 2.5 D	06.01-11.11	12V, 70Ah, 640A	0 986 A02 332		
	康铃 2.8 D 唐鈴 3.0 D	05.05-06.11	12V, 70Ah, 640A	0 986 A02 332		
	康铃 3.0 D 康铃 3.7 D	08.08→ 09.01→	12V, 70Ah, 640A 12V, 70Ah, 640A	0 986 A02 332 0 986 A02 332		
	康铃 3.9 D	10.03→	12V, 70Ah, 640A	0 986 A02 332		
	康铃 4.1 D 康铃 4.3 D	05.07→ 08.03-04.05	12V, 70Ah, 640A 12V, 70Ah, 640A	0 986 A02 332 0 986 A02 332		
	康铃 4.7 D	05.06-05.08	12V, 70Ah, 640A 12V, 70Ah, 640A	0 986 A02 332 0 986 A02 332		
THE ID	康铃 4.8 D	08.03-04.05	12V, 70Ah, 640A	0 986 A02 332		
瑞风	瑞风 1.9 D 瑞风 2.0 i	04.11→ 03.08→	12V, 80Ah, 400A 12V, 70Ah, 500A	0 092 S37 391	0 986 A02 796	
	瑞风 2.5 D	04.02-11.09	12V, 45Ah, 350A	0 092 S37 384	0 000 M02 100	
瑞风Ⅱ	瑞风Ⅱ2.0ⅰ	07.07-03.11	12V, 70Ah, 550A 12V, 70Ah, 600A	0 092 S37 420	0 986 A02 797	
			12V, I UAII, OUUA		0 500 AUZ 191	















		面	参数	S3 动能	S4 动力神	S5 银侠
瑞风Ⅱ	瑞风Ⅱ2.4ⅰ	10.03-06.08	12V, 68Ah, 650A		0 986 A02 610	
		10.03→	12V, 70Ah, 550A 12V, 70Ah, 600A	0 092 S37 420	0 986 A02 797	
	瑞风Ⅱ2.8D	08.07-05.14	12V, 70Ah, 550A 12V, 70Ah, 600A	0 092 S37 420	0 986 A02 797	
瑞风 S3	瑞风 S3 1.5 i	01.14→	12V, 60Ah, 450A	0 092 S37 433		
瑞风 S 5	瑞风 S5 2.0 i	10.12→	12V, 60Ah, 520A 12V, 70Ah, 500A		0 092 S37 388 0 986 A02 796	
瑞鹰	瑞鹰 1.9 D	04.08-03.13	12V, 60Ah, 520A 12V, 70Ah, 500A	0 092 S37 380 0 986 A02 796		
	瑞鹰 2.0 i	10.06-05.09 06.07-03.14	12V, 70Ah, 550A 12V, 60Ah, 520A	0 092 S37 420 0 092 S37 380		
		08.08-07.14	12V, 70Ah, 500A 12V, 70Ah, 550A	0 986 A02 796	0 092 S37 420	
	瑞鹰 2.4 i	07.04-03.14	12V, 70Ah, 530A 12V, 60Ah, 520A 12V, 70Ah, 500A	0 092 S37 380 0 986 A02 796	0 0 3 2 3 3 7 4 2 0	
			12V, 70AII, 500A	U 900 AUZ 7 90		
捷豹						
S-Type	S-Type 2.5 24V		12V, 100Ah, 830A			0 092 S50 130
XF [X250]	XF 3.0 D V6 XF 4.2 机械增压	03.09-10.15	12V, 100Ah, 830A 12V, 100Ah, 830A			0 092 S50 130 0 092 S50 130
	XF 5.0 V8		12V, 100Ah, 830A			0 092 S50 130
KJ [X350]	XJ 3.0 24V	03.03-07.10	12V, 74Ah, 680A			0 986 A02 334
KJ [X351]	XJ 8 4.2 32V XJ 3.0 V6	03.03-07.10 08.11→	12V, 74Ah, 680A 12V, 100Ah, 830A			0 986 A02 334 0 092 S50 130
(K 轿跑	XK 4.2 32V 轿跑		12V, 100Ah, 830A			0 092 S50 13
吉普						
- T - T	大切诺基 4.0 i 4x4	01.03-03 07	12V, 54Ah, 500A	0 092 S37 387		
/	大切诺基 4.7 i 4x4	12.03-03.07	12V, 48Ah, 450A	0 092 S37 404 0 092 S37 402		
	八90日至4.71484	12.05-05.07	12V, 54Ah, 500A	0 092 S37 387		
			12V, 74Ah, 680A	0 092 S37 404		0 986 A02 33
大切诺基 [WK2]	大切诺基 3.0 CRDi 4x4	04.11→	12V, 100Ah, 830A			0 092 S50 130
切诺基	切诺基 2.4 i 4WD 切诺基 2.5 i	06.04-12.06 01.96-07.04	12V, 48Ah, 450A	0 092 \$37 402		
	切伍基 2.51	01.96-07.04	12V, 48Ah, 450A 12V, 54Ah, 500A	0 092 S37 402 0 092 S37 387		
	- 四类甘 0.7:	00.04.10.00	12V, 60Ah, 580A	0 092 S37 404	0.000 400 007	
	切诺基 2.7 i 切诺基 4.0 i	06.04-12.06 01.90-04.04	12V, 60AH, 580A	0 092 S37 399	0 986 A02 827	
			12V, 70Ah, 650A		0 986 A02 618	
指南者 [MK] 指南者 [PK]	指南者 2.4 指南者 2.0 4x4	10.06→ 05.11→	12V, 60Ah, 540A 12V, 74Ah, 680A		0 092 S40 040	0 986 A02 334
指挥官 [XH]	指挥官 4.7 4x4	01.06→	12V, 48Ah, 450A	0 092 S37 402		0 300 A02 33
	长根中 5.7.4.4	04.00	12V, 74Ah, 680A	0.000.007.400		0 986 A02 334
	指挥官 5.7 4x4	01.06→	12V, 48Ah, 450A 12V, 74Ah, 680A	0 092 S37 402		0 986 A02 33
江南						
	m +T 0 0 :	00.00.10.00	101/ 7041- 0404	0.000 400 200		
奥拓	奥拓 0.8 i	08.03-10.08 $01.08 \rightarrow$	12V, 70Ah, 640A 12V, 36Ah, 180A	0 986 A02 332 0 092 S37 381		
			12V, 36Ah, 310A		0 986 A02 781	
金杯						
330	S30 1.5 i	11.11→	12V, 60Ah, 580A		0 092 S47 193	
金典	金典 2.0 i	12.06→	12V, 70Ah, 640A	0 986 A02 332	0 986 A02 827	
<u></u>	金典 2.1 D	01.07→	12V, 70Ah, 640A	0 986 A02 332		
	金典 2.2 D	01.07-07.11	12V, 60Ah, 400A	0.000.007.404	0 986 A02 790	
			12V, 60Ah, 450A 12V, 60Ah, 520A	0 092 S37 431 0 092 S37 406		
			12V, 60Ah, 530A		0 092 S47 187	
	金典 2.2 i 金典 2.4 D	03.01→ 08.09→	12V, 70Ah, 640A 12V, 70Ah, 640A	0 986 A02 332 0 986 A02 332		
	金典 2.4 i	03.01-07.11	12V, 70Ah, 640A	0 986 A02 332		
A 17	金典 2.8 D	04.06-09.09	12V, 70Ah, 640A	0 986 A02 332	0.000.007.404	
金杯	金杯 2.0 D 金杯 2.5 D	06.09→ 01.08→	12V, 70Ah, 550A 12V, 70Ah, 550A		0 092 S37 421 0 092 S37 421	
轻型货车	轻型货车 2.2 i	03.01-08.10	12V, 70Ah, 640A	0 986 A02 332		
	轻型货车3.2D	11.06→	12V, 100Ah, 512A 12V, 100Ah, 680A	0 986 A02 732	0 986 A02 805	
NO THE #	NO TU HE A	05.07.55	12V, 100Ah, 700A	0 092 S37 407		
阁瑞斯	阁瑞斯 2.0 i	05.07-08.14 $09.08 \rightarrow$	12V, 55Ah, 500A 12V, 70Ah, 640A	0 092 S37 393 0 986 A02 332		
	图瑞斯 2.4 i	09.04-06.11	12V, 70Ah, 640A	0 986 A02 332		
		07.07→	12V, 65Ah, 465A		0 092 \$47 102	
	阁瑞斯 2.5 D	06.08→	12V, 65Ah, 550A 12V, 70Ah, 640A	0 986 A02 332	0 986 A02 604	
				Ţ	Ţ	Ţ
				▼	1 / 1	8
				- HOREN	Was a	West BOSCH

金杯 • JMC • 凯马 • 开瑞 • 起亚 • 金龙 • 路虎汽车集团 ▶

五十铃 ・ 依维柯 ・ JAC ・ 捷豹 ・ 吉普 ・ 江南 ・ 金杯 ・ JMC ・ 凯马 ・ 开瑞 ・ 起亚 ・ 金龙 ・ 路虎汽车集团











BOSCH

(a) BOSCH







面	参数	S3 动能	S4 动力神	S5 银侠

金杯 (接上页) 阁瑞斯	阁瑞斯 2.7 i	01.01→	12V, 70Ah, 640A	0 986 A02 332		
7-110.741	[P] -[II] 701 2.7 T	05.04-11.08	12V, 68Ah, 650A	0 000 A02 002	0 986 A02 611	
孙	海狮 2.0 i	07.06→	12V, 60Ah, 475A		0 986 A02 793	
			12V, 60Ah, 520A		0 986 A02 607	
			12V, 60Ah, 550A		0 092 S47 189	
			12V, 93Ah, 680A			0 092 S57 02
		06.10→	12V, 60Ah, 450A	0 092 S37 433		
			12V, 60Ah, 520A		0 092 S37 388	
	海狮 2.2 i	10.01→	12V, 60Ah, 475A		0 986 A02 793	
			12V, 60Ah, 520A		0 986 A02 607	
			12V, 60Ah, 550A		0 092 S47 189	
			12V, 93Ah, 680A			0 092 S57 02
	No. of the last of	12.03→	12V, 70Ah, 640A	0 986 A02 332		
	海狮 2.4 i	03.99→	12V, 60Ah, 475A		0 986 A02 793	
			12V, 60Ah, 520A		0 986 A02 607	
			12V, 93Ah, 680A			0 092 S57 02
	Nevir a se	08.99→	12V, 60Ah, 550A		0 092 S47 189	
	海狮 2.5 D	08.08→	12V, 60Ah, 475A		0 986 A02 793	
			12V, 60Ah, 520A		0 986 A02 607	0.000.057.00
			12V, 93Ah, 680A			0 092 S57 02
JMC(江铃))					
7 R/ -	70 RH 2 4 D	02.10	121/ 7045 6004		0.006.400.700	
7胜	<u>驭胜 2.4 D</u> 驭胜 2.4 i	03.10→	12V, 70Ah, 600A 12V, 70Ah, 600A		0 986 A02 798	
	────────────────────────────────────	11.10→	,		0 986 A02 798	
- 川火	全顺 2.4 D 全顺 2.8 D	06.07→ 12.03→	12V, 66Ah, 550A		0 986 A02 819	
 [铃	至顺 2.8 D 江铃 2.8 D	08.01-03.09	12V, 66Ah, 550A 12V, 60Ah, 550A		0 986 A02 819	
- 14	┴져 2.0 U	08.01-03.09			0 092 S47 189 0 986 A02 793	
		00.01-06.11	12V, 60Ah, 475A 12V, 60Ah, 520A		0 986 A02 793 0 986 A02 607	
 l运	凯运 2.8 D	08.03-12.11	12V, 60An, 520A 12V, 36Ah, 180A	0 092 S37 381	0 300 AUZ 007	
<u>, , ≃</u>	pixe 2.0 U	00.03-12.11	12V, 36Ah, 180A 12V, 36Ah, 310A	0 092 337 381	0 986 A02 781	
		02.06→	12V, 36An, 310A 12V, 60Ah, 475A		0 986 A02 781 0 986 A02 793	
		02.00	12V, 60Ah, 520A		0 986 A02 793 0 986 A02 607	
			12V, 60Ah, 550A		0 986 A02 607 0 092 S47 189	
3典	宝典 2.0 i	08.03→			0 986 A02 793	
5 74	五典 2.01	06.03	12V, 60Ah, 475A 12V, 60Ah, 520A		0 986 A02 793	
	宝典 2.4 i	05.03→	12V, 60Ah, 475A		0 986 A02 793	
	五典 2.41	05.03	12V, 60Ah, 520A		0 986 A02 793	
	宝典 2.8 D	02.01→	12V, 60Ah, 475A		0 986 A02 793	
玉典 2.81	五兴 2.0 0	02.01	12V, 60Ah, 520A		0 986 A02 793	
			12V, 60Ah, 550A		0 092 S47 189	
		02.02-04.09	12V, 70Ah, 640A	0 986 A02 332	0 0 9 2 3 4 7 1 0 9	
		$08.03 \rightarrow$	12V, 70AH, 640A	U 300 AUZ 33Z	0 092 S37 390	
		11.12→	12V, 70Ah, 550A		0 092 \$37 421	
宝威	宝威 2.0 i	04.04-06.11	12V, 60Ah, 475A		0 986 A02 793	
E 1900	±100, 2.01	04.04-00.11	12V, 60Ah, 520A		0 986 A02 607	
	宝威 2.4 i 4WD	04.04-11.10	12V, 60Ah, 475A		0 986 A02 793	
	3. JM, 2.414VID	04.04 11.10	12V, 60Ah, 520A		0 986 A02 607	
	宝威 2.8 D	01 06-08 08	12V, 60Ah, 475A		0 986 A02 793	
	11 M 2.0 B	01.00 00.00	12V, 60Ah, 520A		0 986 A02 607	
	宝威 2.8 D 4WD	04.04-07.08	12V, 60Ah, 475A		0 986 A02 793	
			12V, 60Ah, 520A		0 986 A02 607	
		04.04→	12V, 66Ah, 550A		0 986 A02 819	
顶达	顺达 2.8 D	09.07→	12V, 36Ah, 180A	0 092 S37 381		
		05.10→	12V, 36Ah, 310A 12V, 70Ah, 600A		0 986 A02 781 0 986 A02 798	
		00.10	121, 10/11, 000/1			
凯马						
し马	凯马 1.8 D	05.02→	12V, 70Ah, 640A	0 986 A02 332		
	凯马 2.0 D	09.02-10.07	12V, 70Ah, 640A	0 986 A02 332		
	凯马 2.2 D	09.02→	12V, 70Ah, 640A	0 986 A02 332		
	凯马 2.5 D	06.02→	12V, 70Ah, 640A	0 986 A02 332		
	凯马 2.6 D	04.08→	12V, 70Ah, 640A	0 986 A02 332		
	凯马 2.7 D	06.06-06.11	12V, 70Ah, 640A	0 986 A02 332		
	凯马 3.0 D	06.05-07.09	12V, 70Ah, 640A	0 986 A02 332		
	凯马 3.1 D	06.05-07.09	12V, 70Ah, 640A	0 986 A02 332		
	凯马 3.2 D	11.06→	12V, 70Ah, 640A	0 986 A02 332		
	凯马 3.3 D	07.02→	12V, 70Ah, 640A	0 986 A02 332		
	凯马 3.4 D	12.06-05.08	12V, 70Ah, 640A	0 986 A02 332		
	凯马 3.7 D	03.08→	12V, 70Ah, 640A	0 986 A02 332		
	凯马 3.8 D	06.05-12.08	12V, 70Ah, 640A	0 986 A02 332		
	凯马 3.9 D 凯马 4.1 D	05.02→ 09.04→	12V, 70Ah, 640A 12V, 70Ah, 640A	0 986 A02 332		
	ஏi → 4.1 U	03.04→	124, 1 UAII, 64UA	0 986 A02 332		
开瑞						
	优优 1.0 i	06.09→	12V, 45Ah, 225A	0 092 S37 385		
-0 JU	优优 1.01 优优 1.1 i	06.09→	12V, 45Ah, 325A	0 032 337 303	0 986 A02 785	
	<u>ルルココー</u> 优优 1.2 i	06.09→	12V, 45Ah, 325A		0 986 A02 785	
	N N 1.21	00.03	12V, 45An, 325A 12V, 48Ah, 450A		0 092 S47 185	
大胜	优胜 1.0 i	11.09→	12V, 45Ah, 325A		0 986 A02 785	
TL, ULL	ντ/ΙΣ 1.U I	11.03-7	12V, 45An, 325A 12V, 48Ah, 450A		0 986 A02 785 0 092 S47 185	
	优胜 1.1 i	11.09→	12V, 48An, 450A 12V, 45Ah, 325A		0 986 A02 785	
た雅	<u> </u>	01.08-02.14	12V, 45AH, 525A 12V, 60Ah, 580A		0 986 A02 785	
O.VIE	优雅 1.21 优雅 1.3 i	04.06-06.14	12V, 45Ah, 325A		0 986 A02 785	
	优雅 1.5 i	12.07-11.10	12V, 45AH, 525A 12V, 60Ah, 580A		0 986 A02 827	
	ARAG T10 I		, 50/111, 000/1			



















Ş		面	参数	S3 动能	S4 动力神	S5 银侠
起亚						
2	K2 1.4 i	04.11→	12V, 45Ah, 325A		0 986 A02 786	
2	NZ 1.41	04.11	12V, 48Ah, 450A		0 092 S47 184	
		07.11→	12V, 45Ah, 400A		0 986 A02 600	
	K2 1.6 i	04.11→	12V, 45Ah, 325A 12V, 48Ah, 450A		0 986 A02 786 0 092 S47 184	
3	K3 1.6 i	08.12→	12V, 40Ah, 400A		0 986 A02 789	
_			12V, 60Ah, 530A		0 092 S47 186	
5	K5 2.0 i	03.11→	12V, 60Ah, 580A		0 092 S47 193 0 986 A02 827	
千里马	千里马 1.3 i	08.03-10.08	12V, 60Ah, 400A		0 986 A02 789	
			12V, 60Ah, 450A		0 092 S47 101	
			12V, 60Ah, 520A 12V, 60Ah, 530A	0 092 S37 380	0 092 S47 186	
	千里马 1.6 i	08.03-10.08	12V, 55Ah, 500A	0 092 S37 393		
秀尔	秀尔 1.6 i	12.09→	12V, 45Ah, 325A		0 986 A02 786	
	远舰 1.8 i	11.04-04.13	12V, 48Ah, 450A 12V, 60Ah, 400A		0 092 S47 184 0 986 A02 789	
			12V, 60Ah, 450A		0 092 S47 101	
			12V, 60Ah, 520A	0 092 S37 380	0.000 647 106	
		06.04-06.11	12V, 60Ah, 530A 12V, 60Ah, 400A		0 092 S47 186 0 986 A02 789	
			12V, 60Ah, 450A		0 092 S47 101	
			12V, 60Ah, 520A	0 092 S37 380	0.000.047.400	
≅兰托 [JC]	索兰托 2.4 i	03.03-04.06	12V, 60Ah, 530A 12V, 65Ah, 370		0 092 S47 186 0 092 S47 106	
冒跑	狮跑 2.7 i 4x4	09.04-04.07	12V, 65Ah, 370		0 092 S47 106	
	智跑 2.0 i	$07.10 \rightarrow 07.10$	12V, 60Ah, 490A		0 986 A02 602	
		08.10-02.13 $07.11 \rightarrow$	12V, 65Ah, 490A 12V, 60Ah, 400A		0 986 A02 791 0 986 A02 789	
		07.11	12V, 60Ah, 530A		0 092 S47 186	
总欧 [JB, DE]	锐欧 1.4 i	01.07-09.11	12V, 45Ah, 325A	0.000.007.000	0 986 A02 786	
塞拉图 [FE]	赛拉图 1.6 i	07.05-11.09	12V, 45Ah, 350A 12V, 60Ah, 450A	0 092 S37 386	0 092 S47 101	
量瑞迪	福瑞迪 1.6 i	05.09→	12V, 60Ah, 490A		0 986 A02 602	
喜华∥	嘉华∥2.7i	10.05-10.10	12V, 60Ah, 400A		0 986 A02 789	
			12V, 60Ah, 450A 12V, 60Ah, 520A	0 092 S37 380	0 092 S47 101	
	嘉华 II 3.5 i	09.03-06.08	12V, 60Ah, 400A	0 002 001 000	0 986 A02 789	
			12V, 60Ah, 450A		0 092 S47 101	
寒拉图	赛拉图 1.6 i	07.07-04.13	12V, 60Ah, 520A 12V, 60Ah, 450A	0 092 S37 380	0 092 S47 101	
4.1 4.14	赛拉图 1.8 i	01.04-11.13	12V, 60Ah, 400A		0 986 A02 789	
			12V, 60Ah, 450A		0 092 S47 101	
			12V, 60Ah, 520A 12V, 60Ah, 530A	0 092 S37 380	0 092 S47 186	
金龙						
金龙	金龙 3.3 D	03.03-03.05	12V, 70Ah, 640A	0 986 A02 332		
	金龙 3.4 D	08.03-09.08	12V, 70Ah, 640A	0 986 A02 332		
路虎汽车集团						
 支现者Ⅲ[TAA]	发现者Ⅲ4.0 AWD	09.04-08.09	12V, 100Ah, 830A			0 092 S50 13
	发现者 III 4.4 AWD	09.04-08.09	12V, 100Ah, 830A			0 092 \$50 13
战现者 Ⅳ [LA]	发现者 IV 2.7 TDV6 AWD	09.09-08.10	12V, 100Ah, 830A			0 092 S50 13
	发现者 IV 3.0 TDV6 AWD	09.09-08.10	12V, 100Ah, 830A			0 092 S50 13
	发现者 Ⅳ 5.0 V8 AWD	09.09→	12V, 100Ah, 830A			0 092 S50 13
申行者 2 [LF]	神行者 2 i6 AWD	10.06-11.12	12V, 74Ah, 680A			0 986 A02 33
	神行者 2 SD4 AWD	09.10-11.14	12V, 77Ah, 790A 12V, 77Ah, 790A			0 092 S57 06 0 092 S57 06
	神行者 2 TD4 AWD	10.06-11.14	12V, 74Ah, 680A			0 986 A02 33
K SA- 111 F1 B 47	11/5 RM 11/5 O V O V V V V	00.00.01.10	12V, 77Ah, 790A			0 092 \$57 06
も胜 III [LM] も胜 III [LM L322]	揽胜Ⅲ5.0 V8 AWD 揽胜Ⅲ3.6 TDV8 AWD	09.09-01.13 09.09-01.13	12V, 100Ah, 830A 12V, 110Ah, 850A			0 092 S50 13 0 986 A02 34
[揽胜Ⅲ4.2 AWD	03.05-08.09	12V, 110Ah, 850A			0 986 A02 34
	揽胜Ⅲ4.4 V8 AWD	05.05-08.09	12V, 100Ah, 830A			0 092 \$50 13
览胜运动版 [LS L320]	揽胜运动版 3.0 SD	06.11-08.13	12V, 110Ah, 850A 12V, 100Ah, 830A			0 986 A02 34 0 092 S50 13
- W [LO LOZO]	AWD					
	揽胜运动版 3.6 TD AWD	01.07-08.09	12V, 110Ah, 850A			0 986 A02 34
	揽胜运动版 4.4 AWD 揽胜运动版 5.0 SC	03.05-08.09 09.09-08.13	12V, 110Ah, 850A 12V, 110Ah, 850A			0 986 A02 34 0 986 A02 34
	AWD					
				—	—	—
				·	D BOSCH	B BOSCH
				0		

五十铃 ・ 依维柯 ・ JAC ・ 捷豹 ・ 吉普 ・ 江南 ・ 金杯 ・ JMC ・ 凯马 ・ 开瑞 ・ 起亚 ・ 金龙 ・ 路虎汽车集团









(a) BOSCH



a

参数







S5

银侠



S4 动力神

S3 动能



陆风						
X5	X5 2.0 i	11.12→	12V, 70Ah, 550A		0 092 S37 420	
X6	X6 2.0 i	11.06→	12V, 70Ah, 570A	0 092 S37 399		
	X6 2.4 i	02.02.06.11	12V, 70Ah, 650A 12V, 70Ah, 570A	0 092 S37 399	0 986 A02 618	
	λ0 2.41	02.03-00.11	12V, 70Ah, 650A	0 092 337 399	0 986 A02 618	
	X6 2.5 D	01.08-01.12	12V, 66Ah, 550A		0 986 A02 819	
	X6 2.8 D	08.03-11.06	12V, 70Ah, 570A 12V, 70Ah, 650A	0 092 S37 399	0 986 A02 618	
		12.06-06.13			0 986 A02 819	
X8	X8 2.0 i	04.11→	12V, 70Ah, 600A		0 986 A02 797	
	X8 2.4 i X8 2.5 D	06.09→ 04.09→	12V, 70Ah, 600A 12V, 70Ah, 600A		0 986 A02 797 0 986 A02 797	
风尚	风尚 1.6 i		12V, 76Ah, 660A		0 986 A02 819	
	风尚 2.0 i	10.05-06.08	12V, 66Ah, 550A		0 986 A02 819	
雷克萨斯(凌	[志)					
ES	ES 240 2.4 i	01.13→	12V, 60Ah, 400A		0 986 A02 789	
	ES 350 3.5 i	03.06-09.12	12V, 60Ah, 530A 12V, 77Ah, 790A		0 092 S47 186	0 092 S57 06
GS	GS 350 3.5	08.05-01.12			0 092 S37 420	0 0 3 2 3 3 7 0 0
GS [S1]	GS 300 3.0	01.05-12.11	12V, 70Ah, 550A		0 092 S37 420	
	00 420 4 2	01.05.00.00	12V, 70Ah, 600A		0.006 400 700	0 986 A02 79
IS [E1]	GS 430 4.3 IS 200 2.0 i	01.05-09.08 01.99-07.05	12V, 70Ah, 600A 12V, 60Ah, 400A		0 986 A02 798 0 986 A02 790	
			12V, 75Ah, 650A			0 986 A02 23
LS [F3]	LS 430 4.3 i	08.00-08.06			0 986 A02 815	0.000.057.00
LS [F4]	LS 600hL 5.0 i 4x4	05.07→	12V, 93Ah, 680A 12V, 80Ah, 622A		0 986 A02 815	0 092 S57 02
LX [J1]	LX 470 4.7 4x4	01.98-08.07	12V, 70Ah, 550A		0 092 S37 420	
	IVE70 F 7 AUE	11.07	12V, 70Ah, 600A		0.000.007.100	0 986 A02 79
LX [J2]	LX 570 5.7 4WD	11.07→	12V, 70Ah, 550A 12V, 70Ah, 600A		0 092 S37 420	0 986 A02 79
RX [U3]	RX 300 3.0 i 4x4	02.03-01.06			0 986 A02 797	0 000 A02 13
	RX 400h 3.3 4x4	03.05-12.08				0 092 S57 02
力帆						
320	320 1.3 i	06.08→	12V, 60Ah, 580A		0 092 S47 193	
520	520 1.3 i	01.06.06.09	12V 60Ab 520A		0 986 A02 827 0 092 S47 186	
520	520 1.51	$\frac{01.06\text{-}06.08}{01.06\text{-}07.14}$			0 986 A02 789	
			12V, 60Ah, 450A		0 092 S47 101	
		OF 12 OF 14	12V, 60Ah, 520A	0 092 S37 380	0.000 400 007	
	520 1.6 i	05.12-05.14 01.06-04.10	12V, 60Ah, 580A 12V, 60Ah, 400A		0 986 A02 827 0 986 A02 789	
	020 1.01	01.00 04.10	12V, 60Ah, 450A		0 092 S47 101	
	00045	00.00	12V, 60Ah, 520A	0 092 S37 380	0.000 400 700	
620	620 1.5 i	09.09→	12V, 60Ah, 400A 12V, 60Ah, 450A		0 986 A02 789 0 092 S47 101	
			12V, 60Ah, 520A	0 092 S37 380	0 0 3 2 3 4 7 1 0 1	
			12V, 60Ah, 530A		0 092 S47 186	
	620 1.6 i	$\frac{11.07-07.14}{11.07\rightarrow}$	12V, 60Ah, 530A 12V, 60Ah, 400A		0 092 S47 186 0 986 A02 789	
		11.07→	12V, 60Ah, 450A		0 092 S47 101	
			12V, 60Ah, 520A	0 092 S37 380		
X60	X60 1.8 i	10.10→	12V, 70Ah, 550A		0 092 \$37 421	
丰顺	丰顺 1.0 i	06.10→	12V, 60Ah, 580A		0 092 S47 193 0 986 A02 827	
	丰顺 1.3 i	09.09→	12V, 60Ah, 580A		0 092 S47 193	
					0 986 A02 827	
凌宇						
凌宇	凌宇 2.7		12V, 70Ah, 640A	0 986 A02 332		
	凌宇 2.7D 凌宇 2.7 D	01.08→ 07.07→	12V, 70Ah, 640A 12V, 70Ah, 640A	0 986 A02 332 0 986 A02 332		
	<u>凌于 2.7 D</u> 凌宇 3.4 D		12V, 70Ah, 640A	0 986 A02 332		
	凌宇 3.7	03.10-01.12	12V, 70Ah, 640A	0 986 A02 332		
	凌宇 3.7 D	04.07-06.08	12V, 70Ah, 640A	0 986 A02 332		
柳州						
菱通	菱通 2.0 i	06.03-07.08	12V, 100Ah, 512A	0 986 A02 732		
			12V, 100Ah, 680A 12V, 100Ah, 700A	0 092 S37 407	0 986 A02 805	
纳智捷						
U6	U6 1.8 i SUV	01.14→	12V, 60Ah, 580A		0 092 S47 193	
幼 纳智捷		05.11-01.14	12V, 65Ah, 580A		0 986 A02 827 0 986 A02 609	
纳智捷 7 [SUV]	纳智捷 大 7 SUV 2.2 T	08.12→	12V, 70Ah, 500A		0 986 A02 796	



















参数

S3 动能

S4 动力神

S5 银侠

MASERATI						
GranTurismo	GranTurismo 运动版 4.7	05.12→	12V, 74Ah, 680A			0 986 A02 33
总裁 [M139]	总裁 4.2 V8 32V	03.04-12.12	12V, 100Ah, 760A			0 986 A02 33
总裁 [M156]	总裁 GT S 3.8	11.12→	12V, 100Ah, 830A 12V, 74Ah, 680A			0 092 S50 13 0 986 A02 33
コムナ						
马自达						
323 [BJ]	323 1.6 i	07.98-10.00	12V, 65Ah, 465A 12V, 75Ah, 650A		0 092 S47 102	0 986 A02 23
CX-5 MX-5 [NC]	CX-5 2.0 i MX-5 2.0	04.13→ 07.05-03.15	12V, 60Ah, 490A 12V, 65Ah, 490A	0 986 A01 125	0 986 A02 602	
wx-5 [NC] 马自达 2	MX-5 2.0 马自达 2 1.3 i	10.07→	12V, 65AH, 490A 12V, 60AH, 400A	U 966 AUI 125	0 986 A02 789	
71~2	7,4,221.01	10.01	12V, 60Ah, 450A		0 092 S47 101	
			12V, 60Ah, 520A	0 092 S37 380		
	马自达 2 1.5 i	01.08→	12V, 60Ah, 530A 12V, 55Ah, 500A		0 092 S47 186 0 092 S37 393	
	马口是 2 1.51	01.00	12V, 60Ah, 400A		0 986 A02 789	
			12V, 60Ah, 450A		0 092 S47 101	
			12V, 60Ah, 520A 12V, 60Ah, 530A	0 092 S37 380	0 092 S47 186	
马自达 3	马自达 31.6i	06.07→	12V, 60Ah, 400A		0 986 A02 789	
			12V, 60Ah, 450A		0 092 S47 101	
			12V, 60Ah, 520A 12V, 60Ah, 530A	0 092 S37 380	0 092 S47 186	
		10.11→	12V, 55Ah, 450A		0 986 A02 818	
	马自达 3 2.0 i	01.06→	12V, 60Ah, 400A		0 986 A02 789	
			12V, 60Ah, 450A	0.000.007.000	0 092 S47 101	
			12V, 60Ah, 520A 12V, 60Ah, 530A	0 092 S37 380	0 092 S47 186	
	马自达3昂克赛拉	01.14→	12V, 55Ah, 450A		0 986 A02 818	
7 白汁 F four	1.5 i	00.40	101/ 6545 4004	0.006.404.405		
马自达 5 [CW] 马自达 6	马自达 5 2.0 马自达 6 2.0 i	09.10→ 08.02→	12V, 65Ah, 490A 12V, 68Ah, 650A	0 986 A01 125	0 986 A02 610	
	马自达 6 2.3 i	09.03-03.09	12V, 68Ah, 650A		0 986 A02 610	
		12.05-04.08	12V, 70Ah, 550A	0 092 S37 420		
	马自达 6 睿翼 2.0 i	10.08→	12V, 70Ah, 600A 12V, 70Ah, 600A		0 986 A02 797 0 986 A02 797	
	马自达 6 睿翼 2.5 i	10.00 →	12V, 70Ah, 550A	0 092 S37 420	0 300 A02 131	
			12V, 70Ah, 600A		0 986 A02 797	
梅赛德斯 - 奔驰	也					
3 级 [245]	B 200	04.05-04.11	12V, 85Ah, 760A			0 986 A02 33
			12V, 88Ah, 600A		0 986 A02 823	
C-Klasse [203] Sportcoupe	C 200 KOMPRESSOR Sportcoupe	01.01-08.02	12V, 74Ah, 680A 12V, 85Ah, 760A			0 986 A02 33 0 986 A02 33
sportcoupe	Sportcoupe		12V, 88Ah, 600A		0 986 A02 823	0 900 AUZ 33
CLK-Klasse [209]	CLK 240 Cabrio	02.03-03.05	12V, 74Ah, 680A			0 986 A02 33
Cabrio CLK 级 [209] 轿跑	CLK 240 轿跑	05.02-03.05	12V, 100Ah, 800A 12V, 74Ah, 680A		0 986 A02 824	0 986 A02 33
)LK 3X [203] 4) LE	CLK 280 轿跑	04.05-04.09	12V, 100Ah, 830A			0 092 S50 13
CLK 级 [209]	CLK 200 敞篷轿跑	10.06-12.09	12V, 74Ah, 680A			0 986 A02 33
敞篷轿跑	CLK 350 敞篷轿跑	04.05-12.09	12V, 85Ah, 760A 12V, 88Ah, 600A		0 986 A02 823	0 986 A02 33
			12V, 100Ah, 830A		U 900 AUZ 023	0 092 S50 13
CLS 级 [219]	CLS 63 AMG 轿跑	04.06-02.11	12V, 85Ah, 760A			0 986 A02 33
	010 500 括购	00 04 04 00	12V, 88Ah, 600A		0 986 A02 823	0.000 400 22
	CLS 500 轿跑	06.04-04.06	12V, 85Ah, 760A 12V, 88Ah, 600A		0 986 A02 823	0 986 A02 33
3级	C 180K 1.6	03.10-09.12	12V, 85Ah, 760A			0 986 A02 33
	C 200 1.8 i		12V, 85Ah, 760A			0 986 A02 33
	C 200K 1.8 i	03.10-09.12	12V, 80Ah, 720A 12V, 72Ah, 700A		0 986 A02 822	0 986 A02 34
	C 230 2.5 T		12V, 80Ah, 720A		0 986 A02 341	
	C 260 1.8 i	03.10-06.14	12V, 85Ah, 760A		0.000 100	0 986 A02 33
C级 [203]	C 280 3.0 i C 240 4MATIC	08.07-11.10 09.02-06.05	12V, 80Ah, 720A 12V, 74Ah, 680A		0 986 A02 341	0 986 A02 33
[200]	J 270 TWATIO	00.02 00.00	12V, 85Ah, 760A			0 986 A02 33
/// Faces	0.000 ((0)	01.01.55	12V, 88Ah, 600A		0 986 A02 823	
C 级 [203] T-Modell	C 200 KOMPRESSOR T-Modell	01.01-08.02	12V, 74Ah, 680A 12V, 85Ah, 760A			0 986 A02 33 0 986 A02 33
	1-MOUGH		12V, 88Ah, 600A		0 986 A02 823	U 300 AUZ 33
2 级 [204]	C 180	07.12→	12V, 85Ah, 760A			0 986 A02 33
	C 200 KOMPRESSOR	03.07-04.10	12V, 74Ah, 680A			0 986 A02 33
			12V, 85Ah, 760A 12V, 88Ah, 600A		0 986 A02 823	0 986 A02 33
	C 230	08.07-08.09	12V, 74Ah, 680A			0 986 A02 33
			12V, 85Ah, 760A		0 986 A02 823	0 986 A02 33
		04.09-12.14	12V, 88Ah, 600A 12V, 85Ah, 760A		U 300 AUZ 823	0 986 A02 33
	C 250 CGI	04.05-12.14	12V, 88Ah, 600A		0 986 A02 823	30
	C 250 CGI	03.07-04.09	12V, 74Ah, 680A			
					0 986 A02 823	
			12V, 74Ah, 680A 12V, 85Ah, 760A	↓ ↓	0 986 A02 823	0 986 A02 33 0 986 A02 33
			12V, 74Ah, 680A 12V, 85Ah, 760A	+	0 986 A02 823	
			12V, 74Ah, 680A 12V, 85Ah, 760A	+	0 986 A02 823	

梅赛德斯 - 奔驰 · 名爵 · 三菱 · 日产 · 欧乐克 · 欧宝 ▶

陆风 ・ 雷克萨斯 ・ 力帆 ・ 凌宇 ・ 柳州 ・ 纳智捷 ・ MASERATI ・ 马自达 ・ 梅赛德斯 - 奔驰 ・ 名爵 ・ 三菱 ・ 日产 ・ 欧乐克 ・ 欧宝

















		面	参数	S3 动能	S4 动力神	S5 银侠
梅赛德斯 - 奔驰(
E-Klasse [211]	E 200 KOMPRESSOR E 240	03.02-03.06 03.02-03.05	12V, 72Ah, 700A 12V, 85Ah, 760A 12V, 88Ah, 600A		0 986 A02 822 0 986 A02 823	0 986 A02 336
E-Klasse [212]	E 250 CGI	04.09-12.13	12V, 100Ah, 760A 12V, 100Ah, 760A			0 986 A02 337 0 986 A02 337
	E 300L	04.09→	12V, 72Ah, 700A		0 986 A02 822	0 900 A02 331
E级	E230 2.5 i	06.07-11.10	12V, 85Ah, 760A 12V, 88Ah, 600A		0 986 A02 823	0 986 A02 336
	E260 1.8 i	03.10→	12V, 72Ah, 700A		0 986 A02 822	
	E280 3.0 i	10.05-11.10	12V, 85Ah, 760A 12V, 88Ah, 600A		0 986 A02 823	0 986 A02 336
	E350 3.5 i	09.06-11.10	12V, 85Ah, 760A			0 986 A02 336
E 级 [124]	E 250 涡轮柴油	07.93-06.95	12V, 88Ah, 600A 12V, 100Ah, 830A		0 986 A02 823	0 092 S50 130
E级[210]T型	E 230 T 型	05.96-08.97	12V, 74Ah, 680A			0 986 A02 334
E 级 [212] GLK 级 [204]	E200 1.8 T GLK 280 4MATIC	03.10-04.14	12V, 80Ah, 720A 12V, 100Ah, 830A			0 986 A02 341 0 092 S50 130
	GLK 300 4MATIC	05.09-12.12	12V, 100Ah, 830A		0.000 400 004	0 092 S50 130
GL 级 [164]	GL 450 4MATIC	07.11→ 02.06-12.12	12V, 100Ah, 800A 12V, 100Ah, 830A		0 986 A02 824	0 092 S50 130
R级[251]	R 350 4MATIC	09.05-10.12	12V, 85Ah, 760A		0.000 400 000	0 986 A02 336
	R 500 4MATIC	05.07-10.12	12V, 88Ah, 600A 12V, 85Ah, 760A		0 986 A02 823	0 986 A02 336
CLV /R [170]	SLK 230 KOMPRESSOR	02.00-03.04	12V, 88Ah, 600A		0 986 A02 823	0.006.400.224
SLK 级 [170]	SLN 230 NOWIFNESSON	02.00-03.04	12V, 74Ah, 680A 12V, 85Ah, 760A			0 986 A02 334 0 986 A02 336
			12V, 88Ah, 600A		0 986 A02 823	
SLK 级 [171]	SLK 200 KOMPRESSOR	12.07-11.10	12V, 100Ah, 800A 12V, 74Ah, 680A		0 986 A02 824	0 986 A02 334
7			12V, 85Ah, 760A 12V, 88Ah, 600A		0 986 A02 823	0 986 A02 336
	SLK 280	05.05-02.09	12V, 74Ah, 680A		0 980 A02 823	0 986 A02 334
			12V, 85Ah, 760A 12V, 88Ah, 600A		0 986 A02 823	0 986 A02 336
	SLK 300	03.09-11.10	12V, 74Ah, 680A		0 900 A02 023	0 986 A02 334
	SLK 350	12.07-02.11	12V, 74Ah, 680A 12V, 85Ah, 760A			0 986 A02 334 0 986 A02 336
			12V, 88Ah, 600A		0 986 A02 823	0 900 A02 330
SL 级 [129]	SL 320	07.93-05.98	12V, 85Ah, 760A 12V, 88Ah, 600A		0 986 A02 823	0 986 A02 336
			12V, 100Ah, 830A		0 300 A02 023	0 092 S50 130
SL 级 [230]	SL 350	03.03-12.05	12V, 85Ah, 760A 12V, 88Ah, 600A		0 986 A02 823	0 986 A02 336
			12V, 100Ah, 800A		0 986 A02 824	
S 级 [220]	S 280 S 320	01.99-08.05 10.98-08.02	12V, 100Ah, 830A 12V, 85Ah, 760A			0 092 S50 130 0 986 A02 336
	3 020	10.50 00.02	12V, 88Ah, 600A		0 986 A02 823	
			12V, 100Ah, 760A 12V, 100Ah, 830A			0 986 A02 337 0 092 S50 130
	S 600	09.02-01.06	12V, 85Ah, 760A			0 986 A02 336
			12V, 88Ah, 600A 12V, 100Ah, 760A		0 986 A02 823	0 986 A02 337
S 级 [221]	S 300	09.05-12.09	12V, 100Ah, 830A			0 092 S50 130
唯雅诺 [639]	S 350 唯雅诺 3.2	09.05-01.11 09.03-12.07	12V, 100Ah, 760A 12V, 100Ah, 830A			0 986 A02 337 0 092 S50 130
	唯雅诺 3.5	09.07-12.14	12V, 100Ah, 830A			0 092 S50 130
名爵						
MG3	MG3 1.3 i	09.10→	12V, 55Ah, 450A		0 986 A02 818	
	MG3 1.5 i	05.10→	12V, 55Ah, 450A		0 986 A02 818	
MG6	MG6 1.8 i	09.09→	12V, 55Ah, 450A		0 986 A02 818	
三菱						
戈蓝	戈蓝 2.0 i	05.09→	12V, 70Ah, 550A	0 092 S37 421		
	戈蓝 Grunder 2.4 i	08.06→	12V, 70Ah, 550A	0 092 S37 421 0 092 S37 421		
劲炫 [GA]	劲炫 1.6	09.12→	12V, 60Ah, 400A 12V, 60Ah, 530A		0 986 A02 789 0 092 S47 186	
	劲炫 2.0	09.12→	12V, 65Ah, 490A		0 986 A02 791	
君阁 帕杰罗	君阁 2.0 i 帕杰罗 2.4 i 运动型	08.08→ 08.03-11.05	12V, 70Ah, 600A 12V, 68Ah, 650A		0 986 A02 797 0 986 A02 611	
HAMP	帕杰罗 3.0 i V6 4WD	08.03→	12V, 68Ah, 650A		0 986 A02 611	
	帕杰罗 3.8 i 4WD	01.05-07.09 $10.06 \rightarrow$	12V, 68Ah, 650A 12V, 94Ah, 760A		0 986 A02 611	0 092 S57 028
欧蓝德	欧蓝德 2.4 i 4WD	10.03-07.07	12V, 65Ah, 465A		0 092 \$47 102	0 002 007 020
			12V, 68Ah, 650A 12V, 70Ah, 600A		0 986 A02 610 0 986 A02 797	
			12V, 75Ah, 650A			0 986 A02 234
欧蓝德 [CU]	欧蓝德 2.4 i 4WD	11.05-09.07	12V, 70Ah, 600A 12V, 75Ah, 630A		0 986 A02 797	0 092 S58 384
						0 092 S58 385
欧蓝德 [CW]	欧蓝德 2.0	09.07-12.12	12V, 75Ah, 650A 12V, 75Ah, 630A			0 986 A02 234 0 092 S58 384
	欧花油204.4					0 092 S58 385
	欧蓝德 3.0 4x4	09.07-12.12	12V, 75Ah, 630A			0 092 S58 384 0 092 S58 385
欧蓝德 [GF]	欧蓝德 2.0	04.12→	12V, 75Ah, 630A			0 092 S58 384
	欧蓝德 3.0 4WD	02.13→	12V, 75Ah, 630A			0 092 S58 385 0 092 S58 384
格蓝迪	格蓝迪 2.4	01.04-11.10	12V, 80Ah, 400A	0 092 S37 391		0 092 S58 385
菱绅	菱绅 2.4 i 旅行轿车	03.04-11.08	12V, 94Ah, 760A 12V, 65Ah, 490A		0 986 A02 791	0 092 S57 028
蓝瑟	蓝瑟 1.6 i	12.95-12.07	12V, 45Ah, 225A		0 092 S37 385	
			12V, 60Ah, 400A 12V, 60Ah, 450A		0 986 A02 789 0 092 S47 101	
			, 55, 150/1			













正常			面	参数	S3 动能	S4 动力神	S5 银侠
197. (2004)、5300	蓝瑟	蓝瑟 1.6 i	12.95-12.07	12V, 60Ah, 520A	0 092 S37 380		
日本				12V, 60Ah, 530A			
置談に16 の 513→ 12 (2004, 4004 000 0986 A02 789 0986 A02			05.00-02.03			0 986 AU2 796	0 986 A02 234
日子 D22				12V, 60Ah, 400A			
□							
D22 2.0	口立						
D22 2.4 11.0 12.0 (SOA) 400A 20.0							
12 (** 60An - 530A 0.002 5 4 7 187 1.00	D22						
80.80 → 127, 60.00 → 127,		5222		12V, 60Ah, 530A		0 092 S47 187	
W2200							
X 등일 [190]			09.05-12.11	12V, 55Ah, 420A			0 986 A02 330
					0.092 \$37 380	0 986 A02 788	
12(12V, 60Ah, 520A			
12 12 7 7 7 8 15 1							
					0 986 A02 796	0 980 A02 604	
		天籁 3.5 i	07.04→		0 092 S37 380	0.000.047.400	
天務 [J32]							
		- Mr			0 986 A02 796		
展度 [A33]	大赖 [J32]						
周度 (A33)				12V, 60Ah, 400A		0 986 A02 789	
用光 (13)	☑ 度 [433]	図度30V6 2/IV	07.01→			0 092 S47 186	0.092 \$57 024
群逸 特急 1.8 05.12 → 12V, 58Ah, 510A							0 032 331 024
対象						0 986 A02 608	0.000 057.004
野地 2-0 05.06-03.13 12V, 70Ah, 550A 12V, 70Ah, 550A 12V, 70Ah, 500A 12V, 70Ah, 50AA 1						0 092 S47 193	0 092 557 024
円球			05.00.00.40			0 986 A02 827	
弱地 [12] 弱地 1.5 4WD 08.05.07.10 12.9.36Ah, 310A 12.9.36Ah, 310A 12.9.36Ah, 310A 0.986 A02 782 12.9.56Ah, 390A 0.986 A02 791 3.9.2.51 0.6.08→ 12.9.56Ah, 390A 0.986 A02 603 3.9.2.51 0.6.08→ 12.9.56Ah, 390A 0.986 A02 603 3.9.2.51 0.6.08→ 12.9.56Ah, 490A 0.986 A02 603 3.9.2.51 0.6.08→ 12.9.45Ah, 325A 0.986 A02 603 3.9.2.51 0.1.08→ 12.9.45Ah, 325A 0.986 A02 788 0.992 547 102 0.986 A02 788 0.992 547 182		针选 2.01	05.06-03.13		0 092 \$37 421	0 986 A02 798	
奇装 [731]	玛驰 [K12]	玛驰 1.5 i 4WD	08.05-07.10	12V, 36Ah, 310A		0 986 A02 782	
新設 2.5 i	奇骏 [T31]		06.08→				
機技丁3.31 AWD 05.03-10.08 12V, 60Ah, 990A 0928 AD 2603		奇骏 2.5 i	06.08→	12V, 65Ah, 520A		0 092 S37 419	
無主[V42]	帕拉丁 [WD22]						
通客 2.0 i			05.03-08.11				
接換	逍客 +2 [JJ10]						
12V, 70Ah, 550A 1092 \$37 421		担告 2.01	01.06-7				
接達 [10] 接池 1.8i 09.06-11.13 12V, 70Ah, 50OA 0986 A02 788 現法 [C11] 雅青年 現法 1.6i 06.05→ 12V, 36Ah, 31OA 0985 A02 781	骊威 [L10]	骊威 1.6 i	02.07-07.14	12V, 70Ah, 500A			
関达 [C11] 操背车					0 092 537 421	0 986 A02 798	
12V, 40Ah, 340A 12V, 45Ah, 325A 0 986 A02 818 12V, 45Ah, 350A 0 986 A02 334 181 1 0 986 A02 334 181 1 0 986 A02 334 181 1 0 986 A02 334 1 0 986 A02 318 1 0 986 A02							
世界	骐还 [C11] 掀背牛	骐 达 1.6 ι	06.05→				
(税頭 2.51				12V, 45Ah, 325A		0 986 A02 788	
模U 2.4 i 08.10→ 12V, 80Ah, 622A			03 11→			0 092 S47 182	0.092 \$57 024
機類 3.0 D 08.09 → 12V, 80Ah, 620A 12V, 93Ah, 680A 0986 A02 814 0092 \$57 027 12V, 93Ah, 680A 0986 A02 618 12V, 85Ah, 580A 0986 A02 618 12V, 45Ah, 325A 12V, 48Ah, 450A 0986 A02 788 12V, 48Ah, 450A 0992 \$47 182 12V, 48Ah, 480A 12V, 77Ah, 790A 0992 \$57 060 0986 A02 334 12V, 77Ah, 790A 0992 \$57 060 0986 A02 334 12V, 77Ah, 790A 0992 \$57 060 0986 A02 334 12V, 77Ah, 790A 0986 A02 334 12V, 60Ah, 540A 0986 A02 818 0986 A02 818 12V, 60Ah, 540A 0992 \$47 040 12V, 60Ah, 540A 0992 \$40 040	锐骐		08.10→	12V, 80Ah, 622A			0 002 001 024
12V, 93Ah, 680A 0986 A02 612 0992 \$57 027 12V, 80Ah, 680A 0986 A02 612 12V, 65Ah, 580A 0986 A02 608 12V, 45Ah, 325A 12V, 45Ah, 325A 12V, 45Ah, 350A 12							
蓝鸟 [G10] 蓝鸟 2.0 i 12.03-06.08 12V, 45Ah, 325A 12V, 45Ah, 325A 12V, 45Ah, 325A 12V, 45Ah, 325A 12V, 45Ah, 350A 12V, 45Ah, 450A 12V, 45		5.0 D	00.03	, , .		0 300 A02 014	0 092 S57 027
爾达 [C11] 「陳达 1.6 i	蓝内 [010]						
欧乐克 福仕达 1.0i 12.09-09.14 12V, 45Ah, 350A 0992 \$37 383 00							
福仕达 1.0 i 12.09-09.14 12V, 45Ah, 350A 福仕达 1.1 i 04.08-03.14 12V, 45Ah, 350A 0092 \$37 383 0092 \$				12V, 48Ah, 450A		0 092 S47 182	
福仕达 1.1 i	欧乐克						
欧宝 威达 [C]	福仕达						
威达 [C]		福仕达 1.1 i	04.08-03.14	12V, 45Ah, 350A	0 092 S37 383		
12V, 77Ah, 790A 0 092 \$57 060 0 986 A02 334 12V, 77Ah, 790A 0 092 \$57 060 0 986 A02 334 12V, 77Ah, 790A 0 092 \$57 060 0 986 A02 334 12V, 55Ah, 450A 12V, 60Ah, 540A 12V, 60Ah, 540A 0 092 \$40 040 12V, 60Ah, 540A 12V, 60Ah, 540A 12V, 60Ah, 540A 0 092 \$40 040 12V, 60Ah, 540A 12V, 6	欧宝						
威达 3.2 i 08.02-09.05 12V, 74Ah, 680A 12V, 77Ah, 790A 0 092 S57 060 0 986 A02 334 12V, 55Ah, 450A 12V, 60Ah, 540A 0 092 S40 040 0 092 S40 040 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0	威达 [C]	威达 2.2 i	09.01-09.05				0 986 A02 334
雅特 [G] 雅特 1.8 i 09.00-01.04 12V, 55Ah, 450A 12V, 60Ah, 540A 0992 \$40 040		威达 3 2 i	08 02-00 0E			0 092 S57 060	0 986 402 224
12V, 60Ah, 540A 0 092 \$40 040		<i>既</i> 及 3.2 I	00.02-09.00			0 092 S57 060	0 900 AUZ 334
W-/ BUSCH	雅特 [G]	雅特 1.8 i	09.00-01.04				
W-/ BUSCH				, , , , , , ,			
W-/ BUSCH							
W BOSCH							
W BOSCH							
W-/ BUSCH							
W-/ BUSCH					<u></u>		+
W BOSCH					*	I in a south	Boscu
					BOSCH	BOSCH 4	00000

陆风 ・ 雷克萨斯 ・ 力帆 ・ 凌宇 ・ 柳州 ・ 纳智捷 ・ MASERATI ・ 马自达 ・ 梅赛德斯 - 奔驰 ・ 名爵 ・ 三菱 ・ 日产 ・ 欧乐克 ・ 欧宝











a

参数

S3 动能

S4 动力神







S5

银侠



				初日	4J JJ 14	TIXIX
标致						
小以						
206	206 1.4 i	04.06-12.08	12V, 60Ah, 580A		0 092 S47 193 0 986 A02 827	
	206 1.6 i	08.06-11.09			0 986 A02 827	
206 [T1] CC 207	206 CC 1.6 i 16V 207 1.4 i	09.00-03.07 09.08→	12V, 60Ah, 580A 12V, 62Ah, 480A		0 986 A02 827	0 986 A02 331
	207 1.6 i	01.05-05.14	12V, 62Ah, 480A			0 986 A02 331
301 [M3]	301 1.6 i	05.13→	12V, 60Ah, 580A		0 092 S47 193 0 986 A02 827	
307	307 1.6 i	01.03→	12V, 60Ah, 580A		0 092 \$47 193	
	307 2.0 i	03.04-06.14	12V, 60Ah, 580A		0 986 A02 827 0 986 A02 617	
	307 2.0 i 16V	12.05-06.14	12V, 60Ah, 580A		0 092 S47 193 0 986 A02 617	
					0 986 A02 827	
307 [T5] 308 [T7]	307 2.0 i 308 1.6 i	08.00-05.05 06.11→	12V, 60Ah, 580A 12V, 60Ah, 580A		0 986 A02 827 0 092 S47 193	
500[]					0 986 A02 827	
308 [T9]	308 2.0 i 308 1.6 i	06.11→ 10.12→	12V, 60Ah, 580A 12V, 60Ah, 580A		0 986 A02 827 0 092 S47 193	
			, ,		0 986 A02 827	
408	408 1.6 i	12.09→	12V, 60Ah, 580A		0 092 S47 193 0 986 A02 827	
	408 2.0 i	12.09→	12V, 60Ah, 580A		0 092 \$47 193	
508 [W2]	508 2.0 i	01.11→	12V, 60Ah, 580A		0 986 A02 827 0 092 S47 193	
	508 2.3 i	01.11	10V COAL EROA		0 986 A02 827	
		01.11→	12V, 60Ah, 580A		0 092 S47 193 0 986 A02 827	
607 [Z8]	607 3.0 i	03.00-11.04	12V, 70Ah, 570A 12V, 74Ah, 680A	0 092 S37 399		0 986 A02 334
			12V, 77Ah, 790A			0 092 S57 060
2008 [A94] 3008 [T8]	2008 1.6 i 3008 1.6	12.13→ 08.12→	12V, 60Ah, 580A 12V, 60Ah, 580A		0 986 A02 617 0 092 S47 193	
0000[10]					0 986 A02 827	
	3008 2.0 i	08.12→	12V, 60Ah, 580A		0 092 S47 193 0 986 A02 827	
RCZ [T75]	RCZ 1.6 THP	01.10→	12V, 74Ah, 680A			0 986 A02 334
中顺						
	W 47 a a c	10.05	101/ 051/ 070			
世纪	世纪 2.2 i	12.05→	12V, 65Ah, 370 12V, 70Ah, 500A		0 092 S47 106 0 986 A02 795	
保时捷						
上宮 [ODA]	上京20	00 00 00 10	12V 110Ab 950A			0.006.402.240
卡宴 [9PA]	卡宴 3.0 卡宴 3.2		12V, 110Ah, 850A 12V, 110Ah, 850A			0 986 A02 340 0 986 A02 340
	卡宴 3.6	02.07-08.10	12V, 100Ah, 760A 12V, 110Ah, 850A			0 986 A02 337 0 986 A02 340
	卡宴 4.5 S	09.02-01.07	12V, 100Ah, 760A			0 986 A02 337
	卡宴 4.5 T	09.02-01.07	12V, 110Ah, 850A 12V, 110Ah, 850A			0 986 A02 340 0 986 A02 340
	卡宴 4.8 GTS	08.07-08.10	12V, 110Ah, 850A			0 986 A02 340
	卡宴 4.8 S	02.07-08.10	12V, 100Ah, 760A 12V, 110Ah, 850A			0 986 A02 337 0 986 A02 340
卡曼 [987C]	卡曼 2.7		12V, 88Ah, 600A		0 986 A02 823	
博克斯特 [986]	卡曼 2.9 博克斯特 2.7	02.09-12.12 09.02-08.04	12V, 88Ah, 600A 12V, 88Ah, 600A		0 986 A02 823 0 986 A02 823	
			, ,			
启辰						
D50 R50	D50 1.6 i R50 1.6 i	01.12→ 07.12→	12V, 45Ah, 325A 12V, 45Ah, 325A		0 986 A02 788 0 986 A02 788	
		J.122 /			1107101100	
庆铃						
五十铃	五十铃 3.0 D	09.03→	12V, 135Ah, 520A		0 092 S37 411	
威麟						
V5	V5 1.8 i	07.07-12.13	12V, 70Ah, 500A		0 986 A02 796	
雷诺						
风景 II [JM]	风景Ⅱ2.016V	05.03-04.09	12V, 55Ah, 420A 12V, 55Ah, 450A		0 986 A02 818	0 986 A02 330
梅甘娜Ⅱ	梅甘娜Ⅱ2.0	09.02-10.09	12V, 60Ah, 540A 12V, 55Ah, 450A 12V, 60Ah, 540A		0 092 S40 040 0 986 A02 818 0 092 S40 040	
-1. 444			12 V, OUAII, 340A		0 032 340 040	
瑞麟						
M1 [S18]	M1 1.0 i	02.09-06.12	12V, 45Ah, 325A 12V, 48Ah, 450A		0 986 A02 786 0 092 S47 184	
X1	M1 1.3 i X1 1.3 i		12V, 45Ah, 325A		0 986 A02 786 0 986 A02 786	
VI			12V, 45Ah, 325A 12V, 48Ah, 450A		0 092 S47 184	
	X1 1.5 i	08.10→	12V, 45Ah, 325A		0 986 A02 786	

















荣威						
250	0504.5	00.10	101/ 0041 5004		0.000.400.047	
350 550 (DVVT)	350 1.5 i 550 1.8 i DVVT	03.10→ 06.08→	12V, 60Ah, 580A 12V, 60Ah, 580A		0 986 A02 617 0 986 A02 617	
550 (T)	550 1.8 T	10.07→	12V, 60Ah, 580A		0 092 S47 193	
750	750 1.8 T	11.06→	12V, 65Ah, 550A		0 986 A02 827 0 986 A02 604	
750	750 1.6 1	11.00	12V, 66Ah, 500A		0 986 A02 821	
	750 2.5 i	11.06→	12V, 72Ah, 700A		0 986 A02 822	
N5	W5 1.8 i 4x4	05.10→	12V, 70Ah, 600A	0.000.007.004	0 986 A02 798	
赛 宝	赛宝 1.6 i	08.03-01.05	12V, 45Ah, 350A	0 092 S37 384		
劳斯莱斯						
幻影 [RR1]	幻影 6.8	03.03→	12V, 100Ah, 760A 12V, 100Ah, 830A			0 986 A02 33 0 092 S50 13
幻影 [RR2] Drophead	幻影 6.8 Drophead	06.07→	12V, 100Ah, 830A			0 092 S50 13
幻影 [RR3] 轿跑	幻影 6.8 轿跑	09.08→	12V, 100Ah, 830A			0 092 S50 13
古思特 [RR4]	古思特 6.6 古思特 6.6 V 规格	12.09→ 01.14-06.14	12V, 100Ah, 830A 12V, 100Ah, 830A			0 092 S50 13 0 092 S50 13
萨博						
9-5 [9600] 9-5 [9600]	9-5 2.3 T 萨博 9-5 2.3		12V, 74Ah, 680A 12V, 74Ah, 680A			0 986 A02 33 0 986 A02 33
客货两用车	Turbo Kombi	03.01 02.10	12V, 77Ah, 790A			0 092 S57 06
双环						
SCEO	SCEO 2.0 i	12.05→	12V, 60Ah, 520A	0 092 S37 380		
			12V, 70Ah, 500A	0 986 A02 796		
	SCEO 2.4 i	11.04-06.11	12V, 80Ah, 400A	0 092 S37 390	0.006.400.642	
			12V, 80Ah, 680A 12V, 94Ah, 760A		0 986 A02 613	0 092 S57 02
		06.08→	12V, 60Ah, 520A	0 092 S37 380		
	SCEO 2.5 D	11.07-12.13	12V, 70Ah, 500A 12V, 60Ah, 520A	0 986 A02 796 0 092 S37 380		
	3CEO 2.5 D	11.07-12.13	12V, 70Ah, 500A	0 986 A02 796		
	SCEO 2.8 D	09.05-07.09	12V, 60Ah, 520A	0 092 S37 380		
G-RV	S-RV 2.0 i	04.04-07.07	12V, 70Ah, 500A 12V, 45Ah, 225A	0 986 A02 796 0 092 S37 385		
rn v	S-RV 2.2 i	12.03-07.07	12V, 45Ah, 225A	0 092 537 385		
	S-RV 2.4 i	07.04-06.07	12V, 45Ah, 225A	0 092 S37 385		
斯柯达						
 昊锐	昊锐 1.8T	04.09→	12V, 72Ah, 700A		0 986 A02 822	
	昊锐 2.0 T	04.09→	12V, 72Ah, 700A		0 986 A02 822	
昊锐 [3T4]	昊锐 1.4 T 昊锐 2.0 TSI	01.10→ 05.10-05.15	12V, 72Ah, 700A 12V, 74Ah, 680A		0 986 A02 822	0.006.402.22
昊锐 [3U4]	美锐 2.0 ISI	02.02-03.08	12V, 74Ah, 680A			0 986 A02 33 0 986 A02 33
明锐	明锐 1.6 i	12.13→	12V, 60Ah, 580A		0 092 S47 193	
明锐 [5E3]	明锐 1.6 i	05.11→	12V, 60Ah, 580A		0 986 A02 827 0 092 S47 193	
,, pp [020]	77 60 1.01	00.11	124, 00/11, 000/1		0 986 A02 827	
20 FO 4 03	明锐 2.0 i		12V, 60Ah, 580A		0 986 A02 827	
明锐 [913]	明锐 1.4 i	01.10-06.14	12V, 60Ah, 580A		0 092 S47 193 0 986 A02 827	
	明锐 1.6 i	01.06-03.13		0 092 S37 393		
	□□ 		12V, 55Ah, 420A			0 986 A02 33
	明锐 1.8 i		12V, 55Ah, 420A 12V, 60Ah, 580A		0 986 A02 827	0 986 A02 33
	明锐 2.0 i	11.06-02.14	12V, 55Ah, 420A			0 986 A02 33
听锐	昕锐 1.4 i	10.12→	12V, 60Ah, 580A		0 092 \$47 193	
	昕锐 1.6 i	10.12→	12V, 60Ah, 580A		0 986 A02 827 0 092 S47 193	
					0 986 A02 827	
野帝 [5L7]	野帝 1.4	09.13→	12V, 60Ah, 580A		0 092 S47 193 0 986 A02 827	
	野帝 1.8 i	08.13→	12V, 60Ah, 580A		0 986 A02 827	
R M	野帝 1.8 TSI 4x4	11.09→	12V, 74Ah, 680A			0 986 A02 33
晶锐	晶锐 1.4 i	09.08-01.13 $08.10 \rightarrow$	12V, 60Ah, 580A 12V, 44Ah, 360A		0 986 A02 617	0 986 A02 32
	晶锐 1.6 i	09.08→	12V, 60Ah, 580A		0 092 \$47 193	0 000 A02 02
					0 986 A02 827	
东南						
/3	V3 1.5 i	08.08→	12V, 60Ah, 490A		0 986 A02 602	
	V3 1.5 i	07.12→	12V, 60Ah, 400A 12V, 60Ah, 530A		0 986 A02 789 0 092 S47 186	
	东南 2.0 i	03.02→	12V, 60Ah, 475A 12V, 60Ah, 550A		0 986 A02 793 0 092 S47 189	
东南		03.01-07.11	12V, 70Ah, 640A	0 986 A02 332		0 092 S57 02
东南	得利卡 2.0 i	03.01-07.11	12V, 93Ah, 680A			0 002 001 02
东南	得利卡 2.0 i		12V, 93Ah, 680A 12V, 120Ah, 638A 12V, 120Ah, 740A	0 986 A02 734 0 092 S37 410		0 002 001 01
V5 东南 得利卡	得利卡 2.0 i		12V, 120Ah, 638A			1
东南	得利卡 2.0 i		12V, 120Ah, 638A		+	V
东南	得利卡 2.0 i		12V, 120Ah, 638A		*	2
东南	得利卡 2.0 i		12V, 120Ah, 638A		₩ BOSCH	(A) BOSCH

东南 ・双龙 ・ 斯巴鲁 ・ 铃木 ・ 通宝 ・ 丰田 ▶
标致 ・ 中顺 ・ 保时捷 ・ 启辰 ・ 庆铃 ・ 威麟 ・ 雷诺 ・ 瑞麟 ・ 荣威 ・ 劳斯莱斯 ・ 萨博 ・
双环 ・ 斯柯达 ・ 东南 ・ 双龙 ・ 斯巴鲁 ・ 铃木 ・ 通宝 ・ 丰田







S3

S4







S5



Ę		41	参数	动能	动力神	银侠
东南(接上页) 得利卡	得利卡 2.4 i	04.00-12.10	12V, 70Ah, 640A	0 986 A02 332		0.000 057 007
菱帅	菱帅 1.3 i	08.03-07.08	12V, 93Ah, 680A 12V, 60Ah, 490A		0 986 A02 602	0 092 S57 027
菱利	菱帅 1.6 i	08.03-07.09	12V, 60Ah, 490A 12V, 60Ah, 400A		0 986 A02 602	
変利	菱利 1.3 i		12V, 60Ah, 450A 12V, 60Ah, 520A	0 092 S37 380	0 986 A02 789 0 092 S47 101	
	菱利 1.6 i	07.05-01.09	12V, 60Ah, 450A 12V, 60Ah, 520A	0 092 S37 431 0 092 S37 406		
富利卡	富利卡 1.9 D		12V, 55Ah, 500A	0 092 S37 393		
	富利卡 2.0 i	11.02-07.08	12V, 60Ah, 290A 12V, 60Ah, 450A	0 092 S37 433	0 092 S47 103	
			12V, 60Ah, 475A	0 032 331 433	0 986 A02 793	
			12V, 60Ah, 520A 12V, 60Ah, 550A	0 092 S37 388	0 092 S47 189	
			12V, 60Ah, 490A		0 986 A02 602	
	富利卡 2.4 i	12.04-06.11 01.02-06.03	12V, 55Ah, 500A 12V, 70Ah, 550A	0 092 S37 393 0 092 S37 420		
	H 113 1 2.41	01.02 00.00	12V, 70Ah, 600A	0 002 001 420	0 986 A02 797	
双龙						
新主席	新主席 3.2 i	09.03-01.08	12V, 100Ah, 760A			0 986 A02 337
雷斯特	雷斯特 3.2 i 4WD	09.02-12.09	12V, 100Ah, 830A 12V, 94Ah, 760A			0 092 S50 130 0 092 S57 029
斯巴鲁						
BRZ [Z10] 力狮 [BL]	BRZ 2.0 力狮 3.0 4WD	01.12→ 07.03-05.09	12V, 66Ah, 550A 12V, 60Ah, 450A		0 986 A02 819 0 092 S47 101	
			12V, 65Ah, 550A		0 986 A02 605	
马也鹏	驰鹏 3.0 4x4	04.06-11.07	12V, 65Ah, 465A 12V, 75Ah, 650A		0 092 S47 102	0 986 A02 234
驰鹏 [W10]	驰鹏 3.6 R	11.07-01.14	12V, 75Ah, 650A			0 986 A02 234
傲虎 [B14] 森林人	傲虎 2.5 森林人 2.0 i 4WD	06.09-04.15 10.10-11.12			0 986 A02 819 0 986 A02 819	
** [05]	*** 05:44	07.00.05.00	12V, 70Ah, 600A		0 986 A02 798	
森林人 [SF]	森林人 2.5 i 4x4	07.98-05.02	12V, 60Ah, 450A 12V, 75Ah, 650A		0 092 S47 101	0 986 A02 234
森林人 [SG]	森林人 2.0 i 4x4 森林人 2.0 i 涡轮增压	06.05-11.07			0 986 A02 819	
森林人 [SJ]	4WD	11.12→	12V, 66Ah, 550A		0 986 A02 819	
翼豹	翼豹 2.5 i 涡轮增压 4WD	02.09-11.11	12V, 66Ah, 550A		0 986 A02 819	
铃木						
天语 SX4	天语 SX4 1.6 i	09.06→	12V, 45Ah, 325A		0 986 A02 788	
			12V, 45Ah, 350A 12V, 58Ah, 510A	0 092 S37 384		0 092 S57 002
		01.12→	12V, 45Ah, 350A		0 092 S37 384	0 0 9 2 3 3 7 0 0 2
	天语 SX4 1.6 i 掀背车	$12.06-06.09$ $12.06 \rightarrow$	12V, 45Ah, 350A 12V, 45Ah, 325A	0 092 S37 383	0 986 A02 788	
		12.00 /	12V, 45Ah, 350A	0 092 S37 384		
			12V, 48Ah, 450A 12V, 58Ah, 510A		0 092 S47 182	0 092 S57 002
	天语 SX4 1.8 i	08.08-12.13	12V, 45Ah, 325A		0 986 A02 788	0 002 001 002
			12V, 45Ah, 350A 12V, 58Ah, 510A	0 092 S37 384		0 092 S57 002
	天语 SX4 1.8 i 掀背车	08.08-09.13	12V, 45Ah, 325A		0 986 A02 788	0 0 3 2 3 3 7 0 0 2
			12V, 45Ah, 350A 12V, 58Ah, 510A	0 092 S37 384		0 092 S57 002
北斗星	北斗星 1.0 i	12.03→	12V, 36Ah, 280A	0 092 S37 382		0 002 001 002
			12V, 45Ah, 325A 12V, 48Ah, 450A		0 986 A02 788 0 092 S47 182	
	北斗星 1.1 i	12.03-07.04	12V, 36Ah, 280A	0 092 S37 382		
	 北斗星 1.2 i	12.03-07.04	12V, 45Ah, 325A 12V, 36Ah, 280A	0 092 S37 382	0 986 A02 788	
			12V, 45Ah, 325A		0 986 A02 788	
	北斗星 1.4 i	04.05→	12V, 36Ah, 280A 12V, 45Ah, 325A	0 092 S37 382	0 986 A02 788	
· 기구 ()			12V, 48Ah, 450A		0 092 S47 182	
利亚纳 利亚纳 [ER]	利亚纳 1.4 i 利亚纳 1.6 i 16V 轿车	06.10→ 12.05-12.07	12V, 45Ah, 325A 12V, 45Ah, 325A		0 986 A02 788 0 986 A02 788	
利亚纳 [ER] 掀背车	利亚纳 1.6 i 16V 掀背车	03.01-04.08	12V, 45Ah, 325A		0 986 A02 788	
雨燕	雨燕 1.3 i 8V 掀背车	12.04-09.09	12V, 45Ah, 325A 12V, 45Ah, 350A	0 092 S37 384	0 986 A02 788	
	雨燕 1.3 i 掀背车	05.06-01.12	<u> </u>		0 986 A02 788	0 092 S57 002
		10.10→ 10.07→	12V, 58Ah, 510A 12V, 45Ah, 325A		0 986 A02 788	0 092 S57 024
			12V, 45Ah, 350A 12V, 58Ah, 510A	0 092 S37 384		0 092 S57 002
浪迪	浪迪 1.2 i	04.10-06.14	12V, 45Ah, 325A		0 986 A02 788	352 551 552
	浪迪 1.4 i	12.06→	12V, 45Ah, 325A 12V, 45Ah, 350A	0 092 S37 384	0 986 A02 788	
₩ ¥	数 关 4 0	00.02.10.00	12V, 58Ah, 510A			0 092 S57 002
羚羊	羚羊 1.3 羚羊 1.3 i	09.03-10.08 04.05→	12V, 45Ah, 350A 12V, 36Ah, 180A	0 092 S37 383 0 092 S37 381		
			12V, 36Ah, 310A		0 986 A02 781	
		05.06→	12V, 45Ah, 325A 12V, 40Ah, 340A		0 986 A02 787 0 092 S47 181	
			12V, 48Ah, 450A		0 092 S47 183	
南坛	南红 0 0:	01 07 10 00		0.002.027.004		
奥拓	奥拓 0.8 i	01.97-10.08		0 092 S37 381	0 986 A02 781	
奥拓			12V, 36Ah, 180A 12V, 36Ah, 310A 12V, 40Ah, 340A		0 986 A02 781 0 092 S47 181	
奥拓	奥拓 0.8 i 奥拓 1.0 i	01.97-10.08	12V, 36Ah, 180A 12V, 36Ah, 310A 12V, 40Ah, 340A	0 092 S37 381 0 092 S37 381		


















丰田▶

标致 ・ 中顺 ・ 保时捷 ・ 启辰 ・ 庆铃 ・ 威麟 ・ 雷诺 ・ 瑞麟 ・ 荣威 ・ 劳斯莱斯 ・ 萨博 ・ 双环 ・ 斯柯达 ・ 东南 ・ 双龙 ・ 斯巴鲁 ・ 铃木 ・ 通宝 ・ 丰田



















		Ta Car	参数	S3 动能	S4 动力神	S5 银侠
丰田(接上页)						
锐志	锐志 2.5 i	08.05→	12V, 70Ah, 550A 12V, 70Ah, 600A	0 092 S37 421	0 986 A02 798	
	锐志 3.0 i	08.05→	12V, 70Ah, 550A	0 092 S37 421		
雅力士	雅力士 1.3 VVT-i	01.08-02.13	12V, 70Ah, 600A 12V, 60Ah, 400A		0 986 A02 798 0 986 A02 789	
	雅力士 1.6 i	01.08→	12V, 60Ah, 520A 12V, 60Ah, 520A	0 092 S37 380 0 092 S37 380		
雷凌	雷凌 1.6 i	04.14→	12V, 60Ah, 520A		0 092 S37 380	
传祺						
GA3 GS5	GA3 1.6 i GS5 1.8 i	05.13→ 08.12→	12V, 55Ah, 450A 12V, 70Ah, 570A		0 092 S37 392 0 092 S37 399	
	400 1.01	00.12	121, 10/11, 010/1		0 002 007 003	
沃尔沃						
940 C30	940 2.3 C30 2.4 i	09.94-07.95 10.06-07.10	12V, 74Ah, 680A 12V, 74Ah, 680A			0 986 A02 334 0 986 A02 334
C70 II	C70 II T5	03.06-07.07	12V, 74Ah, 680A			0 986 A02 334
S40 II	S40 II 2.0 i S40 II 2.4	11.08-03.12 12.03-07.10	12V, 72Ah, 700A 12V, 72Ah, 700A		0 986 A02 822 0 986 A02 822	
S60 II	S60 II T6 AWD	08.10→	12V, 74Ah, 680A			0 986 A02 334
S70 S80	S70 2.4 S80L 2.0 i	08.99-07.00 06.11-06.13	12V, 74Ah, 680A 12V, 80Ah, 720A			0 986 A02 334 0 986 A02 341
S80 I	S8012.5	08.03-07.06	12V, 70Ah, 570A	0 092 S37 399		
			12V, 72Ah, 700A 12V, 74Ah, 680A		0 986 A02 822	0 986 A02 334
	S8013.0	08.01-07.06	12V, 74Ah, 680A			0 986 A02 334
S80 II	S80 II 3.0 T	12.08-06.13	12V, 100Ah, 800A 12V, 80Ah, 720A		0 986 A02 824	0 986 A02 341
	S80 II 3.2	08.06-07.10	12V, 74Ah, 680A			0 986 A02 334
	S80 II T6 AWD	08.10→	12V, 88Ah, 600A 12V, 74Ah, 680A		0 986 A02 823	0 986 A02 334
	S80 II V8 AWD	03.06-12.10	12V, 74Ah, 680A			0 986 A02 334
V60	V60 3.0 T6 AWD	09.10→	12V, 88Ah, 600A 12V, 74Ah, 680A		0 986 A02 823	0 986 A02 334
XC60	XC60 T5 FWD	08.10-07.14	12V, 74Ah, 680A			0 986 A02 334
XC90	XC60 T6 AWD XC90 V8 AWD	08.10→ 03.05-12.10	12V, 74Ah, 680A 12V, 74Ah, 680A			0 986 A02 334 0 986 A02 334
			12V, 100Ah, 800A		0 986 A02 824	
XC901	XC9013.2 AWD XC901T5 AWD	08.06-07.10 08.12-07.16	12V, 74Ah, 680A 12V, 74Ah, 680A			0 986 A02 334 0 986 A02 334
	XC90 I T6 AWD	01.03-07.06	12V, 74Ah, 680A 12V, 100Ah, 800A		0 986 A02 824	0 986 A02 334
			12V, 100AII, 000A		0 300 A02 024	
大众						
CC	CC 1.8 T	11 10->	12V 60Ab 590A		0.002.647.102	
CC	CC 1.8 I	11.10→	12V, 60Ah, 580A		0 092 S47 193 0 986 A02 827	
	CC 2.0 i CC 3.0 i	04.10→ 12.11→	12V, 72Ah, 700A 12V, 100Ah, 800A		0 986 A02 822	
Eos [1F7]	Eos 2.0 TSI	05.06-11.10	12V, 74Ah, 680A		0 986 A02 824	0 986 A02 334
开迪	开迪 1.6 i 开迪 2.0 D	01.05-06.08 01.05-08.06	12V, 60Ah, 580A 12V, 60Ah, 580A		0 986 A02 827 0 986 A02 827	
迈腾	迈腾 2.0 i	02.07-12.08	12V, 55Ah, 500A	0 092 S37 393	0 300 A02 021	
		11.09-06.14	12V, 66Ah, 500A 12V, 60Ah, 580A		0 986 A02 821 0 092 S47 193	
					0 986 A02 827	
	迈腾 B6 1.8 T	02.07-07.11	12V, 60Ah, 580A		0 092 S47 193 0 986 A02 827	
	<u></u> 迈腾 B6 2.0 T	11.07-07.11	12V, 66Ah, 500A 12V, 55Ah, 500A	0 092 S37 393	0 986 A02 821	
			12V, 66Ah, 500A		0 986 A02 821	
	迈腾 B7 1.8 T	04.11→	12V, 60Ah, 580A		0 092 S47 193 0 986 A02 827	
	迈腾 B7 2.0 T	04.11→	12V, 60Ah, 580A		0 092 \$47 193	
	迈腾 B7 3.0 i	09.11→	12V, 100Ah, 800A		0 986 A02 827 0 986 A02 824	
宝来	宝来 1.4 T	03.10→	12V, 60Ah, 580A		0 092 S47 193 0 986 A02 827	
	宝来 1.6 i	01.01-06.03	12V, 60Ah, 580A		0 092 S47 193	
		06.08→	12V, 60Ah, 580A		0 986 A02 827 0 092 S47 193	
					0 986 A02 827	
	宝来 1.8 i	05.06-07.07 01.09-06.12	12V, 60Ah, 580A 12V, 60Ah, 580A		0 986 A02 617 0 986 A02 827	
	宝来 1.8 T		12V, 60Ah, 580A		0 092 S47 193	
宝来 [9D, 152]	宝来 1.6 i	01.01-07.08	12V, 55Ah, 500A	0 092 S37 393	0 986 A02 827	
			12V, 60Ah, 580A		0 092 \$47 193	
	宝来 1.8 i		12V, 60Ah, 580A		0 986 A02 827 0 986 A02 617	
			12V, 60Ah, 580A 12V, 62Ah, 480A		0 986 A02 827	0 986 A02 331
	宝来 1.9 TDI	01.01-06.03	12V, 62Ah, 480A			0 986 A02 331
			12V, 70Ah, 650A 12V, 77Ah, 790A		0 986 A02 618	0 092 S57 060
			12V, 80Ah, 640A	0 092 S37 401		
		06 08-07 10	12V, 100Ah, 830A 12V, 60Ah, 580A		0 092 S47 193	0 092 S50 130
	/N 2.VI	50.00 07.10			0 986 A02 827	
尚酷 [137]	尚酷 2.0 TSI	11.09-05.1/	12V, 62Ah, 480A 12V, 74Ah, 680A			0 986 A02 331 0 986 A02 334
帕萨特	帕萨特 1.8 T	01.10-10.12	12V, 60Ah, 580A		0 986 A02 827	1 100 A02 004
	帕萨特 1.9 D 帕萨特 2.0 i	04.05-07.09 01.09-06.12	12V, 60Ah, 580A 12V, 60Ah, 580A		0 986 A02 827 0 986 A02 827	
帕萨特 [3C2]	帕萨特 3.2 FSI 4Moti	on 09.05-07.10	12V, 100Ah, 830A			0 092 S50 130
帕萨特 [357] CC	帕萨特 3.6 FSI CC 4Motion	υ8.08-05.12	12V, 74Ah, 680A			0 986 A02 334













1		面	参数	S3 动能	S4 动力神	S5 银侠
	帕萨特 1.8 i	01.00.04.04	10V COAL FOOA		0 986 A02 617	
帕萨特 [B5]	帕萨特 1.8 T	01.98-04.04 01.03-07.09	12V, 60Ah, 580A		0 986 A02 617	
		01.03-01.13	12V, 70Ah, 570A 12V, 70Ah, 650A	0 092 S37 399	0 986 A02 618	
	帕萨特 1.9 TDI	03.08-06.09	12V, 70Ah, 570A	0 092 S37 399		
	帕萨特 2.0 i	01.02-07.09	12V, 70Ah, 650A 12V, 70Ah, 570A	0 092 S37 399	0 986 A02 618	
		04.03-06.12	12V, 70Ah, 650A 12V, 55Ah, 500A	0 092 S37 393	0 986 A02 618	
	帕萨特 2.0 i GP		12V, 70Ah, 570A	0 092 S37 399		
	帕萨特 2.8 i	01.02-02.07	12V, 70Ah, 650A 12V, 70Ah, 570A	0 092 S37 399	0 986 A02 618	
14 ++ 4+ F==3			12V, 70Ah, 650A		0 986 A02 618	
帕萨特 [B7]	帕萨特 2.0 T	11.10→	12V, 60Ah, 580A		0 092 S47 193 0 986 A02 827	
	新帕萨特1.4T	11.10→	12V, 60Ah, 580A		0 092 S47 193 0 986 A02 827	
	新帕萨特 1.8 T	11.10→	12V, 60Ah, 580A		0 092 S47 193	
	新帕萨特 3.0 i	08.11→	12V, 100Ah, 800A		0 986 A02 827 0 986 A02 824	
帕萨特领驭	帕萨特领驭 1.8 T		12V, 60Ah, 580A		0 092 S47 193	
波罗	波罗 1.4 i	01.01-06.08	12V, 60Ah, 580A		0 986 A02 827 0 986 A02 617	
			12V, 51Ah, 480A 12V, 60Ah, 580A		0 092 S47 190 0 092 S47 193	
					0 986 A02 827	
		02.14→	12V, 51Ah, 480A 12V, 60Ah, 580A		0 092 S47 190 0 092 S47 193	
	V				0 986 A02 827	
	波罗 1.6 i	01.01-06.12 01.06-07.09	12V, 60Ah, 580A 12V, 60Ah, 580A		0 986 A02 617 0 092 S47 193	
					0 986 A02 827	
		02.14→	12V, 60Ah, 580A		0 092 S47 193 0 986 A02 827	
波罗两厢	波罗 1.4 i 两厢	01.01-07.08 $01.01 \rightarrow$	12V, 60Ah, 580A 12V, 51Ah, 480A		0 986 A02 617 0 092 S47 190	
		01.01	12V, 60Ah, 580A		0 092 S47 193	
	波罗 1.6 i 两厢	01.01→	12V, 60Ah, 580A		0 986 A02 827 0 092 S47 193	
	1.01 PJ/H				0 986 A02 827	
夏朗 [7M9,7M6]	夏朗 1.8 T	12.03-07.08 05.00-03.10	12V, 60Ah, 580A 12V, 62Ah, 480A		0 986 A02 617	0 986 A02 331
			12V, 74Ah, 680A			0 986 A02 334
夏朗 [7N1] 朗行	夏朗 2.0 TSI 朗行 1.4 i	11.10-11.15 02.13→	12V, 74Ah, 680A 12V, 60Ah, 580A		0 092 S47 193	0 986 A02 334
	98年16:	01.13→	12V 60Ab 500A		0 986 A02 827 0 092 S47 193	
	朗行 1.6 i		12V, 60Ah, 580A		0 986 A02 827	
朗逸	朗逸 1.4 i	02.13→	12V, 51Ah, 480A 12V, 60Ah, 580A		0 092 S47 190 0 092 S47 193	
					0 986 A02 827	
	朗逸 1.4 T	09.09-10.13	12V, 51Ah, 480A 12V, 60Ah, 580A		0 092 S47 190 0 986 A02 617	
	朗逸 1.6 i	05.11→	12V, 60Ah, 580A		0 092 S47 193 0 986 A02 827	
朗逸 [18]	朗逸 1.6 i	03.08-10.13	12V, 60Ah, 580A		0 986 A02 617	
		01.10-02.12	12V, 60Ah, 580A		0 092 S47 193 0 986 A02 827	
	朗逸 2.0 i	03.08-03.13	, ,		0 986 A02 617	
朗境 桑塔纳	朗境 1.4 i 桑塔纳 1.6 i	06.13→ 12.00→	12V, 60Ah, 580A 12V, 54Ah, 460A		0 986 A02 827 0 986 A02 809	
	桑塔纳 1.8 i	06.04-03.13 09.05-03.13	12V, 60Ah, 580A 12V, 54Ah, 460A		0 986 A02 617 0 986 A02 809	
		09.05-03.13	12V, 54Ah, 500A	0 092 S37 387	U 900 AUZ 0U9	
	桑塔纳 1.8 i GLi	01.97→	12V, 54Ah, 460A	0 092 S37 404	0 986 A02 809	
桑塔纳 2000	桑塔纳 2000 1.8 i	11.00-01.04	12V, 54Ah, 460A		0 986 A02 809	
			12V, 54Ah, 500A	0 092 S37 387 0 092 S37 404		
			12V, 60Ah, 580A		0 092 \$47 193	
	桑塔纳 2000 1.8 i	01.98-12.00	12V, 54Ah, 460A		0 986 A02 827 0 986 A02 809	
桑塔纳 3000	GSi 8V 桑塔纳 3000 1.6 i	01.10-06.12	12V, 54Ah, 460A		0 986 A02 809	
桑塔纳 3000	桑塔纳 3000 1.8 i	03.04→	12V, 54Ah, 460A		0 986 A02 809	
		08.09-03.14	12V, 54Ah, 500A	0 092 S37 387 0 092 S37 404		
	桑塔纳 3000 2.0 i	12.05-01.11	12V, 54Ah, 460A		0 986 A02 809	
			12V, 54Ah, 500A	0 092 S37 387 0 092 S37 404		
桑塔纳旅行车	桑塔纳旅行车 1.8 i 桑塔纳旅行车 1.8 i	09.05-04.09	12V, 60Ah, 580A		0 986 A02 617	
	GLi 8V		12V, 54Ah, 460A		0 986 A02 809	
金安	途安 1.4 T	09.10→	12V, 51Ah, 480A 12V, 60Ah, 580A		0 092 S47 190 0 092 S47 193	
	\\\dagger_1 \\ 2 \\	04.01			0 986 A02 827	
	途安 1.8 T 途安 2.0 i	01.04→ 09.04-01.11	12V, 60Ah, 580A 12V, 60Ah, 580A		0 986 A02 617 0 986 A02 617	
金观	途双 1.4 TSI	09.11→	12V, 51Ah, 480A		0 092 S47 190	
途观		12.09→	12V, 60Ah, 580A 12V, 60Ah, 580A		0 986 A02 827 0 092 S47 193	
₹70 (ENO)		11 11 1	101/ 7445 0004		0 986 A02 827	0.000 400 001
金观 [5N2] 金观 [5NX]	途观 2.0 TDI 4Motion 途观 2.0 TSI	11.11→ 12.09→	12V, 74Ah, 680A 12V, 60Ah, 580A		0 986 A02 827 0 092 S47 193	0 986 A02 334
	途观 2.0 TDI 4Motion					0 986 A02 334 0 092 S50 130







大众▶















		T	参数	S3 动能	S4 动力神	S5 银侠
大众(接上页) 途锐[7LA]	途锐 3.6 FSI	08 05-11 06	12V, 100Ah, 760A			0 986 A02 337
~~**()			12V, 100Ah, 800A 12V, 100Ah, 830A		0 986 A02 824	0 092 S50 130
	途锐 4.2		12V, 100Ah, 830A 12V, 100Ah, 870A	0 092 S37 206		0 092 S50 130
途锐 [7P5] 速腾	途锐 4Motion 3.0 FSI 速腾 1.4 TSI/4V	04.10→ 04.09→	12V, 100Ah, 800A 12V, 60Ah, 580A		0 986 A02 824 0 986 A02 617	
XEII-J	速腾 1.6 i	12.05→	12V, 60Ah, 580A		0 092 S47 193	
	速腾 1.8T	12.05-01.12	12V, 60Ah, 580A		0 986 A02 827 0 986 A02 617	
	本咲 2 0 :	10.11-08.14	12V, 60Ah, 580A		0 986 A02 827	
	速腾 2.0 i 速腾 2.0 T	12.05-11.09	12V, 60Ah, 580A 12V, 60Ah, 580A		0 986 A02 617 0 986 A02 827	
高尔 高尔夫	高尔 1.6 i 高尔夫 2.0 i	01.02→ 09.01-10.03	12V, 60Ah, 580A 12V, 60Ah, 580A		0 986 A02 617 0 986 A02 827	
同 小八	高尔夫 VII 1.4	09.13→	12V, 60Ah, 580A		0 092 S47 193	
	 高尔夫 Ⅶ 1.6 i	07.13→	12V, 60Ah, 580A		0 986 A02 827 0 986 A02 617	
高尔夫IV	高尔夫 IV 1.6 i	08.03-03.09	12V, 63Ah, 550A		0 986 A02 810	
	高尔夫 IV 1.8 i	09.09-03.14 08.03-07.08	12V, 63Ah, 550A 12V, 63Ah, 550A		0 986 A02 810 0 986 A02 810	
高尔夫 V [1K1]	高尔夫 V 2.0 FSI	01 04 07 04	12V, 74Ah, 680A 12V, 63Ah, 550A		0 986 A02 810	0 986 A02 334
-			12V, 74Ah, 680A			0 986 A02 334
高尔夫 VI	高尔夫 VI 1.4 TSI 高尔夫 VI 1.6 i	09.09-06.14 09.09-06.14	12V, 63Ah, 550A 12V, 60Ah, 580A		0 986 A02 810 0 092 S47 193	
					0 986 A02 827	
高尔夫 VI [517]	高尔夫 VI 2.0 GTI 高尔夫 VI 1.4 TSI	12.09-06.14 09.12→	12V, 72Ah, 700A 12V, 74Ah, 680A		0 986 A02 822	0 986 A02 334
敞蓬轿车	敞蓬轿车		, , , , , , , , , , , , , , , , , , , ,			
高尔夫 VI 旅行版 [AJ5]	高尔夫 VI 1.6 旅行版	07.09-04.13	12V, 74Ah, 680A			0 986 A02 334
捷达	捷达 1.4 i	01.13→	12V, 51Ah, 480A 12V, 60Ah, 580A		0 092 S47 190 0 092 S47 193	
			12V, 60AN, 580A		0 986 A02 827	
	捷达 1.6 i	01.99-06.14 09.04-06.13	12V, 63Ah, 550A 12V, 55Ah, 500A	0 092 S37 393	0 986 A02 810	
			12V, 63Ah, 530A	0 092 S37 398		
		09.12→	12V, 60Ah, 580A		0 092 S47 193 0 986 A02 827	
July Diff. Form 3	捷达 1.9 D	10.01-05.12	12V, 63Ah, 550A		0 986 A02 810	
辉腾 [3D]	辉腾 3.2 4Motion 辉腾 4.2 4Motion	05.04-10.08 08.03→	12V, 74Ah, 680A 12V, 74Ah, 680A			0 986 A02 334 0 986 A02 334
	響味 C O AMation	05.05→	12V, 77Ah, 790A			0 092 S57 060
新甲壳虫[1C1,9C1]	辉腾 6.0 4Motion 新甲壳虫 1.6	05.05→ 06.02-12.10	12V, 74Ah, 680A 12V, 60Ah, 580A		0 986 A02 827	0 986 A02 334
	新甲壳虫 1.8 T	10.00-12.10	12V, 74Ah, 680A 12V, 60Ah, 580A		0 986 A02 827	0 986 A02 334
			12V, 74Ah, 680A			0 986 A02 334
	新甲壳虫 2.0	06.01-09.10	12V, 60Ah, 580A 12V, 74Ah, 680A		0 986 A02 827	0 986 A02 334
新桑塔纳	新桑塔纳 1.4	05.14→	12V, 51Ah, 480A		0 092 \$47 190	
	新桑塔纳1.4i	08.12→	12V, 51Ah, 480A 12V, 60Ah, 580A		0 092 S47 190 0 092 S47 193	
	立る埃加 1 C:	08.12→	107 COAL EDDA		0 986 A02 827	
	新桑塔纳 1.6 i	08.12→	12V, 60Ah, 580A		0 092 S47 193 0 986 A02 827	
万丰						
万丰	万丰 2.2 i	09.03-03.07	12V, 80Ah, 680A		0 986 A02 612	
五菱						
小旋风	小旋风 1.0 i	01.08→	12V, 48Ah, 450A	0 092 S37 402		
	小旋风 1.1 i	11.02-02.11	12V, 48Ah, 450A	0 092 \$37 402		
五菱之光	小旋风 1.2 i 五菱之光 1.0 i	04.10→ 01.03→	12V, 48Ah, 450A 12V, 45Ah, 325A	0 092 S37 402	0 986 A02 787	
		11.08→	12V, 48Ah, 450A 12V, 45Ah, 350A		0 092 S47 183 0 092 S37 384	
	T#444	01.10→	12V, 36Ah, 180A	0 092 S37 381		
	五菱之光 1.1 i	$01.03 \rightarrow 07.03-06.13$	12V, 45Ah, 325A 12V, 48Ah, 450A		0 986 A02 787 0 092 S47 183	
	工業力业 4 0 :	12.06→	12V, 45Ah, 350A		0 092 S37 384	
	五菱之光 1.2 i	01.07→	12V, 45Ah, 325A 12V, 48Ah, 450A		0 986 A02 787 0 092 S47 183	
		$\frac{11.07 \rightarrow}{01.08 \rightarrow}$	12V, 45Ah, 350A 12V, 48Ah, 450A		0 092 S37 384 0 092 S37 402	
	五菱之光 1.3 i	01.08→ 10.03-07.08	12V, 36Ah, 180A	0 092 S37 381		
		10 03-05 00	12V, 36Ah, 310A 12V, 45Ah, 325A		0 986 A02 781 0 986 A02 787	
- 10 10	五菱之光 1.5 i	03.12→	12V, 48Ah, 450A		0 092 \$37 402	
五菱龙 双厢皮卡	五菱龙 0.8 i 双厢皮卡 0.8 i		12V, 48Ah, 450A 12V, 36Ah, 180A	0 092 S37 402 0 092 S37 381		
	双厢皮卡 1.0 i	12.02-07.10	12V, 36Ah, 180A	0 092 S37 381		
兴旺	兴旺 0.8 i	01.02-06.08	12V, 36Ah, 280A 12V, 45Ah, 350A	0 092 S37 382 0 092 S37 384		
	兴旺 1.0 i	01.02-12.08	12V, 48Ah, 450A 12V, 45Ah, 350A	0 092 S37 402	0 092 S37 383	
	/\d_ 1.01	01.02-03.11	12V, 45Ah, 350A	0 092 S37 384		
	兴旺 1.1 i		12V, 45Ah, 325A 12V, 45Ah, 350A	0 092 S37 384	0 986 A02 785	
宏光	宏光 1.2 i	03.10→	12V, 45Ah, 225A	0 092 S37 385		
	宏光 1.4 i 宏光 1.5 i	03.10-07.14 10.12→	12V, 45Ah, 225A 12V, 45Ah, 325A	0 092 S37 385	0 986 A02 785	
带 业			12V, 48Ah, 450A	0.002.027.005	0 092 S47 185	
荣光	荣光 1.2 i	06.07-12.13 $03.12 \rightarrow$	12V, 45Ah, 225A 12V, 48Ah, 450A	0 092 S37 385 0 092 S37 402		
		01.13→	12V, 45Ah, 325A 12V, 48Ah, 450A		0 986 A02 785	
	荣光 1.5 i	03.12→	12V, 45Ah, 325A		0 092 S47 185 0 986 A02 785	
都市清风	都市清风 1.3 i	01.97-06.05	12V, 48Ah, 450A 12V, 48Ah, 450A	0 092 S37 402	0 092 S47 185	
THE STATE OF	B		,,			
















跃进 • 云雀 • 宇通 • 中华 • 中兴 ▶

 \bigcirc



(lacktriangle)



•







		面	参数	S3 动能	S4 动力神	S5 银侠
跃进 (接上页) 跃进	跃进 3.2 D	05.04→	12V. 70Ah. 640A	0.096 402 220		
以 进	跃进 3.2 D 跃进 3.3 D	05.04→ 09.01-06.11	12V, 70Ah, 640A	0 986 A02 332 0 986 A02 332		
	跃进 3.4 D	04.03-11.08	12V, 70Ah, 640A 12V, 120Ah, 638A	0 986 A02 332 0 986 A02 734		
			12V, 120Ah, 740A	0 092 S37 410		
	跃进 3.6 D 跃进 3.7 D	03.03-03.07 06.01→	12V, 70Ah, 640A 12V, 70Ah, 640A	0 986 A02 332 0 986 A02 332		
	跃进 3.8 D	04.06-06.08	12V, 70Ah, 640A	0 986 A02 332		
	跃进 3.9 D	03.01-10.08	12V, 120Ah, 638A 12V, 120Ah, 740A	0 986 A02 734 0 092 S37 410		
		03.01→	12V, 70Ah, 640A	0 986 A02 332		
	跃进 4.1 D	03.02→	12V, 70Ah, 640A 12V, 120Ah, 638A	0 986 A02 332		
			12V, 120Ah, 740A	0 986 A02 734 0 092 S37 410		
\ π#\Δ	跃进 4.6 D	08.02-03.05	12V, 70Ah, 640A	0 986 A02 332	0.000 400 700	
新雅途	新雅途 1.5 i	10.03-06.08	12V, 45Ah, 325A 12V, 45Ah, 350A	0 092 S37 384	0 986 A02 788	
			12V, 58Ah, 510A			0 092 S57 00
云雀						
云雀	云雀 0.7 T	06.03-04.08	12V, 36Ah, 310A		0 986 A02 782	
			12V, 40Ah, 340A		0 092 S47 180	
宇通						
宇通	宇通 2.7 D	10.03→	12V, 60Ah, 400A		0 986 A02 789	
			12V, 60Ah, 450A	0.002.027.200	0 092 S47 101	
		04.06-05.08	12V, 60Ah, 520A 12V, 70Ah, 640A	0 092 S37 380 0 986 A02 332		
		08.06-05.08	12V, 60Ah, 400A		0 986 A02 790	
			12V, 60Ah, 450A 12V, 60Ah, 520A	0 092 S37 431 0 092 S37 406		
			12V, 60Ah, 530A		0 092 S47 187	
	<u>宇通 2.8 D</u>	11.08→ 08.06-06.12	12V, 70Ah, 640A 12V, 70Ah, 640A	0 986 A02 332 0 986 A02 332		
	宇通 3.0 D	06.07→	12V, 70Ah, 640A	0 986 A02 332		
	宇通 3.3 D 宇通 3.4 D	11.02-01.07 09.03-02.07	12V, 70Ah, 640A 12V, 68Ah, 650A	0 986 A02 332	0 986 A02 611	
	宇通 3.7 D	12.03-08.10		0 986 A02 332	0 300 A02 011	
	宇通 3.8 宇通 3.9 D	04.07→ 02.03→	12V, 70Ah, 640A 12V, 70Ah, 640A	0 986 A02 332 0 986 A02 332		
	宁通 3.5 D 宇通 4.1 D	03.02→	12V, 70Ah, 640A	0 986 A02 332		
	宇通 4.2 D	09.03→	12V, 70Ah, 640A	0 986 A02 332		
	宇通 5.6 D 宇通 7.8 D		12V, 70Ah, 640A 12V, 70Ah, 640A	0 986 A02 332 0 986 A02 332		
中华						
H230	H230 1.5 i	03.12→	12V, 60Ah, 580A		0 092 S47 193	
H330	H330 1.5 i	07.12→	12V, 60Ah, 580A		0 986 A02 827 0 092 S47 193	
H530	H530 1.6 i	03.11→	12V, 60Ah, 580A		0 986 A02 827 0 092 S47 193	
V5	V5 1.5 i	08.11→	12V, 60Ah, 580A		0 986 A02 827 0 092 S47 193	
	V5 1.6 i	08.11→	12V, 60Ah, 580A		0 986 A02 827 0 092 S47 193	
双门轿车	酷宝 M3 1.8 i	06.07-05.11	12V, 60Ah, 400A		0 986 A02 827 0 986 A02 790	
771 JJJ	HA III 110 1.01	00.01 00.11	12V, 60Ah, 450A 12V, 60Ah, 520A	0 092 S37 431 0 092 S37 406		
· · · · · · · · · · · · · · · · · · ·	%捷 1.6 i	04.10→	12V, 60Ah, 530A 12V, 60Ah, 580A	0 032 331 400	0 092 S47 187 0 092 S47 193	
<i>3</i> .7.2	%捷 1.8 i	11.08→	12V, 65Ah, 370		0 986 A02 827 0 092 S47 106	
	%捷 1.9 D	06.08-06.09	12V, 70Ah, 500A 12V, 65Ah, 370		0 986 A02 795 0 092 S47 106	
7/14			12V, 70Ah, 500A		0 986 A02 795	
骏捷 FRV	骏捷 FRV 1.3 i	04.08-01.14	12V, 45Ah, 325A 12V, 48Ah, 450A		0 986 A02 786 0 092 S47 184	
	骏捷 FRV 1.5 i	12.08→	12V, 45Ah, 325A		0 986 A02 786	
	骏捷 FRV 1.6 i	04.08-05.11	12V, 48Ah, 450A 12V, 45Ah, 325A		0 092 S47 184 0 986 A02 786	
骏捷 FSV	%捷FSV1.5 i	05.09→	12V, 48Ah, 450A 12V, 60Ah, 450A	0 092 S37 432	0 092 S47 184	
骏捷 [M2]	骏捷 1.6 i	01.06-12.10	12V, 60Ah, 520A 12V, 65Ah, 370	0 092 S37 389	0 092 S47 106	
-	骏捷 1.8 i		12V, 70Ah, 500A 12V, 65Ah, 370		0 986 A02 795 0 092 S47 106	
	骏捷 2.0 i	03.06→	12V, 70Ah, 500A 12V, 65Ah, 370		0 986 A02 795 0 092 S47 106	
尊驰	尊驰 1.8 i	12.05-10.10		0 092 \$37 380	0 986 A02 795	
	尊驰 1.8T	12.05→	12V, 70Ah, 500A 12V, 45Ah, 225A	0 986 A02 796 0 092 S37 385		
	24.51		12V, 58Ah, 510A 12V, 70Ah, 500A		0 986 A02 795	0 092 S57 024
	尊驰 2.0 i	$06.03 \rightarrow 11.08 \rightarrow$	12V, 70Ah, 500A 12V, 45Ah, 225A	0 092 S37 385	0 986 A02 795	0.000.057.05
	尊驰 2.4 i	02.03-06.09	12V, 58Ah, 510A 12V, 70Ah, 500A		0 986 A02 795	0 092 \$57 024
中兴					0 092 \$47 103	
中兴	工 限20i	07 06-01 07	12V 60VP 200V			
中兴 ^{无限}	无限 2.0 i	07.06-01.07	12V, 60Ah, 290A 12V, 60Ah, 475A		0 986 A02 793	
			12V, 60Ah, 475A 12V, 60Ah, 520A		0 986 A02 793 0 986 A02 607	
	无限 2.0 i 无限 2.2 i		12V, 60Ah, 475A		0 986 A02 793	
			12V, 60Ah, 475A 12V, 60Ah, 520A 12V, 60Ah, 290A 12V, 60Ah, 475A 12V, 60Ah, 520A		0 986 A02 793 0 986 A02 607 0 092 S47 103	





