FRASIL — CHEAT SHEET

FIRMWARE 2.0 FOR THE M-VAVE FM-1

frasilsynth.com THE GUIDE · PLAY IT IN THE BROWSER

A PRESS SHOWS · A HOLD ACTS

Tap a button for the white word under it; hold it for the amber one. A +: hold it, then press or turn what follows.

- THE DRONES
- GLINT · FREEZE · K1–K4
- HELD · PRESSED · BASS

MASTER — VOLUME

SELECT (A) — KEYS

PRESETS (B) — PRESET

ALGORITHM (C) — BODY

OCT – | OCT +

OCTAVE –3 … +2 · BOTH: –1



ON SCREEN, A SETTING WEARS ITS KNOB'S BADGE

A B C — LEFT

1 2 3 4 — K1–K4

K1 (1) | K2 (2) | K3 (3) | K4 (4)

THE PAGE'S FOUR SETTINGS

FX	SEL	ENV	LFO	EDIT	GLO
GENERATIVE FX FREEZE	HARMONY + KEY: 1 NOTE	DRONE SHAPE SWELL	DRONE MOTION + K: ROUTE	DRONE PARAMS COMPARE	GLOBAL + CC: LEARN
HOME	SAVE	ARP	SEQ	PLAY	REC
PLAY PAGE HELP	SCENES + REC: STORE + KEY: LOAD	GLINT LATCH	BASS	START · STOP RELEASE ALL	RECORD METRONOME



PRESSURE: THE 20 LOWEST KEYS · HOLD ONE AND PRESS IN

THE TOP 7: NO PRESSURE

DRONE — HOME · SELECT A LEFT

TAP	lights a note or chord; it stays.
TAP AGAIN	it fades over **RELEASE**.
PRESS IN	it swells and opens.
SEL + KEY	a single note over a chord.
ENV HELD	**SWELL**: every voice at once.
PLAY HELD	**RELEASE ALL**; again: **RESTORE**. Held, or starting: the beat restarts.
KEY MODE	**GLOBAL**, K4: **LATCH** or **HOLD**.

GLINT — ARP · SELECT A MIDDLE

KEY	an icy **FM** bell; it rings out.
PRESS IN	louder; a wiggle: **VIBRATO**.
SEQ	**OFF**, **ARP**, or **SEQ** (32 steps): **GLINT I**, K2.
ARP HELD	**LATCH** (on: SEQ on ARP): plays on.
REC	records **LIVE** into the sequence; again: off; held: metronome.
SEQ, KEY	transposed, from step 1 on the beat; on its SEQ pages, a glint.

BASS — SEQ · SELECT A RIGHT

TAP	holds one note, **OCTAVE** down.
OTHER KEY	it glides there (**GLIDE**).
ITS KEY	it lets go.
PRESS IN	louder; its filter opens.
IT STAYS	till PLAY is held.
PULSE	struck again on the grid.
MODEL	**SINE**, **TRIANGLE**, **SQUARE**, **SAW**, **REESE**, **SUB**, **ORGAN**, **FM**.
SEQUENCE	16 steps; REC: as you play.

SCENES — 16 SLOTS · 1–7 FACTORY · NEW SHARD: START FRESH — SAVE

SAVE	**SCENES**: K1 or A the slot, K2 **MORPH**, K3 **LOAD**.
SAVE + REC	**STORE**, in K1's slot on **SCENES**, else in the current scene.
NAME IT	then, 16 characters: OCT– OCT+ the cursor, K4 letters, K3 digits; SEL stores it, FX cancels.
SAVE + KEY	loads: the 16 white keys are the 16 slots. On **SCENES**: PLAY.
MORPH	**CUT** (at power-on), or **1 S** to **2:00**: the sound glides into the scene.
LOAD	**SND+NOTES**: all let go, its notes play. **SND ONLY**: the sound alone, what plays goes on.
EDIT HELD	**COMPARE**: the scene as saved. SAVE lit: it has **CHANGED**.

USEFUL TIPS

PAGE + A	Hold a page button + turn **SELECT**: cycle pages.
LFO + K	Hold LFO + turn a K knob to map an **LFO** target.
HOME HELD	The help: what every button does.

THE RIVER — river.frasilsynth.com

Back up over USB, in Chrome or Edge: each slot a card, a *shard*. Download them all or a few, put them back whole or slot by slot; the FM-1 asks first: SEL yes, FX no.

QUICK BACKUP	YOUR RIVER	NAVIGATE
to a file, no account	your shards, online	every shard shared

THE PAGES — TAP AGAIN, OR + SELECT: THE NEXT — ×2 TURN TWICE

	PAGE	K1	K2	K3	K4
HOME	SOUND MIXER	CHOIR DRONE	PARTIALS BASS	BREATH GLINT	WARMTH CLOUD
EDIT	DRONE PARAMS CHOIR CHOIR II PARTIALS PARTIALS II BREATH BREATH II	TIMBRE CHOIR SHAPE PARTIALS EVOLVE BREATH GRAIN	SPACE DETUNE INTERVAL TILT BEAT RESONANCE PITCH	MOTION FILTER RESONANCE ODD FORMANT COLOR TONE	BODY WARMTH TYPE STRETCH PEAK SPREAD AIR
ENV	DRONE SHAPE	ATTACK	RELEASE	PRESSURE	VELOCITY
LFO	DRONE MOTION LFO 1 · 2 · 3 … TARGETS	MOTION SHAPE TARGET 1	RATE RATE TARGET 2	TIDE DEPTH TARGET 3	PERIOD POLARITY TARGET 4
SEL	HARMONY	ROOT	SCALE	CHORD	VOICING
ARP	GLINT I GLINT II GLINT ADSR GLINT DELAY GLINT ARP GLINT SEQ GLINT SEQ II GLINT SEQ III	PRESET OCTAVE ATTACK TIME MODE STEP SEQ LENGTH TRANSPOSE	SEQ RATIO DECAY FEEDBACK RATE NOTE RATE CLEAR ×2	LEVEL PING SUSTAIN MIX RANGE ACCENT GATE NEW TAKE ×2	BRIGHT VIBRATO RELEASE SPACE CHANCE RECORD CHANCE UNDO TAKE ×2
SEQ	BASS BASS II BASS ADSR BASS SEQ BASS SEQ II	MODEL LEVEL ATTACK STEP SEQ STEPS	DRIVE OCTAVE DECAY NOTE SEQUENCE	FILTER GLIDE SUSTAIN STEP LENGTH CLEAR ×2	RESONANCE PULSE RELEASE RECORD TRANSPOSE
FX	GENERATIVE FX CLOUD CLOUD II CLOUD III PUMP PUMP II	SWELL SIZE DIFFUSION SHIMMER RATE RELEASE	SPARKLE DECAY MODULATION INTERVAL DRONE ATTACK	BLUR TONE PRE-DELAY BRIGHT BASS OFFSET	SINK FREEZE WIDTH – GLINT –
GLO	GLOBAL MIDI MASTERING	TEMPO DRONE CH THRESHOLD	LOW CUT GLINT CH RATIO	TUNE BASS CH RELEASE	KEY MODE ×2 – GAIN
SAVE	SCENES	SLOT 1–16	MORPH	LOAD	–

After **GLINT DELAY**, as SEQ is set: **GLINT ARP** (ARP) or **GLINT SEQ**, **II**, **III** (SEQ).

MIDI — USB · TRS IN — GLO ×2

1 DRONES | 2 GLINT | 3 BASS — each OFF, 1–16, OMNI

1	MOTION	16	SINK	71	PARTIALS	77	DECAY	123 *notes off*
11	SWELL	17	DRONE	72	BREATH	78	SHIMMER	
12	BODY	18	GLINT	73	ATTACK	79	WARMTH	
13	PRESET	19	BASS	74	TIMBRE	80	FREEZE	
14	SPARKLE	64	SUSTAIN	75	RELEASE	91	SPACE	
15	BLUR	70	CHOIR	76	SIZE	120	*all off*	

CCs on the drones' channel; 17–19: **MIXER**. **PROGRAM CHANGE** 0–15: scenes 1–16. **LEARN**: turn a setting, hold GLO, move a **CC**.