

ΕΘΝΙΚΟ ΜΕΤΣΟΒΙΟ ΠΟΛΥΤΕΧΝΕΙΟ ΣΧΟΛΗ ΗΛΕΚΤΡΟΛΟΓΩΝ ΜΗΧΑΝΙΚΩΝ ΚΑΙ ΜΗΧΑΝΙΚΩΝ ΥΠΟΛΟΓΙΣΤΩΝ ΕΡΓΑΣΤΗΡΙΟ ΜΙΚΡΟΥΠΟΛΟΓΙΣΤΩΝ ΚΑΙ ΨΗΦΙΑΚΩΝ ΣΥΣΤΗΜΑΤΩΝ (MICROLAB)

3η Εργαστηριακή Αναφορα στο μαθημα "ΕΡΓΑΣΤΗΡΙΟ ΜΙΚΡΟΥΠΟΛΟΓΙΣΤΩΝ" του 7ου Εξαμηνου

των φοιτητών της ομάδας 17,

Εμμανουήλ Αναστάσιου Σερλή, Α.Μ. 03118125 Ευάγγελου Περσόπουλου, Α.Μ.: 03121701

<u>1η Άσκηση:</u> -> micro_lab03_ex01.asm και micro_lab03_ex01.c

Το ζητούμενο πρόγραμμα ελέγχει το άναμμα και το σβήσιμο ενός φωτιστικού, με τρόπο παρόμοιο με αυτόν της άσκησης 2.3 του προηγούμενου εργαστηρίου. Η διαφορά έγκειται στην χρήση χρονιστή, ο οποίος αρχικοποιείται κάθε φορά που απαιτείται σβήσιμο των leds μετά από 4sec στην αντίστοιχη ρουτίνα εξυπηρέτησης.

Assembly Program:

```
.include "m328PBdef.inc" ; checked
.equ FOSC MHZ=16
.def counter=r19
.org 0x0
rjmp reset
.org 0x4
rjmp ISR1
.org 0x1A
rjmp ISR TIMER1 OVF
reset:
    ; init stack pointer
    ldi r24, LOW(RAMEND)
    out SPL, r24
    ldi r24, HIGH(RAMEND)
    out SPH, r24
    ;interrupt on the rising edge of INT1 pin
    ldi r24, (1<<ISC11) | (1 << ISC10)
    sts EICRA, r24
    ; Enable INT1
    ldi r24, (1<<INT1)
    out EIMSK, r24
    ldi r24, (1<<CS12) | (0<<CS11) | (1<<CS10) ;prescale=1024
    sts TCCR1B, r24
    sei
IO set:
    ; PORTB as output
    ser r24
    out DDRB, r24
    ; PORTC as input
    clr r24
```

```
out DDRC, r24
    clr counter
main:
    in r24, PINC
    cpi r24, 0x5F
    brne main
    ldi r24, LOW(16*200)
    ldi r25, HIGH(16*200)
    rcall wait_x msec ;sparkle effect
    cpi counter, 0x00
    breq pc5 routine
    ser r24
    out PORTB, r24 ;leds on
    ldi r24, LOW(16*500)
    ldi r25, HIGH(16*500)
    rcall wait x msec
pc5 routine:
    ldi r24, 0x01
    out PORTB, r24
    ldi r24, HIGH(3035)
                            ;4 sec timer
    sts TCNT1H, r24
    ldi r24, LOW(3035)
    sts TCNT1L, r24
    ; enable TCNT1 of TIME/COUNTER1
    ldi r24, (1<<TOIE1)
    sts TIMSK1, r24
    inc counter
    rjmp main
ISR TIMER1 OVF:
    clr r21
    out PORTB, r21
    clr counter
    ldi r18, (0<<TOIE1)
    sts TCNT1L, r18
    reti
ISR1:
    cli
    push r25
    push r24
    in r24, SREG
    push r24
check:
    ldi r24, (1 << INTF1) ;includes sparkle effect
```

```
out EIFR, r24
                   ;at the start of int. routine
   ldi r24, low(16*5)
   ldi r25, high (16*5)
   rcall wait x msec ;5ms delay before interrupt routine
   in r24, EIFR
   cpi r24, 2
   breq check
   ;4 sec timer
   sts TCNT1H, r24
   ldi r24, LOW(3035)
   sts TCNT1L, r24
   ; enable TCNT1 of TIME/COUNTER1
   ldi r24, (1<<TOIE1)
   sts TIMSK1, r24
   ldi r24, 0x01
   out PORTB, r24
   ;inc counter
   cpi counter, 0x00
   breq telos int1
   ldi r24, 0xFF
   out PORTB, r24
   ldi r24, LOW(16*500)
   ldi r25, HIGH(16*500)
   rcall wait x msec
   clr r24
   sts TCNT1H, r24
   sts TCNT1L, r24
   ldi r24, HIGH(3035) ;4 sec timer
   sts TCNT1H, r24
   ldi r24, LOW(3035)
   sts TCNT1L, r24
   ldi r24, 0x01
   out PORTB, r24
telos int1:
   inc counter
   pop r24
   out SREG, r24
   pop r24
   pop r25
   sei
   reti
;produces x sec delay
wait x msec:
   sbiw r24 , 1
   breq telos ; check if r24 = 1
```

```
loop1:
    rcall wait 1msec
    rcall wait4
    nop
    sbiw r24 , 1
   brne loop1 ;1 or 2 cycles
    nop ;1 cycle
   nop
telos:
    rcall wait_1msec
   ret ;3 cycles
wait 1msec:
                        ;produce 988usec delay
    ldi r26 , 97
loop2:
   rcall wait4 ;4+3=7 cycles
             ;1 cycle
    dec r26
   brne loop2
   rcall wait4
   nop
   nop
   nop
    nop
   ret ;4 cycles
 wait4: ret
C Program:
#define F CPU 16000000UL //checked
#include "avr/io.h"
#include<avr/interrupt.h>
#include<util/delay.h>
unsigned int counter=0;
ISR(INT1_vect)
   // delay ms(50);
   TCNT1 = 3035;
   PORTB = 0x01;
   counter++;
   if (counter > 1)
      PORTB = 0xFF;
       delay ms(500);
       TCNT1 = 3035;
       PORTB = 0 \times 01;
```

```
}
ISR(TIMER1 OVF vect)
    PORTB = 0;
    counter = 0;
}
void pc5_routine()
    PORTB = 0 \times 01;
    _delay_ms(200); //for sparkle effect
    TCNT1 = 3035;
    counter++;
}
void pc5 again()
    PORTB = 0xFF;
    delay ms(500);
    PORTB = 0 \times 01;
    TCNT1 = 3035;
}
int main()
    EICRA = (1 << ISC11) | (1 << ISC10); //INT1-PD3
    EIMSK = (1 \ll INT1);
    TCCR1B = (1 << CS12) | (0 << CS11) | (1 << CS10); //prescale 1024
    TIMSK1 = (1 << TOIE1);
    sei(); // enable all interrupts
    DDRC = 0 \times 00;
    DDRB = 0xFF;
    unsigned int pc5=0;
    counter = 0;
    while (1)
    {
        pc5 = PINC;
        //asm("NOP");
        if (pc5 == 0x5F)
         //if(pc5 == 0x20) //only for simulator
         {
             pc5_routine();
             if \overline{\text{(counter > 1)}}
               pc5_again();
         }
```

```
}
return 0;
}
```

2η Άσκηση: -> micro_lab03_ex02.asm και micro_lab03_ex02.c

Το ζητούμενο πρόγραμμα καλείται να ρυθμίσει την φωτεινότητα του PB1 μέσω του duty cycle της αντίστοιχης PWM κυματομορφής. Συγκεκριμένα, η μέγιστη τιμή που μπορεί να λάβει ο καταχωρητής OCR1A είναι 255 (με prescaler 8), η οποία αντιστοιχεί στην μέγιστη φωτεινότητα του LED. Έτσι, υπολογίστηκαν και αποθηκεύτηκαν σε πίνακα όλες οι υπόλοιπες τιμές (από 5 ως 250), οι οποίες απαιτούνται στις περιπτώσεις αυξομείωσής της φωτεινότητας.

Assembly Program:

```
.include "m328PBdef.inc" ; checked
.def counter=r19
.def duty=r20
.def temp=r18
.equ FREQ=16 ;operating freq
reset:
    ; init stack pointer
    ldi r24, LOW(RAMEND)
    out SPL, r24
    ldi r24, HIGH(RAMEND)
    out SPH, r24
    ;fast PWM mode and prescaler=8
    ldi r25 , (1<<WGM10) | (1<<COM1A1)
    sts TCCR1A, r25
    ldi r25 ,(1<<WGM12) | (1<<CS11)
    sts TCCR1B, r25
    sei ; enable all interrupts
    ;set PB1 as output
    ldi r27, 0x02
    out DDRB, r27
    nop
    ldi counter, 4 ;initialize variables and d.c.
    rcall load dc
    nop
```

```
main:
    in temp, PIND
    cpi temp, 0xFD ; check for PD1 ; possibly needs reverse logic value
    breq incr
    cpi temp, 0xFB ; check for PD2 ; possibly needs reverse logic value
    breq decr
    rjmp main
incr:
    cpi counter, 12 ; check if index exceeds 12
    breq incr sp
    inc counter
    rcall load dc ; load dc value
    rjmp main
incr sp:
    ldi counter, 12
    rcall load dc ; load dc value
    rjmp main
decr:
    cpi counter, 0 ; check if index exceeds 0
    breq decr sp
    dec counter
    rcall load dc ; load dc value
    rjmp main
decr sp:
    ldi counter, 0
    rcall load dc ; load dc value
    rjmp main
load dc:
    ldi Zh, HIGH(Table*2) ; multiply by 2 for byte access
    ldi Zl, LOW(Table*2)
    clr r18
    add zl, counter ; access table value by index
    adc zh, r18
    lpm; rz to r0
    mov r22, r0
    sts OCR1AL, r22
    sts OCR1AH, r18
    ldi r24, low(FREQ*200); then wait for 50ms
    ldi r25, high(FREQ*200)
    rcall delay mS ; delay 50ms
    ret
delay mS: ; create ms delay
    ldi r23,249
loop inn:
```

```
dec r23
nop
brne loop_inn

sbiw r24,1
brne delay_mS

ret

;c values -> {5,25,46,66,86,107,127,148,168,189,209,229,250}
Table:
.DW 0x1905,0x422E,0x6B56,0x947F,0xBDA8,0xE5D1,0xFAFA
```

C Program:

```
#define F CPU 16000000UL //checked
#include "avr/io.h"
#include <util/delay.h>
#include<avr/interrupt.h>
const int duty arr[]={5,25,46,66,86,107,127,148,168,189,209,229,250};
int main() {
    unsigned char duty;
    unsigned int temp;
    unsigned int counter;
    //fast PWM mode and prescaler at 8
    TCCR1A = (1 << WGM10) | (1 << COM1A1);
    TCCR1B = (1 << WGM12) | (1 << CS11);
    sei(); // enable all interrupts
    DDRB |=0b00000010; //PB1 as output
    DDRD |=0b00000000;
    //PWM init();
    duty=duty arr[6];
    counter=6; //initialize counter
    OCR1A=duty;
    while(1){
        temp=PIND;
        if(temp==0xFB){
            counter++;
            if(counter<13){
                duty=duty arr[counter];
                OCR1A=duty;
                delay ms(200);
            else{
```

```
counter=12;
                duty=duty arr[counter];
                OCR1A=duty;
                delay ms(200);
        }
        if(temp==0xFD){
            if (counter == 0) {
                counter=0;
                duty=duty arr[counter];
                OCR1A=duty;
                delay ms(200);
            if(counter>0){
                counter--;
                duty=duty arr[counter];
                OCR1A=duty;
                _delay_ms(200);
        }
   }
}
```

3η Άσκηση: -> micro_lab03_ex03.asm και micro_lab03_ex03.c

Το ζητούμενο πρόγραμμα καλείται να παράξει μία κυματομορφή PWM με έξοδο το PB1 και duty cycle 50%. Στην συνέχεια, ανάλογα με το πατημένο πλήκτρο του PORTD, αλλάζει η συχνότητα της κυματομορφής σύμφωνα με τον δοθέντα πίνακα. Οι τιμές του καταχωρητή ICR1(=TOP) υπολογίστηκαν μέσω της σχέσης:

$$TOP = \frac{f_{clk}}{N * f_{pwm}} - 1$$

, όπου N=8 η τιμή του prescaler

 $f_{clk} = 16 MHZ$ η ονομαστική συχνότητα λειτουργίας του μικροελεγκτή f_{pwm} η ζητούμενη τιμή συχνότητας της κυματομορφής

Έτσι, λάβαμε τον κάτωθι πίνακα:

ПЛНКТРО	$f_{pwm}(\mathrm{kHz})$	TOP
PD.0	125	15999
PD.1	250	7999
PD.2	500	3999
PD.3	1000	1999

Assembly Program:

```
.include "m328PBdef.inc" ; checked
.def freql=r19
.def freqh=r20
.def duty=r17
.def temp=r18
.equ FREQS=16 ; operating freq
.equ HALF DUTY=128
reset:
    ; init stack pointer
    ldi r24, LOW(RAMEND)
    out SPL, r24
    ldi r24, HIGH(RAMEND)
    out SPH, r24
    ;fast PWM mode and prescaler=8
    ldi r25 ,(1<<WGM11)| (0<<WGM10) | (1<<COM1A1)
    sts TCCR1A, r25
    ldi r26 ,(1<<WGM12) | (1<<CS11) | (1<<WGM13)
    sts TCCR1B, r26
    sei ; enable all interrupts
    ;set PB1 as output
    ldi r27, 0x02
    out DDRB, r27
    clr duty ;initialize d.c. at 50%
    clr r18
    rcall load dc
    nop
main:
    in temp, PIND
    cpi temp, 0xFF ; check pushed PDi and change freq accordingly
    breq freq0
```

```
cpi temp, 0xFE ; possibly needs reverse logic value
    breq freq1
    cpi temp, 0xFD
    breq freq2
    cpi temp, 0xFB
    breq freq3
    cpi temp, 0xF7
    breq freq4
    rjmp main
freq0:
    clr duty ;initialize d.c. at 50%
    clr r18
    rcall load dc
    rjmp main
freq1:
    ldi duty, HALF DUTY ;initialize d.c. at 50%
    clr r18
    rcall load dc
    ldi freql, 0x7F
    ldi freqh, 0x3E
    rcall load freq
    rjmp main
freq2:
    ldi duty, HALF DUTY ;initialize d.c. at 50%
    clr r18
    rcall load dc
    ldi freql, 0x3F
    ldi freqh, 0x1F
    rcall load freq
    rjmp main
freq3:
    ldi duty, HALF DUTY ;initialize d.c. at 50%
    clr r18
    rcall load dc
    ldi freql, 0x9F
    ldi freqh, 0xF
    rcall load freq
    rjmp main
freq4:
    ldi duty, HALF DUTY ;initialize d.c. at 50%
    clr r18
    rcall load dc
    ldi freql, 0xCF
    ldi freqh,0x7
    rcall load freq
    rjmp main
load dc:
    sts OCR1AH, r18
    sts OCR1AL, duty
```

```
ret
load freq:
    sts ICR1H, freqh
    sts ICR1L, freql
    ret
delay mS: ; create ms delay
    ldi r23,249
loop inn:
    dec r23
    nop
    brne loop inn
    sbiw r24,1
    brne delay mS
    ret
C Program:
#define F CPU 16000000UL //checked
#include<avr/io.h>
#include<avr/interrupt.h>
#include<util/delay.h>
unsigned char duty;
unsigned int top;
unsigned int temp;
const int icr1 arr[]={15999,7999,3999,1999}; //output value on top
int main(){
    //fast PWM mode and prescaler at 8
    TCCR1A = (1 << WGM11) | (0 << WGM10) | (1 << COM1A1);
    TCCR1B = (1<<WGM12) | (1<<CS11) | (1<<WGM13);
    sei(); // enable all interrupts
    duty=128; //50% duty cycle
    DDRB |=0b00000010; //PB1 as output
    temp=0;
    OCR1AL=duty;
    asm("NOP");
    while(1){
        asm("NOP");
        temp=PIND;
        if(temp==0xFE) { //cases
```

OCR1A=duty;

```
//_delay_ms(10);
ICR1=icr1_arr[0];
        else if(temp==0xFD){
             OCR1A=duty;
             //_delay_ms(10);
             ICR1=icr1_arr[1];
        else if(temp==0xFB){
             OCR1A=duty;
             //_delay_ms(10);
             ICR1=icr1_arr[2];
        else if(temp==0xF7){
             OCR1A=duty;
             //_delay_ms(10);
             ICR1=icr1_arr[3];
        else if (temp==0xFF) {
             OCR1A=0;
             //_delay_ms(10);
        }
}
}
```