







APCO Road Marking Tack Coat Primer

Production Description

APCO Road Marking Tack Coat Primer is used to provide an improved bonding of hot melt thermoplastic on concrete masonry surfaces.

Areas of Application

Use APCO Road Marking Tack Coat Primer to pre-treat all concrete surfaces on concrete masonry surfaces before application of thermoplastic road marking.

Technical Data	
Colour Range	Amber
Composition	Hydrocarbon solvent with aromatic resin and tackifier.
Specific Gravity	0.85 - 0.95
Appearance	Clear Liquid
Thinner	Not Required. Supplied RFU (Ready for Use) Do not thin.
Cleaning Solvent	GP Thinner / Acetone
Coverage	8 – 12 sq metres per litre depending on surface profile.
Packs available	20 litres
Component	Single Component
Transportation	Hazchem Code: 3YE and transport classification of 3.1.

Application

APCO Road Marking Tack Coat Primer can be applied by spray, rolled or brushed directly to the road surface. Always allow APCO Road Marking Tack Coat Primer to dry or tack dry before the application of thermoplastic products.

Surface Preparation

Ensure that the area where line marking is to be done is clean and free from all dirt, dust, grease, oil, loosely adhered material and all other surface contamination. If any mould or fungus is present on the surface, wash it with a commercial bleaching agent and then with rinse with clean water. Allow the surface to dry fully before application.

Flammability & Transport

- Highly flammable, Dangerous Goods Class 3.2, Flash Point 32⁰ C, UN 1263, PG III
- Keep away from heat and flame, eliminate any source of ignition.
- Soak all used cloths and rags immediately in water to prevent self-ignition.
- Ensure container is upright with lid secure.
- Ensure the container is secured in the vehicle for transport.

Environmental

- Do not wash painting equipment and allow waste to enter drains and water ways.
- Do not dispose of unwanted paint and thinners that will enter drains and water ways.
- Refer to state / local EPA and council web sites for environmental and safe disposal details.









APCO Road Marking Tack Coat Primer

Safety & Precautions

- Do not apply when surface temperature is below 10^o C.
- Do not apply in environments of high humidity/moisture, or if pending rain is a possibility.
- Apply in calm fine weather conditions.
- Cease painting if weather changes are forecast.
- Use only the recommended thinner for dilution and cleaning.
- Check paint colour to the colour chart/standard prior to application
- Provide adequate ventilation during use.
- Keep out of reach of children
- Avoid exposure of the new paint film to steam for 48 hours and to washing or scrubbing for 7 days.
- Check cross cut adhesion test of old coating before repainting.
- Apply a test sample for compatibility of this product over a small test area.

The technical information and suggestions for use and application are given in good faith. Since conditions of use are beyond the manufacturer's control, information contained herein is without warranty, implied or otherwise. The manufacturer does not assume any liability for any loss or injury resulting from the use of the product. Cooler temperature, higher film thickness and higher humidity conditions will require longer drying times

Omega Paints 111 Kurrajong Avenue Mt Druitt NSW 2770 Phone (02) 9632 0000 / www.omegapaints.com.au Reviewed July 2014