







Oil Prep Wood Primer Interior/Exterior

Production Description

APCO OilPrep Wood Primer Interior/Exterior is a premium quality oil based primer for preparing timber surfaces for subsequent paint coats. The primer has high opacity and film build. OilPrep Wood Primer Interior/Exterior has deep penetrating and sealing properties. Easy to sand, OilPrep Wood Primer Interior/Exterior provides an excellent base coat for subsequent coats.

Areas of Application

All timber, plywood, hardboard & custom wood surfaces. For use on bare substrate or for spot priming. For interior & exterior use.

White and Pink.
Flat
Resistance to aliphatic hydrocarbons is good. Other solvents may
attack the film.
Dry film is not toxic
Enamel Thinner 600 / Min turps. Though product is designed for
undiluted application, up to 5% thinner can be used if necessary.
Up to 5% thinner may be necessary depending on method of
application and climatic conditions.
10 -14 sq. m. / litre per coat. Practical coverage may depend on
surface profile, method of application and losses.
Touch Dry 4 hours / Recoat 16 hours*
1 litre, 4 litre, 10 litre,
APAS 0181

^{*}Cooler temperature, higher film thickness and higher humidity conditions will require longer drying times

Method of Application

Brush, Roller or Spray. Please use the method best suited to your requirement and skill. Brushing is recommended for application over bare timber for thorough penetration in to the timber grain and nail holes etc. Apply OilPrep Wood Primer Interior/Exterior and allow to dry before filling nail holes and surface cracks and defects. Filling bare and unprimed surfaces allows the filler to dry out, shrink and may fail.

Surface Preparation

Remove all surface contamination and ensure the surface clean and dry and free of dust, dirt, grease, etc. If mould or fungus is present on the surface, wash with a commercially available bleaching agent and then treat with antifungal solution. For previously painted surfaces, remove all loose and flaking paint. Do not apply OilPrep Wood Primer Interior/Exterior over previously painted surfaces, may be used to spot prime bare timber.

Note: OilPrep Wood Primer Interior/Exterior is a preparatory coating only and therefore needs to be over coated with the finished product once thoroughly dry. Do not allow OilPrep Wood Primer Interior/Exterior to be left exposed to UV rays and the weather for any period of time before top coating.

^{**}Practical coverage may depend on surface profile, method of application and losses. Higher film thickness will lead to lower coverage.









Oil Prep Wood Primer Interior/Exterior

Mix and Colour Check

Mix the paint before application with a wide flat (25mm) paddle or a hand paint mixer with a perforated base, in a circular lifting motion from the bottom of the container for 5 minutes or until the paint and colour are thoroughly mixed. Remix the paint every 2 hours to ensure product consistency.

Check colour to the colour chart/standard prior to application. Inner mix multiple containers together to ensure colour consistency. Replace and secure container lid during painting to prevent the paint drying within the container.

Coating Maintenance

Washing the painted surface periodically will maintain the look of a newly painted surface longer. Clean the surface with a diluted sugar soap or a mild detergent and rinse well with clean water.

Do not use scouring pads, abrasive brushes, high pressure washing or solvent to clean the painted surface. These will damage the paint film and cause premature failure of the coating.

Flammability & Transport

- Highly flammable, Dangerous Goods Class 3.2, Flash Point 32⁰ C, UN 1263, PG III
- Keep away from heat and flame, eliminate any source of ignition.
- Soak all used cloths and rags immediately in water to prevent self-ignition.
- Ensure container is upright with lid secure.
- Ensure the container is secured in the vehicle for transport.

Environmental

- Do not wash painting equipment and allow waste to enter drains and water ways.
- Do not dispose of unwanted paint and thinners that will enter drains and water ways.
- Refer to state / local EPA and council web sites for environmental and safe disposal details.

Safety & Precautions

- Do not apply when surface temperature is below 10^o C or over 35^o C
- Do not apply in environments of high humidity/moisture, or if pending rain is a possibility.
- Apply in calm fine weather conditions and only during daylight hours.
- Cease painting 2 hours before sunset or if weather changes are forecast.
- Use only the recommended thinner for dilution and cleaning.
- Check paint colour to the colour chart/standard prior to application
- Provide adequate ventilation during use.
- Keep out of reach of children
- Avoid exposure of the new paint film to steam for 48 hours and to washing or scrubbing for 7 days.
- Check cross cut adhesion test of old coating before repainting.
- Apply a test sample for compatibility of this product over a small test area.

The technical information and suggestions for use and application are given in good faith. Since conditions of use are beyond the manufacturer's control, information contained herein is without warranty, implied or otherwise. The manufacturer does not assume any liability for any loss or injury resulting from the use of the product. Cooler temperature, higher film thickness and higher humidity conditions will require longer drying times

Omega Paints 111 Kurrajong Avenue Mt Druitt NSW 2770 Phone (02) 9632 0000 / www.omegapaints.com.au Reviewed July 2014