sign up log in tour help stack overflow careers

Stack Overflow is a question and answer site for professional and enthusiast programmers. It's 100% free, no registration required.

Take the 2-minute tour

Linux device driver handling multiple interrupt sources/vectors



I am writing a device driver to handle interrupts for a PCIe card, which currently works for any interrupt vector raised on the IRQ line.

But it has a few types that can be raised, flagged by the Vector register. So now I need to read the vector information and be a bit cleverer...

So, do I:-

- 1/ Have separate dev nodes <code>/dev/int1</code> , <code>/dev/int2</code> , etc for each interrupt type, and just doc that <code>int1</code> is for vector type A etc?
- 1.1/ As each file/char-devices will have its own minor number, when opened I'll know which is which. i think.
- 1.2/ ldd3 seems to demo this method.
- 2/ Have one node /dev/int (as I do now) and have multiple processes hanging off the same read method? sounds better?!
- 2.1/ Then only wake the correct process up...?
- 2.2/ Do I use separate $wait_queue_head_t$ $wait_queue$ s? Or different flag /test conditions?

In the read method:-

```
wait_event_interruptible(wait_queue, flag);
```

In the handler not real code! :-

```
int vector = read_vector();
if vector = A then
   wake_up_interruptible(wait_queue, flag)
   return IRQ_HANDLED;
else
   return IRQ_NONE/IRQ_RETVAL?
```

EDIT: notes from peoples comments :-

- 1) my user-space code $\ _{\text{mmap}}$'s all of the PCIe firmware registers
- 2) User-space code has a few threads, each perform a blocking read on the device driver device nodes, which then returns data from the firmware when an interrupt occurs. I need the correct thread woken up depending on the interrupt type.

linux device-driver linux-device-driver interrupt

edited Mar 22 '11 at 11:15



3 Answers

I am not sure I understand correctly what you mean with the Vector register (a pointer to some documentation would help me precise for your case).

Anyway, any PCI device gets a unique interrupt number (given by the BIOS or some firmware on other architectures than x86). You just need to register this interrupt in your driver.

One other thing that I do not really understand is why you would export your interrupts as a dev node: interrupts are certainly something that need to remain in your driver/kernel code. But I guess here you want to export a device that is then accessed in userspace. I just find

/dev/int no to be a good naming.

For your question about multiple dev nodes: if your different interrupt sources then provide access to different hardware resources (even if on the same PCI board) I would go for option 1), with a wait_queue for each device. Otherwise, I would go for option 2)

Since your interrupts are coming from the same physical device, if you chose option 1) or option 2), the interrupt line will have to be shared and you will have to read the *vector* in your interrupt handler to define which *hardware resource* raised the interrupt.

For option 1), it would be something like this:

For option 2, it would be similar, but you would have only one if clause (for the respective vector value) in every different interrupt handler that you would request for every node.

edited Mar 22 '11 at 12:39

answered Mar 22 '11 at 8:10

Longfield
767 5 16

sorry docs are proprietary/custom firmware. but the memory map contains a source vector so I know which type has been raised. Thanks, I have the <code>request_irq</code> code bit working, my driver currently hangs off this single IRQ, but the PCle card raises different interrupts, which as we all know, all raise the same IRQ line. – <code>lan Vaughan Mar 22 '11 at 10:57</code>

I am not exporting the *interrupts* per-sa, I am exposing a device node for user-space to use, as I might not of been clear, I have updated my Q, see also my other comment reply. And the name int is just a pseudo name for here. Yes, your right with having to read the *vector*. (and without meaning to insult, but your option 1 code looks very much like my pseudo code in my Q!? (but is actual code!)) — Ian Vaughan Mar 22 '11 at 11:106

Don't worry, I don't feel insulted, there are not 10 ways of doing irq handling. What I wanted to mean with this example is that you can have one single irq handler that takes all the possible sources in the vector, or many irq handlers that share this interrupt and all address one irq source in the vector. For version 1) you would have one device with many queues and for version 2) you would have many devices with each one queue. From your edited question, I would say option 2 maybe looks simpler and cleaner. – Longfield Mar 22 '11 at 12:43



If you have different chanel you can $_{\rm read}()$ from, then you should definitely use different minor number. Imagine you have a card whith four serial port, you would definitely want four $_{\rm dev/ttySx}$.

But does your device fit whith this model?

answered Mar 22 '11 at 7:56



I like the analogy of the serial ports, I might go down this route, ensuring that the card firmware handles concurrency! can of worms – lan Vaughan Mar 22 '11 at 11:13

First, I assume you're not trying to get your code into the mainline kernel. If you are, expect a vigorous discussion about the best way to do this. If you're writing a simple interrupt handling driver for a card which is mostly driven by mmap from user-space, there are a lot of ways to solve this problem.

If you use multiple device nodes (option 1), you can also implement poll so that a single application can open multiple device nodes and wait for a selection of interrupts. The minor number will be sufficient to tell them apart. If you have a wake queue for each vector, you can wake only the relevant listeners. You'll need to latch the vector after a successful poll to be sure that the read succeeds.

If you use a single device node (option 2), you'll need to add some extra magic so that the threads can register their interest in particular interrupt vectors. You could do this with an ioctl, or have the threads write the interrupt vectors to the device. Each thread should open the device node to get its own file descriptor. You can then associate the list of requested vectors with each open file descriptor. As a bonus, you can let the application read the interrupt vector from the device, so it knows which one happened.

You'll need to think about how the interrupt gets cleared. The interrupt handler will need to remove the interrupt, then store the result so it can be passed to user-space. You might find a kfifo useful for this rather than a wait queue. If you have a fifo for each open file descriptor, you can distribute the interrupt notifications to each listening application.

edited Mar 22 '11 at 13:36

answered Mar 22 '11 at 7:57



nope, not submitting anything, just writing a bespoke PCle driver for in house card, and yes, all of the registers on the PCle card are mmap ed in the userspace application. I like the single node with a write, I was thinking I'd have to add an ioctl as you state, very nifty. I dont need to pass the result of the interrupt per-se, just release the correct blocking read (I do a copy_to_user and return some data). (I have updated my Q with some clarifications) - lan Vaughan Mar 22 '11 at 10:50

I don't think I need poll as the user-space application has a thread for each node it open s and pends/blocks on a read with. – Ian Vaughan Mar 22 '11 at 11:17

I've worked on a few devices like that. If you want separate threads to monitor different interrupts, you either need multiple device nodes, or for each thread to open the single device node and acquire its own file descriptor. Do you need to queue up and count interrupts, or should each read block until the next one comes along? – Adrian Cox Mar 22 '11 at 12:45

I believe your two options are as per my 1 & 2? ("either multiple devices...or...") Is that a correct assumption? I do not need to queue them up or count (each thread will have 1 blocking read, it will be activated by my driver and then loop round and block again.) – lan Vaughan Mar 22 '11 at 13:24

I've edited my answer to refer back to your points 1&2, and mentioned threading. I've still left in a few points that aren't really relevant given your comments. – Adrian Cox Mar 22 '11 at 13:36