Screen PPI Calculator
Calculator: screen-ppi-calculator | Engine version: 1
Raw engine values: full numeric precision; no display rounding or sampled rows.
Units appear only where supplied by the calculation or bound display metadata.
Embedded Unicode glyphs are readable.
Unsupported characters and controls use explicit Unicode escapes.
Tagged PDF; PDF/UA conformance: UNVERIFIED.
Text follows document order; charts include complete numeric text alternatives.

INPUTS
Width (pixels) [pixels]
input["widthPixels"] = 1920
Height (pixels) [pixels]
input["heightPixels"] = 1080
Diagonal (in) [in]
input["diagonalInches"] = 15.6

RESULTS
Pixel density [PPI]
output["value"] = 141.21199808219862
output["steps"][0] = "Screen PPI = 141.21199808219862"

METHODOLOGY
Deterministic calculation using the reviewed Technology & Computing engine.\u000aTechnical calculation revision: technology.screen-ppi@1\u000a\u000aPixel density from pixel dimensions and physical diagonal size.\u000aPPI = √(width² + height²) ÷ diagonal inches

DECLARED FORMULAS
screen-ppi-calculator: PPI = √(width² + height²) ÷ diagonal inches
Pixel density from pixel dimensions and physical diagonal size.

SOURCES
NIST — image resolution terminology
https://www.nist.gov/glossary-term/28116
NIST defines nominal image resolution as pixels per unit distance (for example ppi or ppmm). CalcuMint derives the screen pixel diagonal geometrically from supplied horizontal and vertical pixel dimensions, then divides by the supplied physical diagonal in inches.