# Quick Installation Guide to AWUS036NHR

|	
	Insert the supplied CD into your computer's disc drive. The setup program should start automatically. If the instructions do not appear, locate and double-click the setup.exe file on the CD.
	When the 1st title screen appears, click "**AWUS036NHR**" then on the following screen select the operating system your computer is operating on.
	Click **Next** and proceed with the following instructions to complete the installation process.
	Select **No, I'll restart my computer later** and click **Finish**.

|	Found New Hardware notification will pop up from the notification area after AWUS036NHR was been plugged in.
	Double click on the "**Realtek 11n USB Wireless LAN Utility**" and select the **Available Network** tab. Double click your target network to establish the wireless connection.

MAC OS X

	Insert the supplied CD into your computer's disc drive.
036NHR_MacOS10.4 2012/1/10 下午 0... 036NHR_MacOS10.5 2012/1/10 下午 0... 036NHR_MacOS10.6 2012/1/10 下午 0... 036NHR_MacOS10.7 2012/1/10 下午 0... QIG_036NHR 2011/9/13 下午 0...	Click on the CD icon located on your desktop and look for installation folder "NHR" and then select your Mac OS then click **Installer.pkg** to launch the installation wizard.
	Click **Continue** and proceed with the following instructions to complete the installation process.

	For the authentication menu, please enter your name and password then click **OK** to continue the installation process.
	Click **Restart** to complete the installation process.
	Plug in your AWUS036NHR into your computer and the **Wireless Network Utility** window will pop up. Select your target network then **Connect** to establish the wireless connection.