


Figure 11.8 Design of Stop-and-Wait Protocol



## Algorithm 11.3 Sender-site algorithm for Stop-and-Wait Protocol

```
1 while(true)
                                   //Repeat forever
 2 canSend = true
                                   //Allow the first frame to go
    WaitForEvent();
                                   // Sleep until an event occurs
     if (Event (Request To Send) (AND can Send)
 6
 7
        GetData();
       MakeFrame();
        SendFrame();
                                   //Send the data frame
10
        canSend = false;
                                   //Cannot send until ACK arrives
11
     WaitForEvent();
                                   // Sleep until an event occurs
12
     if (Event (ArrivalNotification) // An ACK has arrived
13
14
        ReceiveFrame();
                                   //Receive the ACK frame
15
16
        canSend = true;
17
```






#### Algorithm 11.2 Receiver-site algorithm for the simplest protocol

```
1 while(true)
                                   // Repeat forever
2 {
 3
    WaitForEvent();
                                    // Sleep until an event occurs
    if (Event (Arrival Notification)) //Data frame arrived
 5
 6
        ReceiveFrame();
7
        ExtractData();
        DeliverData();
                                    //Deliver data to network layer
 9
10 }
```

Figure 11.9 Flow diagram for Example 11.2



## 11-5 NOISY CHANNELS

Although the Stop-and-Wait Protocol gives us an idea of how to add flow control to its predecessor, noiseless channels are nonexistent. We discuss three protocols in this section that use error control.

# Topics discussed in this section:

Stop-and-Wait Automatic Repeat Request
Go-Back-N Automatic Repeat Request
Selective Repeat Automatic Repeat Request


JECH KLIMAAD KI



# Note

Error correction in Stop-and-Wait ARQ is done by keeping a copy of the sent frame and retransmitting of the frame when the timer expires.

Figure 11.11 Flow diagram for Example 11.3



# -

# Example 11.4

Assume that, in a Stop-and-Wait ARQ system, the bandwidth of the line is 1 Mbps, and 1 bit takes 20 ms to make a round trip. What is the bandwidth-delay product? If the system data frames are 1000 bits in length, what is the utilization percentage of the link?

## **Solution**

The bandwidth-delay product is

$$(1 \times 10^6) \times (20 \times 10^{-3}) = 20.000 \text{ bits}$$

HESH KUMAR N

2000

Set Up Monitor



## Example 11.4 (continued)

The system can send 20,000 bits during the time it takes for the data to go from the sender to the receiver and then back again. However, the system sends only 1000 bits. We can say that the link utilization is only 1000/20,000, or 5 percent. For this reason, for a link with a high bandwidth or long delay, the use of Stop-and-Wait ARQ wastes the capacity of the link.