AquaPure X2 Water Purifier

User manual — model AP-X2 — Northwind Labs

1. Safety instructions

Read this manual before installing the AquaPure X2. Connect the purifier only to the cold-water supply: the inlet water temperature must stay between 5°C and 38°C. Do not install the unit outdoors or where it can freeze. Unplug the purifier before cleaning it or replacing filters. Children should not play with the appliance.

2. Technical specifications

Specification	Value
Filtration stages	4: sediment filter, activated carbon filter, reverse osmosis (RO) membrane, UV-C LED
Tank capacity	6 litres
Flow rate	1.2 litres per minute
Inlet water pressure	1.0 to 4.0 bar
Power consumption	48 W
Dimensions (W x D x H)	42 x 18 x 45 cm
Weight (empty)	7.8 kg

3. Installation

1. Close the cold-water supply valve under the sink. 2. Connect the inlet hose to the supply valve using the supplied adapter. 3. Connect the drain hose to the sink drain. 4. Plug in the power adapter and open the supply valve. 5. Before first use, let the purifier flush for 10 minutes and discard this water. The blue indicator light shows that the purifier is ready.

4. Indicator lights

Light	Meaning
Blue	Normal operation
Amber, blinking	A filter must be replaced within the next 2 weeks
Red	A filter has expired; replace it now
Red, blinking with a beep	Leak detected; the inlet valve closes automatically

5. Filter replacement

Replace the filters according to the following schedule. Intervals are based on average household use of 10 litres per day; replace filters earlier if your water is very hard or contains a lot of sediment.

Component	Part number	Replace every
Sediment filter	AP-SF2	6 months
Activated carbon filter	AP-CF2	6 months
RO membrane	AP-RO2	24 months
UV-C LED module	AP-UV2	3 years

To replace a filter, unplug the purifier, open the front cover, turn the filter a quarter turn anticlockwise and pull it out. Insert the new filter and turn it clockwise until it clicks. After replacing a filter, reset the filter timer by pressing and holding the FILTER button for 5 seconds until the indicator turns blue.

6. Cleaning and maintenance

Wipe the outside of the purifier with a soft, damp cloth. Do not use abrasive cleaners or solvents. Sanitise the water tank every 6 months with the AquaPure cleaning kit (part AP-CK1). If the purifier will not be used for more than two weeks, close the supply valve and empty the tank; flush the system for 5 minutes before using it again.

7. Troubleshooting

Problem or code	Possible cause and solution
Low water flow	Check that the supply valve is fully open. Replace the sediment filter if it is older than 6 months.
Water tastes or smells unusual	Flush the system for 5 minutes. If the problem continues, replace the activated carbon filter.
Error E1	Inlet water pressure is too low (below 1.0 bar). Check the supply valve and household water pressure.
Error E2	Leak detected. Unplug the purifier, dry the leak sensor under the unit and check all hose connections.
Error E3	UV-C module fault. Do not drink the water; contact customer support.

8. Warranty and support

The AquaPure X2 comes with a 2-year standard warranty. The warranty is extended to 5 years when you register the product within 60 days of purchase at northwind-labs.example/register. Filters and the cleaning kit are consumables and are not covered by the warranty. Damage caused by incorrect installation, freezing or connection to hot water is not covered.

Customer support is available by email at support@northwind-labs.example and by phone on +31 10 555 0199, Monday to Friday from 08:30 to 17:30 (CET).